

PARTS CATALOGUE

20D'93 (6L3)
25N'93 (6L2)

2R6L2-300E1

CONTENTS

Fig. 1	CYLINDER. CRANKCASE	A3
Fig. 2	CRANKSHAFT. PISTON	A4
Fig. 3	INTAKE	A5
Fig. 4	CARBURETOR	A6
Fig. 5	OIL PUMP	A7
Fig. 6	STARTER	B1
Fig. 7	FUEL	B2
Fig. 8	TOP COWLING	B3
Fig. 9	BOTTOM COWLING	B4
Fig. 10	BRACKET 1	B5
Fig. 11	BRACKET 2	B6
Fig. 12	STEERING	B7
Fig. 13	CONTROL	C1
Fig. 14	UPPER CASING	C2
Fig. 15	LOWER CASING. DRIVE 1	C3
Fig. 16	LOWER CASING. DRIVE 2	C4
Fig. 17	MAGNETO	C5
Fig. 18	ELECTRICAL 1	C6
Fig. 19	ALTERNATE 1 (20DE(R)O/25NE(R)O MODEL)	C7
Fig. 20	ALTERNATE 2 (20DE(R)O/25NE(R)O MODEL)	D1
Fig. 21	REMOTE CONTROL	D2
Fig. 22	REMO-CON ATTACHMENT	D3
Fig. 23	STEERING GUIDE ATTACHMENT	D4
Fig. 24	REMOTE CONTROL ASSY 1	D5
Fig. 25	OPTIONAL PARTS 1	D6
Fig. 26	OPTIONAL PARTS 2	D7
Fig. 27	OPTIONAL PARTS 3	E1
Fig. 28	OPTIONAL PARTS 4	E2
Fig. 29	REPAIR KIT 1	E3
Fig. 30	REPAIR KIT 2	E4
	NUMERICAL INDEX	

This Parts Catalogue is related to the parts in use for the Yamaha outboard motor 20D'93 (6L3)/25N'93(6L2). When you are ordering replacement parts for the 20D'93(6L3)/25N'93 (6L2), refer to this Parts Catalogue and quote both part numbers and part names correctly.

1. Modifications or additions which have been made after issue of the Parts Catalogue will be announced in the Yamaha Parts News.
It is advisable that according to the Yamaha Parts News you make necessary corrections to the Parts Catalogue on hand to keep it up-to-date.

2. Abbreviations

The following abbreviations are used in this Parts Catalogue.

UR	Use size (thickness) and/or number as required.
UN	Use as many as you need.
AP	Alternate Parts
STD	Standard
O/S	Over Size

3. Parts, which are to be supplied in the form of assemblies, are listed with an indentation of one letter's space, and a dot (.) is put against the name of each part.

EXAMPLE

CARBURETOR ASS'Y

. JET, pilot

. NOZZLE, main

4. Indication of No. of constituent parts for assembly.



The numeral appearing to the right of each constituent part under the description indicates the quantity of such parts for each individual assembly unit.

EXAMPLE

Part No.	Description	Q'ty	Remarks
6E0-85500-70	C.D.I. MAGNETO ASS'Y	1	
6E0-85550-70	. ROTOR ASS'Y	1	
6E0-15723-00-94	. . PULLEY, starter	1	

5. Initial Serial No. and Color Code


Engine Serial No.		
20DMO	S :	105105 and following
	L :	402106 and following
20DEO	S :	154488 and following
	L :	451437 and following
20DERO	S :	180101 and following
	L :	480101 and following
25NMO	S :	108271 and following
	L :	403723 and following
25NEO	S :	150989 and following
	L :	451630 and following
25NERO	S :	280101 and following
	L :	480101 and following



Color Code	Color Name	Abbreviate
EJ	METALLIC MARINE BLUE	MMB

Fig. 1 CYLINDER. CRANKCASE

Ref.No.	Parts No.	Description	Q'ty	Ref.No.	Parts No.	Description	Q'ty
1	6L2-W0090-11-EJ	CRANK CYLINDER ASSY (Ref. No.2 to 37 and Fig. 2, Ref. No. 1 to 29)	1	20	6L2-11193-A1	GASKET, head cover 1	1
2	6L2-15100-10-94	CRANKCASE ASSY	1	21	90119-08M20	BOLT, with washer	10
3	6E5-11372-00	.NIPPLE, hose	4	22	97313-06016	BOLT	2
4	90445-07M15	HOSE	2	23	92990-06600	WASHER, plate	2
5	90467-06016	CLIP	4	24	6E5-12411-01	THERMOSTAT	1
6	93604-10M03	PIN, dowel	4	25	6H4-12413-00-9M	COVER, thermostat	1
7	95612-08645	BOLT, stud	2	26	6J8-12414-A0	GASKET, cover	1
8	90201-08086	WASHER, plate	2	27	97313-06025	BOLT	2
9	95333-08600	NUT	2	28	92990-06600	WASHER, plate	2
10	90119-08M21	BOLT, with washer	4	29	6L2-41111-00-9M	INNER COVER, exhaust	1
11	90119-06M14	BOLT, with washer	4	30	6L2-41112-A1	GASKET, exhaust inner cover	1
12	6J8-11325-00	ANODE	1	31	6L2-41113-00-9M	OUTER COVER, exhaust	1
13	6H3-11327-00-94	COVER, anode	1	32	676-11372-00	.NIPPLE, hose	1
14	6H3-11328-00	GROMMET, anode	1	33	6L2-41114-A1	GASKET, exhaust outer cover	1
15	97313-06016	BOLT	1	34	97313-06030	BOLT	10
16	92990-06600	WASHER, plate	1	35	92990-06600	WASHER, plate	10
17	6L2-11111-00-94	HEAD, cylinder 1	1	36	90445-10M40	HOSE	1
18	6L2-11181-A1	GASKET, cylinder head 1	1	37	6L2-45113-A1	GASKET, upper casing	1
19	6L2-11191-00-9M	COVER, cylinder head 1	1	38	94702-00271	PLUG, spark (NGK BR7HS 10)	2






Fig. 2 CRANKSHAFT. PISTON

Ref.No.	Parts No.	Description	Q'ty	Ref.No.	Parts No.	Description	Q'ty
1	6L2-11400-10	CRANKSHAFT ASSY	1	18	6L2-11631-00-97	PISTON (STD)	2
2	6L2-11412-00	.CRANK 1	1		6L2-11635-00	PISTON (0.25MM O/S)	2 AP
3	6L2-11422-00	.CRANK 2	1		6L2-11636-00	PISTON (0.50MM O/S)	2 AP
4	6L2-11432-00	.CRANK 3	1	19	6L2-11610-00	PISTON RING SET (STD)	2
5	6L2-11442-00	.CRANK 4	1		6L2-11610-10	PISTON RING SET (1ST O/S)	2 AP
6	93313-628U0	.BEARING, cylindrical	1		6L2-11610-20	PISTON RING SET (2ND O/S)	2 AP
7	93102-26M27	.OIL SEAL	1	20	648-11633-00	PIN, piston	2
8	93210-42159	.O-RING	1	21	93602-18M12	PIN, dowel	62
9	93306-305U5	.BEARING	2	22	93450-20026	CIRCLIP	4
10	6L2-11651-00	.ROD, connecting	2	23	90201-18522	WASHER, plate	4
11	6L2-11681-00	.PIN, crank 1	2	24	6L2-15396-00-5B	HOUSING, oil seal	1
12	93310-424W9	.BEARING, cylindrical	2	25	93102-25142	OIL SEAL	1
13	90209-24M15	.WASHER	4	26	93101-13M37	OIL SEAL	1
14	6L2-11515-00	.SEAL, labyrinth 1	1	27	93210-56M80	O-RING	1
15	91690-30010	.PIN, spring	1	28	97395-06016	BOLT	2
16	6J8-11536-00	.GEAR, drive	1	29	92990-06600	WASHER, plate	2
17	90201-50306	WASHER, plate	1				




Fig. 3 INTAKE

Ref.No.	Parts No.	Description	Q'ty	Ref.No.	Parts No.	Description	Q'ty
1	6L2-13610-00	REED VALVE ASSY	2	15	93210-35M86	O-RING	2
2	6L2-W0004-00	.REED SET	1	16	97313-05012	BOLT	4
3	98580-05016	SCREW, pan head	4	17	92990-05600	WASHER, plate	4
4	92990-05600	WASHER, plate	4	18	97390-06085	BOLT	4
5	6L2-13641-10-94	MANIFOLD 1	1	19	92990-06600	WASHER, plate	4
6	676-14485-00	.PIPE, joint	2	20	6L2-14476-11	SEAL	1
7	6L2-13621-00	GASKET, valve seat	1	21	6L2-14418-00	COVER 2	1
8	97313-06025	BOLT	6	22	97886-05016	SCREW, pan head	4
9	92990-06600	WASHER, plate	6	23	92990-05600	WASHER, plate	4
10	90445-09012	HOSE	1	24	6J8-41259-00	ROD, choke 3	1
11	90467-08004	CLIP	2	25	661-41262-02	JOINT, choke lever	3
12	6L2-14198-00	GASKET	2	26	6J8-41271-01	KNOB, choke	1
13	6L2-14417-00-94	COVER 1	1	27	6L2-41257-00	ROD, choke 2	1
14	6L2-14476-00	SEAL	1	28	6L2-41217-00	ROD, accel. lever	1

Fig. 4 CARBURETOR

Ref.No.	Parts No.	Description	Q'ty	Ref.No.	Parts No.	Description	Q'ty
1	6L2-14301-01	CARBURETOR ASSY 1 (Upper) (25N MODEL)	1 UR	15	6L2-14323-00	.SCREW, air adjusting	2
	6L3-14301-00	CARBURETOR ASSY 1 (Upper) (20D MODEL)	1 UR	16	646-14212-01	.SPRING, pilot adjusting	4
2	6L2-14302-01	CARBURETOR ASSY 2 (Lower) (25N MODEL)	1 UR	17	664-14321-01	.SCREW, throttle	2
	6L3-14302-00	CARBURETOR ASSY 2 (Lower) (20D MODEL)	1 UR	18	97980-04112	.SCREW, with washer	8
3	6L2-14381-00	.BODY, float chamber 1 (Upper)	1 UR	19	677-14383-01	.SCREW, drain	2
	6L2-14383-00	.BODY, float chamber 2 (Lower)	1 UR	20	6L2-14398-00	.GASKET	2
4	6L2-14384-00	.GASKET, float chamber	2	21	677-24444-01	.SCREW	4
5	6L2-14385-00	.FLOAT	2	22	98980-04006	.SCREW, bind	2
6	6E5-14386-01	.PIN, float	2	23	6A0-24421-01	.VALVE, check	2
7	6L2-14392-00	.VALVE, needle	2	24	95380-03600	.NUT (25N MODEL)	2 UR
8	98580-04010	.SCREW, pan head	4		98813-03100	.NUT (20D MODEL)	2 UR
9	6L2-14157-00	.COVER, mixing	2	25	6E7-14325-00	.SCREW, pan head	2
10	6L2-14399-00	.GASKET	2	26	6L2-24435-00	.GASKET, body 2 (25N MODEL)	1 UR
11	6L2-14341-00	.NOZZLE, main	2		677-24435-01	.GASKET, body 2 (20D MODEL)	1 UR
12	30X-14343-63	.JET, main (#125)	2	27	6L2-24413-00	.BODY 2	1
13	6L2-14342-30	.JET, pilot (# 60)	2	28	682-24412-01	.BODY 1	1
14	50M-14355-00	.PLUG	2	29	677-24411-02	.DIAPHRAGM	1
				30	677-24434-02	.GASKET, body	1
				31	6L2-14578-00	.COLLAR	1
				32	92901-04100	.WASHER, spring	4





Fig. 5 OIL PUMP

Ref.No.	Parts No.	Description	Q'ty	Ref.No.	Parts No.	Description	Q'ty
1	90201-08M93	WASHER, plate	1	24	6L2-21758-00	WASHER, special 2	1
2	6L2-11537-00	GEAR, driven	1	25	6H1-24633-00	CHAIN, ball	1
3	6J8-13117-00	COLLAR, distance	1	26	6H1-21757-00	WASHER, special 1	2
4	93210-13595	O-RING	1	27	6J8-13411-00	STRAINER, oil	1
5	6L2-13200-00	OIL INJECTION PUMP ASSY	1	28	6J8-13414-00	GASKET, strainer cover	1
6	6L2-13471-00	.PLUG, drain	1	29	6L2-13416-00	PIPE, oil 1	1
7	1YU-13187-00	.GASKET	1	30	90467-08004	CLIP	1
8	93210-19M82	.O-RING	1	31	90467-11M08	CLIP	1
9	97513-05218	BOLT, with washer	1	32	90445-11M03	HOSE	2
10	90109-05M33	BOLT	1	33	90445-11M07	HOSE	2
11	90445-07M32	HOSE	2	34	6J8-21744-00	BREATHER	1
12	90468-07M02	CLIP	4	35	6E5-24376-10	PIPE, joint 1	1
13	6J8-13183-00	VALVE, check	2	36	90467-10M04	CLIP	1
14	90445-07M04	HOSE	1	37	90464-11M24	CLAMP	1
15	90468-07M02	CLIP	4	38	90446-10M02	HOSE	1
16	90445-07M16	HOSE	1	39	6A0-82317-00	DAMPER, ignition coil	3
17	682-41237-50	JOINT, link	1	40	624-42542-00	PIPE	3
18	6H1-41237-00	JOINT, link	1	41	90119-06M65	BOLT, with washer	3
19	95380-05700	NUT	1	42	6L2-21798-00	BRACKET, damper	1
20	90202-05088	WASHER, plate	1	43	97313-06016	BOLT	2
21	90468-05M03	CLIP	1	44	92990-06600	WASHER, plate	2
22	6L2-21707-01	OIL TANK COMP.	1	45	6L2-85720-01	OIL LEVEL GAUGE ASSY	1
23	6H4-21770-00	OIL TANK CAP ASSY	1				






Fig. 6 STARTER

Ref.No.	Parts No.	Description	Q'ty	Ref.No.	Parts No.	Description	Q'ty
1	6L2-15710-01	STARTER ASSY	1	22	92990-06600	WASHER, plate	1
2	6L2-15711-00-94	.CASE, starter	1	23	97395-06025	BOLT	2
3	91690-40014	.PIN, spring	1	24	92990-06600	WASHER, plate	2
4	6L2-15758-00-94	.GUIDE, rope	1	25	99530-10014	PIN, dowel	1
5	97395-06016	.BOLT	2	26	656-15748-00	PLUNGER, starter stop	1
6	92990-06600	.WASHER, plate	2	27	90501-10227	SPRING, compression	1
7	6L2-15762-00	.SEAL, rubber 2	1	28	6L2-15770-00	CABLE COMP., starter stop	1
8	689-15755-01	.HANDLE, starter	1	29	6L2-15746-00	ARM	1
9	6F5-15779-02	.COVER	1	30	90387-06M51	COLLAR	1
10	*	.WIRE (L1950)	1	31	97313-06020	BOLT	1
11	6J8-15714-00	.DRUM, sheave	1	32	92990-06100	WASHER, spring	1
12	90510-08M04	.SPRING, spiral	1	33	6L2-15747-00	LINK	1
13	677-15717-01	.SHAFT, starter	1	34	6L2-15774-00	STAY 4	1
14	90201-065F3	.WASHER, plate	1	35	90201-06M62	WASHER, plate	1
15	97313-06025	.BOLT	1	36	661-41262-02	JOINT, choke lever	2
16	95303-06700	.NUT	1	37	6L2-15772-00-94	STAY 2	1
17	676-15741-03	.PAWL, drive	1	38	97313-06020	BOLT	1
18	93430-06M02	.CIRCLIP	1	39	92990-06600	WASHER, plate	1
19	6J8-15705-00	.SPRING, drive pawl	1	40	97313-06020	BOLT	1
20	6A0-15789-00	.DAMPER	1	41	6L2-15723-00	PULLEY, starter	1
21	97395-06035	BOLT	1	42	97516-08212	BOLT, with washer	3

* Cut from 50m rolls, parts No.90890-44373, cutting length 1.95m.




Fig. 7 FUEL

Ref.No.	Parts No.	Description	Q'ty	Ref.No.	Parts No.	Description	Q'ty
1	6Y1-W2420-62-24	FUEL TANK ASSY	1	18	6Y1-24305-02	.FUEL PIPE JOINT COMP. 2	1
2	6Y1-24246-00	.GRAPHIC, side	2	19	93210-08287	..O-RING	1
3	6Y1-24257-00	.GRAPHIC	1	20	6G1-24304-02	FUEL PIPE JOINT COMP. 1	1
4	6Y1-24260-02	.FUEL METER ASSY	1	21	97395-06020	BOLT	1
5	6Y1-24268-00	.GASKET, fuel meter	1	22	92990-06600	WASHER, plate	1
6	98586-05016	.SCREW, pan head	4	23	6H4-24311-00	PIPE, fuel 1	1
7	6Y1-24329-00	.SEAL	4	24	90445-09M25	HOSE	1
8	6Y1-24610-00	.CAP ASSY	1	25	90467-08004	CLIP	4
9	6Y1-24167-00	.STRAINER	1	26	655-24560-01	FILTER ASSY	1
10	6Y1-24256-80	.GRAPHIC, fuel tank 9	1	27	6F5-24563-00	.ELEMENT, filter	1
11	6Y1-24306-51	FUEL PIPE COMP. 1	1	28	93210-37M25	.O-RING	1
# 12	90445-11M06	.HOSE (L2050)	1	29	655-24521-01	.CUP, filter	1
13	6Y1-24360-51	.PRIMER PUMP ASSY	1	30	6L2-24566-00	BRACKET, filter	1
# 14	90445-11M05	.HOSE (L850)	1	31	97013-06012	BOLT	1
15	650-24351-51	.BAND 1	4	32	95380-08600	NUT	1
16	6G1-24305-01	.FUEL PIPE JOINT COMP. 2	1	33	92990-08100	WASHER, spring	1
17	93210-08287	..O-RING	1	34	656-W2810-02	TOOL KIT	1

Also available in 30m rolls. (Parts No. 90890-56878)

Fig. 8 TOP COWLING

Ref.No.	Parts No.	Description	Q'ty	Ref.No.	Parts No.	Description	Q'ty
1	6L2-42610-V4-EJ	TOP COWLING ASSY (25NO Model)	1 UR	8	92990-06600	.WASHER, plate	4
	6L3-42610-V4-EJ	TOP COWLING ASSY (2000 Model)	1 UR	9	6L2-W0070-E1	.GRAPHIC SET	1
2	6L2-42615-00	.SEAL	1	10	6L2-42677-10	.GRAPHIC, front (25NO Model)	1 UR
3	661-42651-71	.HOOK	1		6L3-42677-10	.GRAPHIC, front (2000 Model)	1 UR
4	6L2-42647-00	.HOLDER, clamp band	1	11	6L2-42678-10	.GRAPHIC, rear (25NO Model)	1 UR
5	90266-04M00	.RIVET	2		6L3-42678-10	.GRAPHIC, rear (2000 Model)	1 UR
6	6L2-42613-00-EJ	.MOLDING, air duct	1	12	90266-04M04	.RIVET	2
7	97395-06016	.BOLT	4				




Fig. 9 BOTTOM COWLING

Ref.No.	Parts No.	Description	Q'ty	Ref.No.	Parts No.	Description	Q'ty
1	6L2-42711-02-EJ	COWLING, bottom	1	15	6L2-42748-01	GROMMET	1
2	6L2-42815-00-EJ	LEVER, clamp	1	16	6L2-42716-00	RUBBER, seal 1	1
3	90386-12M45	BUSH	2	17	90338-05M03	PLUG	2
4	6L2-42816-00	LEVER, clamp	1	18	90480-15M31	GROMMET	4
5	90206-12052	WASHER, wave	1	19	90387-06M52	COLLAR	4
6	97890-06035	SCREW, pan head	1	20	90105-06M15	BOLT, washer based	4
7	95780-06300	NUT, flange	1	21	6L2-42738-01	PLATE, fitting	2
8	6L2-42719-A0	PANEL, front lower	1	22	6H3-44391-01	NIPPLE, hose	1
9	689-41273-00	GROMMET	1	23	689-82575-03	ENGINE STOP SWITCH ASSY	1
10	6J8-41274-00	GROMMET 2	1	24	682-82556-00	.STOPPER	1
11	6L2-42725-00	GROMMET (20DMO/25NMO)	1	25	682-84381-00	2P CONCENT	1 UR
12	661-42724-00	GROMMET	1	26	6J8-85410-00	EMERGENCY SIGNAL LIGHT ASSY	1
13	6L2-42726-01	GROMMET	1 UR	27	6E5-82588-00	PLATE (20DERO/25NERO)	2
14	6L2-42726-10	GROMMET (20DERO/25NERO)	1 UR	28	95895-06016	BOLT, flange (20DERO/25NERO)	2
14	661-42727-00	GROMMET	1				






Fig. 10 BRACKET 1

Ref.No.	Parts No.	Description	Q'ty	Ref.No.	Parts No.	Description	Q'ty
1	6L2-43111-02-EJ	BRACKET, clamp	1	29	93210-29375	O-RING	1
2	6L2-43112-03-EJ	BRACKET, clamp	1	30	90386-30M60	BUSH	1
3	6E5-82148-00	WIRE, lead 4	1	31	6L2-44512-00-EJ	COVER, upper mount	1
4	97895-06008	SCREW, pan head	2	32	6L2-45114-A1	GASKET, upper casing	1
5	616-43118-00-EJ	HANDLE, transom clamp	2	33	6L2-44365-00	DAMPER, water seal	1
6	90243-04M00	PIN	2	34	97395-06020	BOLT	3
7	6L2-43116-00	SCREW	2	35	92990-06600	WASHER, plate	3
8	648-43114-01	PAD, transom clamp	2	36	6L2-44514-00	MOUNT DAMPER, upper side	1
9	6J8-43131-01	BOLT, clamp bracket	1	37	97515-06250	BOLT, with washer	2
10	90386-22M67	BUSH	2	38	97515-06240	BOLT, with washer	1
11	90201-22428	WASHER, plate	2	39	90101-08M09	BOLT	2
12	90185-22043	NUT, self-locking	2	40	90201-08M01	WASHER, plate	4
13	665-43145-00	CAP, clamp bracket	2	41	6L2-44526-00	PLATE	1
14	6J8-43113-01	PLATE, clamp bracket	1	42	95780-08300	NUT, flange	2
15	6L2-43311-03-EJ	BRACKET, swivel	1	43	6L2-44551-00-EJ	HOUSING, lower mount rubber	1
16	93700-06M03	NIPPLE, grease	1	44	6L2-44552-00-EJ	HOUSING, lower mount rubber	1
17	663-45119-00	CAP, grease nipple	1	45	93604-10M03	PIN, dowel	2
18	6H4-42528-00	PLATE, friction	1	46	97395-08085	BOLT	2
19	689-43373-01	SEAL, damper	1	47	92990-08600	WASHER, plate	2
20	90105-06M18	BOLT, washer based	1	48	6L2-44555-00	MOUNT DAMPER, lower side	2
21	6L2-42121-00-EJ	BRACKET	1	49	6L2-44557-00	MOUNT DAMPER, lower front	1
22	6E0-44191-11	INDICATOR, shift	1	50	6L2-44553-00-EJ	COVER, lower mount	1
23	90116-10M28	BOLT, stud	2	51	97395-08045	BOLT	2
24	92990-10600	WASHER, plate	2	52	92990-08600	WASHER, plate	2
25	90185-10051	NUT, self-locking	2	53	97395-08070	BOLT	2
26	6L2-42510-00-EJ	STEERING BRACKET ASSY	1	54	95380-08600	NUT	4
27	90386-30M75	BUSH	2	55	92990-08600	WASHER, plate	4
28	90201-30M00	WASHER, plate	1				





Fig. 11 BRACKET 2

Ref.No.	Parts No.	Description	Q'ty	Ref.No.	Parts No.	Description	Q'ty
1	6L2-43165-00	PLATE, tilt lock	1	18	6L2-43641-00	LEVER, tilt	1
2	97515-06210	BOLT, with washer	4	19	6L2-43659-00	SHAFT, reverse lock	1
3	6L2-43160-00	TILT ROD ASSY	1	20	99080-05600	CIRCLIP	1
4	6L2-43630-01	TILT LEVER ASSY	1	21	6L2-43617-00	ROD, tilt lock	1
5	682-43318-01	COVER	1	22	6L2-43613-00	ARM, tilt lock	1
6	90386-08032	BUSH	3	23	99080-05600	CIRCLIP	1
7	6L2-43682-01	LEVER, shallow water drive 2	1	24	6L2-43624-00	PLATE, tilt rock	1
8	97395-05010	BOLT	1	25	6L2-43336-00	PIN	1
9	92990-05600	WASHER, plate	1	26	6J8-43611-01	SHAFT, tilt lock	1
10	6L2-43191-01	SHAFT, stopper	1	27	99080-05600	CIRCLIP	1
11	99080-05600	CIRCLIP	1	28	6L2-43614-00	PLATE, tilt lock	1
12	90°06-20M27	SPRING, tension	1	29	90508-12M28	SPRING, torsion	1
13	6L2-43270-02	RECEIVER ASSY	1	30	90508-12M29	SPRING, torsion	1
14	6L2-43631-00	LEVER, tilt	1	31	6L2-43615-00	PLATE, tilt lock	1
15	6L2-43188-00	SPRING	1	32	90506-23M11	SPRING, tension	1
16	6L2-43633-10	COVER, tilt lever	1	33	6L2-43657-00	SPRING, lock	1
17	6L2-43611-00	SHAFT, tilt lock	1	34	6L2-43676-00	HOOK	1



HANDLE STEERING
ASS'Y





Fig. 12 STEERING

Ref.No.	Parts No.	Description	Q'ty	Ref.No.	Parts No.	Description	Q'ty
1	6L2-W0084-00-EJ	HANDLE STEERING ASSY (Ref. No. 2 to 24)	1	20	6G1-42138-01	LEVER, throttle	1
2	6G1-42111-03-EJ	HANDLE, steering	1	21	6E0-42159-02	STAY	1
3	90206-35M20	WASHER, wave	1	22	97395-05012	BOLT	1
4	90202-35M24	WASHER, plate	1	23	6L2-26301-00	THROTTLE CABLE ASSY	2
5	90386-34M40	BUSH	1	24	6L2-44111-00-94	HANDLE, gear shift	1
6	90386-43M79	BUSH	1	25	90386-15M73	BUSH	2
7	6G1-42131-01	COVER, handle steering	1	26	90206-15M18	WASHER, wave	1
8	97395-06016	BOLT	1	27	90202-15M37	WASHER, plate	1
9	6G1-42125-01	BOLT, friction adjusting	1	28	90386-12M72	BUSH	1
10	6G1-42126-00	FRICTION, steering handle grip	1	29	6L2-44125-00	LEVER, shift rod	1
11	91490-16010	PIN, cotter	1	30	97395-06020	BOLT	1
12	664-42119-00	GRIP, steering handle	1	31	92990-06600	WASHER, plate	1
13	6G1-42177-00	RUBBER, handle	1	32	90202-06009	WASHER, plate	2
14	6L2-42137-00	INDICATOR, throttle	1	33	91490-20010	PIN, cotter	1
15	90269-02M09	RIVET	1	34	6L2-44124-00	LINK, shift rod	1
16	90501-23215	SPRING, compression	1	35	6L2-26363-00	END, cable	1
17	92990-10600	WASHER, plate	1	36	95330-06700	NUT	1
18	90149-05M13	SCREW	1	37	90202-05088	WASHER, plate	2
19	90386-08032	BUSH	1	38	90202-05M38	WASHER, plate	1
				39	90468-05M03	CLIP	1

Fig. 13 CONTROL




Ref.No.	Parts No.	Description	Q'ty	Ref.No.	Parts No.	Description	Q'ty
1	6L2-14497-00	STAY, throttle wire	1	22	6L2-44123-00	ARM, shift rod	1
2	97395-06020	BOLT	1	23	91690-30318	PIN, spring	1
3	95380-06700	NUT	1	24	6L2-44143-00	ROD, shift	1
4	6L2-41213-00	CAM, accel.	1	25	90170-06015	NUT	1
5	6L2-41283-00	LEVER, free accel.	1	26	6L2-14368-00	DIAPHRAGM ASSY 1	1
6	6L2-41631-00	LEVER, magneto control	1	27	97313-06008	BOLT	2
7	6J8-42167-00	SPRING 1	1	28	6L2-44122-00	BUSHING, shift rod lever	1
8	6L2-42167-00	SPRING 1	1	29	91690-30318	PIN, spring	1
9	97395-06075	BOLT	1	30	6L2-42192-00	ROD 2	1
10	92990-06600	WASHER, plate	1	31	90202-05086	WASHER, plate	2
11	90387-06M18	COLLAR	1	32	91490-20010	PIN, cotter	2
12	689-42169-01	JOINT	1	33	6L2-44141-01	LINK, shift rod	1
13	6H1-41237-00	JOINT, link	1	34	90109-06M28	BOLT	1
14	95380-05600	NUT	1	35	6L2-41212-00	ARM, accel.	1
15	6L2-44121-00	LEVER, shift rod	1	36	6L2-44141-10-94	LINK, shift rod	1
16	6G1-41662-01-94	BRACKET	2	37	97313-05016	BOLT	1
17	97313-06020	BOLT	2	38	92990-05600	WASHER, plate	1
18	92990-06600	WASHER, plate	2	39	6L2-41237-00	JOINT, link	1
19	6J8-44116-00	SPRING	1	40	6L2-41238-00	JOINT, link	1
20	97395-06012	BOLT	1	41	95380-05700	NUT	1
21	92990-06600	WASHER, plate	1				

C1

Fig. 14 UPPER CASING

Ref.No.	Parts No.	Description	Q'ty	Ref.No.	Parts No.	Description	Q'ty
1	6L2-45111-01-EJ	CASING, upper (Short)	1 UR	9	92990-08600	WASHER, plate	6
	6L2-45111-11-EJ	CASING, upper (long)	1 UR	10	6L2-41131-00-5B	MANIFOLD, ext. 1 (25N Model)	1 UR
2	6L2-45151-01-EJ	COVER, upper casing	1		6L3-41131-00-9M	MANIFOLD, ext. 1 (20D Model)	1 UR
3	6L2-45115-00	GASKET, upper casing	1	11	6L2-41134-00	GASKET, exhaust manifold	1
4	90159-06M11	SCREW, with washer	2	12	6L2-45123-00	GASKET, muffler	1
5	93604-10M03	PIN, dowel	2	13	6L2-41133-A1	GASKET, exhaust manifold 1	1
6	6L2-82127-00	WIRE, lead 2	1	14	97395-06020	BOLT	4
7	90157-06M06	SCREW, pan head	1	15	92990-06600	WASHER, plate	4
8	97395-08030	BOLT	6				








Fig. 15 LOWER CASING. DRIVE 1

Ref.No.	Parts No.	Description	Q'ty	Ref.No.	Parts No.	Description	Q'ty
1	6L2-45300-02-EJ	LOWER UNIT ASSY (Short) (Ref. No. 2 to 51)	1 UR	26	6L2-45510-10	DRIVE SHAFT ASSY (Long)	1 UR
	6L2-45300-12-EJ	LOWER UNIT ASSY (Long) (Ref. No. 2 to 51)	1 UR	27	90280-03024	KEY, woodruff	1
2	6L2-45311-01-EJ	CASING, lower	1	28	6L2-45551-01	PINION	1
3	93332-00005	BEARING	1	29	90179-10M14	NUT	1
4	6L2-45567-00-10	SHIM (T:1.0MM)	1 UR	30	93341-320U0	BEARING	1
	6L2-45567-00-11	SHIM (T:1.1MM)	1 UR	31	6L2-45587-00-15	SHIM (T:1.5MM)	1 UR
	6L2-45567-00-12	SHIM (T:1.2MM)	1 UR		6L2-45587-00-16	SHIM (T:1.6MM)	1 UR
	6L2-45567-00-14	SHIM (T:1.4MM)	1 UR	32	6L2-45560-00	GEAR	1
5	93315-220V9	BEARING, cylindrical	1	33	6L2-45571-00	GEAR	1
6	6L2-45536-00	SLEEVE, drive shaft	1	34	90201-20417	WASHER, plate	1
7	90340-08M04	PLUG, straight screw	2	35	6L2-45577-00-10	SHIM (T:1.0MM)	1 UR
8	90430-08020	GASKET	2		6L2-45577-00-11	SHIM (T:1.1MM)	1 UR
9	6L2-44311-00	HOUSING, water pump	1		6L2-45577-00-12	SHIM (T:1.2MM)	1 UR
10	93210-45161	O-RING	1		6L2-45577-00-13	SHIM (T:1.3MM)	1 UR
11	6L2-44322-00	INSERT, cartridge	1	36	6L2-45611-00	SHAFT, propeller	1
12	6L2-44323-00	OUTER PLATE, cartridge	1	37	90501-10065	SPRING, compression	1
13	6L2-44352-00	IMPELLER	1	38	6L2-45631-00	CLUTCH, dog	1
14	97395-06040	BOLT	4	39	90250-05010	PIN, straight	1
15	92990-06600	WASHER, plate	4	40	648-45633-00	RING, cross pin	1
16	6L2-44328-00	PLATE	2	41	648-45635-00	PLUNGER, shift	1
17	6L2-45331-00-5B	HOUSING, bearing	1	42	6L2-45361-02-EJ	CAP, lower casing	1
18	93315-22004	BEARING, cylindrical	1	43	93306-00609	BEARING	1
19	93101-20048	OIL SEAL	2	44	93210-60MA3	O-RING	1
20	6L2-44147-00	BOOT, shift rod	1	45	93315-22004	BEARING, cylindrical	1
21	93604-10M03	PIN, dowel	2	46	93101-20M07	OIL SEAL	2
22	6L2-45315-A0	PACKING, lower casing	1	47	97395-06020	BOLT	2
23	97395-06020	BOLT	2	48	92990-06600	WASHER, plate	2
24	92990-06600	WASHER, plate	2	49	6L2-44150-00	SHIFT CAM ASSY (Short)	1 UR
25	6L2-45375-00	DAMPER, seal	1		6L2-44150-10	SHIFT CAM ASSY (Long)	1 UR
26	6L2-45510-00	DRIVE SHAFT ASSY (Short)	1 UR	50	95380-06600	NUT	1
				51	93210-60M99	O-RING	1

Fig. 16 LOWER CASING. DRIVE 2

Ref.No.	Parts No.	Description	Q'ty	Ref.No.	Parts No.	Description	Q'ty
1	6L2-44368-00	RUBBER, water seal 4	1	16	92990-14200	WASHER, plain	1
2	6L2-44361-00	TUBE, water (Short)	1 UR	17	90171-14013	NUT, castle	1
	6L2-44361-10	TUBE, water (Long)	1 UR	18	91490-30030	PIN, cotter	1
3	6L2-44366-00	DAMPER, water seal	1	19	664-45941-01-EL	PROPELLER (3X9-7/8"X9"-F)	1 UR
4	93604-10M03	PIN, dowel	2		664-45943-01-EL	PROPELLER (3X9-7/8"X8"-F)	1 UR
5	90105-10M12	BOLT, washer based	4		664-45945-00-EL	PROPELLER (3X9-7/8"X10-1/2"-F)	1 UR
6	92990-10600	WASHER, plate	4		664-45947-01-EL	PROPELLER (3X9-7/8"X11-1/4"-F)	1 UR
7	664-45371-01	TAB-TRIM	1		664-45949-02-EL	PROPELLER (3X9-7/8"X13"-F)	1 UR
8	90105-08M02	BOLT, washer based	1		664-45952-00-EL	PROPELLER (3X9-7/8"X14"-F)	1 UR
9	6L2-44367-00	DAMPER, water seal	1			STAINLESS STEEL PROPELLER	
10	6L2-45214-00	COVER, water inlet	1		664-45970-00-98	PROPELLER (3X9-1/8"X13"-F)	1 UR
11	6L2-45215-00	COVER, water inlet	1		664-45972-00-98	PROPELLER (3X9-1/8"X12"-F)	1 UR
12	98680-05030	SCREW, oval head	2			DUAL THRUST PROPELLER	
13	90185-05002	NUT, self-locking	2	20	6J8-W4591-00-EL	PROPELLER (3X10-5/8"X8-1/4"-F)	1 UR
14	6L2-45987-01	SPACER	1	21	6J8-45986-10-98	.RING, deflector	1
15	689-45997-00	SPACER	1				








Fig. 17 MAGNETO

Ref.No.	Parts No.	Description	Q'ty	Ref.No.	Parts No.	Description	Q'ty
1	6L2-85550-A0	ROTOR ASSY	1	14	663-85518-00	JOINT, ball	1
2	6L2-85560-F1	BASE ASSY	1	15	90280-05013	KEY, woodruff	1
3	6L2-85520-F0	.COIL, charge	1	16	90179-12M04	NUT	1
4	6L2-85592-F1	.PULSER COIL ASSY	1	17	90201-13M42	WASHER, plate	1
5	6L2-85595-F1	.COIL, pulser	1	18	6G1-41611-00	RETAINER, magneto base	1
6	6L2-85533-F0	.COIL, lighting	1	19	695-41613-00	PLATE, base friction	1
7	98501-05020	.SCREW, pan head	2	20	97013-06012	BOLT	3
8	98501-05010	.SCREW, pan head	4	21	92990-06600	WASHER, plate	3
9	98503-05025	.SCREW, pan head	2	22	6G1-41612-00	RETAINER, magneto base	1
10	92990-05100	.WASHER, spring	8	23	97985-05210	SCREW, with washer	3
11	6G1-85548-70	.HOLDER	1	24	6L2-81332-00	PLATE, timing	1
12	98580-04008	.SCREW, pan head	1	25	97985-05210	SCREW, with washer	1
13	92902-04100	.WASHER, spring	1	26	6L2-82599-00	COVER, connector	1




Fig. 18 ELECTRICAL 1

Ref.No.	Parts No.	Description	Q'ty	Ref.No.	Parts No.	Description	Q'ty
1	6L2-85540-10	C.D.I. UNIT ASSY	1	13	90480-25161	GROMMET	1
2	92990-06200	WASHER, plain	2	14	90465-08028	CLAMP	1
3	90159-06M15	SCREW, with washer	2	15	97395-06012	BOLT	1
4	6L2-85542-01-94	BRACKET	1	16	92995-06100	WASHER, spring	1
5	97313-06030	BOLT	3	17	6G1-82370-20	PLUG CAP ASSY	2
6	92990-06600	WASHER, plate	3	18	97395-06012	BOLT	2
7	90101-06M16	BOLT	2	19	92995-06100	WASHER, spring	2
8	92990-06600	WASHER, plate	2	20	689-82560-00	THERMO SWITCH ASSY	1
9	6L2-85570-N0	IGNITION COIL ASSY	2	21	6J8-81960-00	RECTIFIER & REGULATOR ASSY	1
10	97313-06030	BOLT	4	22	97395-06016	BOLT	1
11	92990-06100	WASHER, spring	4	23	92990-06600	WASHER, plate	1
12	90465-18147	CLAMP	1	24	6J8-82105-10	WIRE, harness	1





Fig. 19 ALTERNATE 1 (20DE(R)0/25NE(R)0 MODEL)

Ref.No.	Parts No.	Description	Q'ty	Ref.No.	Parts No.	Description	Q'ty
1	6L2-81800-11	STARTING MOTOR ASSY	1	10	6L2-81812-10	..BRUSH 2	1
2	6L2-81850-11	..ARMATURE ASSY	1	11	682-81832-10	..CLUTCH, over run	1
3	682-81809-10	..WASHER KIT	1	12	682-81830-10	..FRONT BRACKET ASSY	1
4	6L2-81833-10	..RING, stop	1	13	682-81826-10	..BOLT	2
5	682-81810-11	..STATOR ASSY	1	14	682-81847-10	..O-RING	2
6	6L2-81820-10	..REAR BRACKET ASSY	1	15	682-81834-10	..RING	1
7	6L2-81840-10	..BRUSH HOLDER ASSY	1	16	97013-08025	BOLT	2
8	682-81813-10	..SPRING, brush	2	17	92990-08600	WASHER, plate	2
9	6L2-81811-10	..BRUSH 1	1				

Fig. 20 ALTERNATE 2 (20DE(R)0/25NE(R)0 MODEL)

Ref.No.	Parts No.	Description	Q'ty	Ref.No.	Parts No.	Description	Q'ty
1	6G1-81941-10	STARTER RELAY ASSY	1	16	682-86117-00	HOOK, wire pull	1
2	6G1-81952-00	HOLDER, relay	1	17	6L2-86115-00	HOLDER, solenoid	1
3	6L2-81945-00	PLATE, switch fitting	1	18	98580-05008	SCREW, pan head	2
4	97013-06012	BOLT	1	19	92990-05600	WASHER, plate	2
5	92990-06100	WASHER, spring	1	20	90480-10155	GROMMET	1
6	6G1-82105-00	WIRE HARNESS	1	21	98580-04008	SCREW, pan head	4
7	6G1-82117-00	WIRE, lead	1	22	92990-04200	WASHER, plain	4
8	6G1-82119-00	COVER, lead wire	1	23	6L2-86112-00	STAY, solenoid	1
9	6L2-42725-50	GROMMET	1	24	97013-05012	BOLT	2
10	6G1-81970-61	RECTIFIER ASSY	1	25	92990-06100	WASHER, spring	2
11	6G1-82151-00	FUSE	1	26	93210-03261	O-RING	1
12	98503-05025	SCREW, pan head	1	27	97013-06012	BOLT	1
13	92990-05600	WASHER, plate	1	28	92990-06100	WASHER, spring	1
14	6G5-82152-00	HOLDER, fuse	1	29	6L2-82590-00	WIRE HARNESS ASSY	1
15	6L2-86111-00	COIL, solenoid	1	30	6K3-83557-00	TUBE	1



D1







Fig. 21 REMOTE CONTROL

Ref.No.	Parts No.	Description	Q'ty	Ref.No.	Parts No.	Description	Q'ty
* 1	703-48230-12	REMOTE CONTROL ASSY (Single)	1 UR	3	701-48320-60	CABLE, remote control (L:16f)	2 UR
* 2	703-48220-12	REMOTE CONTROL ASSY (Twin Lever)	1 UR		701-48320-80	CABLE, remote control (L:17f)	2 UR
3	701-48310-40	CABLE, remote control (L:8f)	2 UR		701-48320-90	CABLE, remote control (L:18f)	2 UR
	701-48310-60	CABLE, remote control (L:9f)	2 UR		701-48320-40	CABLE, remote control (L:19f)	2 UR
	701-48310-80	CABLE, remote control (L:10f)	2 UR		701-48320-70	CABLE, remote control (L:20f)	2 UR
	701-48310-90	CABLE, remote control (L:11f)	2 UR		701-48350-00	CABLE, remote control (L:21f)	2 UR
	701-48320-00	CABLE, remote control (L:12f)	2 UR		701-48350-10	CABLE, remote control (L:22f)	2 UR
	701-48320-20	CABLE, remote control (L:13f)	2 UR		701-48350-20	CABLE, remote control (L:23f)	2 UR
	701-48320-30	CABLE, remote control (L:14f)	2 UR	4	703-48290-01	TWIN ATTACHMENT	1
	701-48320-50	CABLE, remote control (L:15f)	2 UR				

* See Fig. 24 for detail service parts.

Fig. 22 REMO-CON ATTACHMENT



Ref.No.	Parts No.	Description	Q'ty	Ref.No.	Parts No.	Description	Q'ty
1	6L2-48501-11	REMOTE CONT. ATTACHMENT ASSY.	1	12	682-48538-50	.CLAMP, cable 1	2
2	6L2-48544-01	.LEVER, shiftcontrol	1	13	91690-30012	.PIN, spring	2
3	6L2-48534-01	.THROTTLE LEVER, control	1	14	90105-06M23	.BOLT, washer based	2
4	90386-10009	.BUSH	4	15	6G8-26363-00	.END, cable	2
5	95780-08300	.NUT, flange	4	16	6G8-26364-00	.END, cable 2	2
6	6L2-42154-01	.LEVER, throttle control	2	17	6L2-48511-00	HOOK, steering	1 UR
7	6L2-42191-01	.ROD 1	1	18	90185-10051	NUT, self-locking	1
8	6L2-42192-20	.ROD 2	1	19	92990-10600	WASHER, plate	1
9	90202-05088	.WASHER, plate	2	20	97395-10040	BOLT	1
10	91490-20010	.PIN, cotter	2	21	6J8-48511-00-EJ	HOOK, steering	1 UR
11	6L2-48531-00	.BRACKET, remote control 1	1				

Fig. 23 STEERING GUIDE ATTACHMENT

Ref.No.	Parts No.	Description	Q'ty	Ref.No.	Parts No.	Description	Q'ty
1	689-61350-02	STEERING GUIDE ATTACHMENT KIT	1	12	90201-10M76	.WASHER, plate	2
2	689-61351-01	.ROD, steering link	1	13	90170-09M05	.NUT	2
3	90201-10M20	.WASHER, plate	2	14	90101-09M70	.BOLT	2
4	90185-09M01	.NUT, self-locking	2	15	90185-09M01	.NUT, self-locking	2
5	90170-09M03	.NUT	1	16	6E5-61303-00	.STEERING EYE COMP.	2
6	90387-10M42	.COLLAR	1	17	6E5-61315-00	.TIE BAR	1
7	90101-09M66	.BOLT	1	18	95380-14700	.NUT	2
8	90201-10M63	.WASHER, plate	1	19	6E5-61313-00	.ADJUSTER	1
9	6E5-43145-00	.CAP, clamp bracket	1	20	688-61311-11	.TIE BAR	1
10	93210-16275	.O-RING	1	21	90170-14M06	.NUT	1
11	688-61301-01	TWIN KIT (L:430-630MM)	1				






Fig. 24 REMOTE CONTROL ASSY 1




Ref.No.	Parts No.	Description	Q'ty	Ref.No.	Parts No.	Description	Q'ty
1	703-48230-12	REMOTE CONTROL ASSY (Single)	1 UR	31	703-48223-00	.LOCK, neutral	1
	703-48220-12	REMOTE CONTROL ASSY (Twin Lever)	1 UR	32	703-48225-00	.COVER	1
2	703-48261-10	.ARM, throttle	1	33	703-48219-00	.COVER, lead	1
3	703-48153-00	.SHAFT, free accel.	1	34	98780-05012	.SCREW, flat head	2
4	703-48235-00	.BUSHING	1	35	98780-05016	.SCREW, flat head	7
5	703-48273-00	.BUSHING	2	36	97395-08030	.BOLT	1
6	703-48197-00	.WASHER, wave	1	37	92990-08600	.WASHER, plate	1
7	703-48268-00	.SPACER	1	38	98580-04010	.SCREW, pan head	3
8	703-48263-00	.BUSHING	1	39	98580-04006	.SCREW, pan head	2
9	703-48264-00	.THROTTLE, friction	1	40	98580-05010	.SCREW, pan head	1
10	95380-05600	.NUT	1	41	98580-03015	.SCREW, pan head	2
11	97380-05025	.BOLT	1	42	703-48291-10	.SCREW	3
12	703-48265-00	.SHAFT, friction	1	43	95380-06600	.NUT	3
13	93430-06024	.CIRCLIP	3	44	703-48293-10	.SPACER, remote control (Single)	1 UR
14	703-48245-00	.PLATE, lock	1		703-48293-00	.SPACER, remote control (Twin)	3 UR
15	703-48252-00	.ROLLER, cam	1	45	701-48287-00	.WASHER	3
16	701-48248-00	.ROLLER, free accel.	1	46	703-48215-00	.GRAPHIC	1
17	703-48198-00	.WASHER, wave	1	47	702-48217-00	.MARK	1
18	703-48243-00	.BUSHING	1	48	703-82510-10	.MAIN SWITCH ASSY	1
19	703-48236-00	.BUSHING 1	2	49	703-82574-00	.SWITCH, choke	1
20	703-48189-00	.RETAINER	1	50	703-82531-00	.WIRE, lead	1
21	703-48234-00	.ROLLER, detent	1	51	688-82575-01	.ENGINE STOP SWITCH ASSY	1
22	703-48345-01	.CABLE END, remote control 2	2	52	682-82556-00	.STOPPER	1
23	703-48358-00	.ANCHOR, cable	1	53	688-82586-21	.EXTENSION, wire harness (L:5M 7P)	1
24	703-48244-00	.SPRING, free accel.	1	54	703-82540-00	.NEUTRAL SWITCH ASSY	1
25	703-48238-00	.SPRING, detent	5	55	703-83383-01	.BUZZER	1
26	703-48246-00	.SPACER	1	56	703-48284-00	.GROMMET	1
27	703-48227-00	.SPRING, neutral lock	1	57	90465-13169	.CLAMP	2
28	703-82594-00	.CLAMP	1	58	80L-26397-00	.BAND	1
29	703-48226-00	.PLATE, stopper	1	59	703-48224-00	.COVER, control lever	1
30	703-48222-00	.GRIP, control lever (Single)	1 UR	60	703-48221-00	.LEVER, control	1
	703-48222-10	.GRIP, control lever (Twin)	1 UR				

FWD

D5

Fig. 25 OPTIONAL PARTS 1

Ref.No.	Parts No.	Description	Q'ty	Ref.No.	Parts No.	Description	Q'ty
1	689-82550-01	ENGINE STOP SWITCH ASSY	1	8	689-42725-40	GROMMET	1
2	689-82575-12	ENGINE STOP SWITCH ASSY	1	9	6G1-81970-61	RECTIFIER ASSY	1
3	682-82556-00	.STOPPER	1	10	6G1-82151-00	.FUSE	1
4	689-82553-20	EXTENSION, wire lead	1	11	98503-05025	SCREW, pan head	1
5	689-42725-40	GROMMET	1	12	92990-05600	WASHER, plate	1
6	689-82550-11	ENGINE STOP SWITCH ASSY	1	13	663-81910-10	VOLTAGE REGULATOR ASSY	1
7	689-82553-20	EXTENSION, wire lead	1				






Fig. 26 OPTIONAL PARTS 2

Ref.No.	Parts No.	Description	Q'ty	Ref.No.	Parts No.	Description	Q'ty
1	689-82570-15	PANEL SWITCH ASSY	1	11	95380-05600	NUT	4
2	689-82510-00	.MAIN SWITCH ASSY	1	12	92990-05100	WASHER, spring	4
3	703-82574-00	.SWITCH, choke	1	13	92990-05600	WASHER, plate	4
4	688-82575-01	.ENGINE STOP SWITCH ASSY	1	14	688-82586-50	EXTENSION, wireharness (L:5m 7P)	1
5	682-82556-00	..STOPPER	1	15	688-82586-11	EXTENSION, wireharness (L:2m 7P)	1 UR
6	689-82571-02	.PANEL, switch	1		688-82586-31	EXTENSION, wireharness (L:3m 7P)	1 UR
7	663-82581-01	.STAY, cord clamp	1	16	6H3-82540-00	NEUTRAL SWITCH ASSY	1
8	98303-04008	.SCREW, cylinder head	1	17	6L2-82554-00	STAY, neutral switch	1
9	92901-04100	.WASHER, spring	1	18	97013-06012	BOLT	1
10	90149-05M05	SCREW	4	19	92990-06100	WASHER, spring	1





Fig. 27 OPTIONAL PARTS 3

Ref.No.	Parts No.	Description	Q'ty	Ref.No.	Parts No.	Description	Q'ty
1	6Y5-W0080-12	TACHOMETER KIT	1	19	97780-40116	.SCREW, tapping	5
2	6Y5-83540-12	.TACHOMETER ASSY	1	20	6Y5-W0088-31	HOUR METER KIT	1
3	688-83516-00	..BULB	1	21	6Y5-83504-01	.HOUR METER ASSY	1
4	6Y5-83536-10	..SOCKET, meter	1	22	688-83664-00	..DAMPER	1
5	6Y5-83523-00	..DAMPER	1	23	6Y5-83577-00	..PLATE, fitting	1
6	6Y5-83514-00	..PLATE, fitting	1	24	6Y5-83518-00	..BULB, meter	1
7	6Y5-83553-00	.WIRE, lead	1	25	6Y5-83536-00	..SOCKET, meter	1
8	1E6-82151-00	..FUSE (10A)	1	26	663-83553-A0	.WIRE, lead	1
9	6Y5-W0081-40	SPEEDOMETER KIT	1	27	663-83553-Y0	.WIRE, lead	1
10	6Y5-83510-30	.SPEEDOMETER ASSY	1	28	6Y5-W0088-20	FUEL METER KIT	1
11	688-83516-00	..BULB	1	29	6Y5-85750-00	.FUEL METER ASSY	1
12	6Y5-83536-10	..SOCKET, meter	1	30	6Y5-83518-00	..BULB, meter	1
13	6Y5-83523-00	..DAMPER	1	31	6Y5-83536-00	..SOCKET, meter	1
14	6Y5-83514-00	..PLATE, fitting	1	32	688-83664-00	..DAMPER	1
15	688-83557-00	..TUBE	1	33	6Y5-83544-00	..PLATE, fitting	1
16	90465-11M10	..CLAMP	2	34	688-85752-01	.SENDER UNIT ASSY, fuel meter	1
17	688-83556-01	.SENDER	1	35	663-83553-Y0	.WIRE, lead	1
18	90601-31402	.NYLON CLIP 1	5	36	663-83553-A0	.WIRE, lead	1













Fig. 28 OPTIONAL PARTS 4



Ref.No.	Parts No.	Description	Q'ty	Ref.No.	Parts No.	Description	Q'ty
1	688-83383-11	BUZZER	1	11	92990-06600	.WASHER, plate	2
2	97780-60516	SCREW, tapping	1	12	663-82521-09	.WIRE, lead	1
3	92990-05600	WASHER, plate	1	13	688-82520-00	LIGHT SWITCH ASSY	1
4	688-83373-10	LEAD, horn	1	14	688-82526-00	SWITCH, lamp	1
5	688-W0088-40	PILOT LAMP KIT	1	15	6Y5-82149-00	WIRE, lead (BLUE)	1
6	663-84301-01	.PILOT LIGHT ASSY 1	1	16	6Y5-82117-00	WIRE, lead (BLACK)	1
7	663-84309-00	.PLATE, set	1	17	6Y5-82521-00	WIRE, lead (YELLOW)	1
8	95428-31316	.SCREW, wood	4	18	6Y5-83553-00	WIRE, lead	1
9	697-81901-60	.CHARGE WARNING UNIT ASSY	1	19	1E6-82151-00	.FUSE (10A)	1
10	97780-60120	.SCREW, tapping	2				

Fig. 29 REPAIR KIT 1

Ref.No.	Parts No.	Description	Q'ty	Ref.No.	Parts No.	Description	Q'ty
1	6L2-W0001-02	POWER HEAD GASKET KIT	1	15	93210-37M25	.O-RING	1
2	93102-25142	.OIL SEAL	1	16	6L2-45113-A1	.GASKET, upper casing	1
3	93101-13M37	.OIL SEAL	1	17	6L2-41133-A1	.GASKET, exhaust manifold 1	1
4	93210-56M80	.O-RING	1	18	6L2-W0093-00	CARBURETOR REPAIR KIT	1
5	6L2-11181-A1	.GASKET, cylinder head 1	1	19	6L2-14198-00	.GASKET	2
6	6L2-11193-A1	.GASKET, head cover 1	1	20	6L2-14384-00	.GASKET, float chamber	2
7	6J8-12414-A0	.GASKET, cover	1	21	6L2-14385-00	.FLOAT	2
8	6L2-41114-A1	.GASKET, exhaust outer cover	1	22	6E5-14386-01	.PIN, float	2
9	6L2-41112-A1	.GASKET, exhaust inner cover	1	23	6L2-14392-00	.VALVE, needle	2
10	93102-26M27	.OIL SEAL	1	24	6L2-14399-00	.GASKET	2
11	93210-42159	.O-RING	1	25	98580-04012	.SCREW, pan head	2
12	6L2-13621-00	.GASKET, valve seat	1	26	92903-04100	.WASHER, spring	2
13	6L2-14384-00	.GASKET, float chamber	2	27	6L2-14398-00	.GASKET	2
14	6L2-14198-00	.GASKET	2				






Fig. 30 REPAIR KIT 2

Ref.No.	Parts No.	Description	Q'ty	Ref.No.	Parts No.	Description	Q'ty
1	6L2-W0001-23	LOWER UNIT GASKET KIT	1	10	93210-60M99	.O-RING	1
2	6L2-41134-00	.GASKET, exhaust manifold	1	11	6L2-W0078-00	WATER PUMP REPAIR KIT	1
3	90430-08020	.GASKET	2	12	6L2-44323-00	.OUTER PLATE, cartridge	1
4	93210-45161	.O-RING	1	13	93210-45161	.O-RING	1
5	6L2-44367-00	.DAMPER, water seal	1	14	6L2-44352-00	.IMPELLER	1
6	93101-20048	.OIL SEAL	2	15	6L2-44322-00	.INSERT, cartridge	1
7	6L2-45315-A0	.PACKING, lower casing	1	16	97395-06040	.BOLT	4
8	93210-60MA3	.O-RING	1	17	90280-03024	.KEY, woodruff	1
9	93101-20M07	.OIL SEAL	2				

NUMERICAL INDEX

PART NO. REF. NO.

6L2-W0001-02 29- 1
6L2-W0001-23 30- 1
6L2-W0004-00 3- 2
6L2-W0070-E1 8- 9
6L2-W0078-00 30-11
6Y5-W0080-12 27- 1
6Y5-W0081-40 27- 9
6L2-W0084-00-EJ 12- 1
6Y5-W0088-20 27-28
6Y5-W0088-31 27-20
688-W0088-40 28- 5
6L2-W0090-11-EJ 1- 1
6L2-W0093-00 29-18
6Y1-W2420-62-24 7- 1
656-W2810-02 7-34
6J8-W4591-00-EL 16-20
6L2-11111-00-94 1-17
6L2-11181-A1 1-18
6L2-11191-00-9M 29- 5
6L2-11193-A1 1-19
6J8-11325-00 1-12
6H3-11327-00-94 1-13
6H3-11328-00 1-14
6E5-11372-00 1- 3
676-11372-00 1-32
6L2-11400-10 2- 1
6L2-11412-00 2- 2
6L2-11422-00 2- 3
6L2-11432-00 2- 4
6L2-11442-00 2- 5
6L2-11515-00 2-14
6J8-11536-00 2-16
6L2-11537-00 5- 2
6L2-11610-00 2-19
6L2-11610-10 2-19
6L2-11610-20 2-19
6L2-11631-00-97 2-18
648-11633-00 2-20
6L2-11635-00 2-18
6L2-11636-00 2-18
6L2-11651-00 2-10
6L2-11681-00 2-11
6E5-12411-01 1-24
6H4-12413-00-9M 1-25
6J8-12414-A0 1-26
29- 7

PART NO. REF. NO.

6J8-13117-00 5- 3
6J8-13183-00 5-13
1YU-13187-00 5- 7
6L2-13200-00 5- 5
6J8-13411-00 5-27
6J8-13414-00 5-28
6L2-13416-00 5-29
6L2-13471-00 5- 6
6L2-13610-00 3- 1
6L2-13621-00 3- 7
6L2-13641-10-94 29-12
6L2-14157-00 3- 5
6L2-14198-00 4- 9
646-14212-01 3-12
6L2-14301-01 29-14
6L3-14301-00 29-19
6L2-14302-01 4-16
6L3-14302-00 4- 1
664-14321-01 4- 2
6L2-14323-00 4- 2
6E7-14325-00 4-17
6L2-14341-00 4-15
6L2-14342-30 4-25
30X-14343-63 4-11
50M-14355-00 4-13
6L2-14368-00 4-12
6L2-14381-00 4-14
6L2-14383-00 13-26
677-14383-01 4- 3
6L2-14384-00 4- 3
6L2-14385-00 4-19
6E5-14386-01 4- 4
6L2-14392-00 29-13
6L2-14398-00 29-20
6L2-14399-00 4- 5
6L2-14417-00-94 29-21
6L2-14418-00 4- 6
6L2-14476-00 29-22
3-14

PART NO. REF. NO.

6L2-14476-11 3-20
676-14485-00 3- 6
6L2-14497-00 13- 1
6L2-14578-00 4-31
6L2-15100-10-94 1- 2
6L2-15396-00-5B 2-24
6J8-15705-00 6-19
6L2-15710-01 6- 1
6L2-15711-00-94 6- 2
6J8-15714-00 6-11
677-15717-01 6-13
6L2-15723-00 6-41
676-15741-03 6-17
6L2-15746-00 6-29
6L2-15747-00 6-33
656-15748-00 6-26
689-15755-01 6- 8
6L2-15758-00-94 6- 4
6L2-15762-00 6- 7
6L2-15770-00 6-28
6L2-15772-00-94 6-37
6L2-15774-00 6-34
6F5-15779-02 6- 9
6A0-15789-00 6-20
6L2-21707-01 5-22
6J8-21744-00 5-34
6H1-21757-00 5-26
6L2-21758-00 5-24
6H4-21770-00 5-23
6L2-21798-00 5-42
6Y1-24167-00 7- 9
6Y1-24246-00 7- 2
6Y1-24256-80 7-10
6Y1-24257-00 7- 3
6Y1-24260-02 7- 4
6Y1-24268-00 7- 5
6G1-24304-02 7-20
6G1-24305-01 7-16
6Y1-24305-02 7-18
6Y1-24306-51 7-11
6H4-24311-00 7-23
6Y1-24329-00 7- 7
650-24351-51 7-15
6Y1-24360-51 7-13
6E5-24376-10 5-35
677-24411-02 4-29
682-24412-01 4-28
6L2-24413-00 4-27

PART NO. REF. NO.

6A0-24421-01 4-23
677-24434-02 4-30
6L2-24435-00 4-26
677-24435-01 4-26
677-24444-01 4-21
655-24521-01 7-29
655-24560-01 7-26
6F5-24563-00 7-27
6L2-24566-00 7-30
6Y1-24610-00 7- 8
6H1-24633-00 5-25
6L2-26301-00 12-23
6G8-26363-00 22-15
6L2-26363-00 12-35
6G8-26364-00 22-16
80L-26397-00 24-58
6L2-41111-00-9M 1-29
6L2-41112-A1 1-30
6L2-41113-00-9M 29- 9
6L2-41114-A1 1-31
6L2-41131-00-5B 29- 8
6L3-41131-00-9M 14-10
6L2-41133-A1 14-13
6L2-41134-00 29-17
6L2-41212-00 14-11
6L2-41213-00 30- 2
6L2-41217-00 13-35
6H1-41237-00 13- 4
6L2-41237-00 13-39
682-41237-50 5-17
6L2-41238-00 9-11
6L2-41257-00 9-11
6J8-41259-00 20- 9
661-41262-02 25- 5
6J8-41271-01 9-13
689-41273-00 9-13
6J8-41274-00 9-10
6L2-41283-00 9-15
6G1-41611-00 17-18
6G1-41612-00 17-22
695-41613-00 17-19
6L2-41631-00 13- 6

PART NO. REF. NO.

6G1-41662-01-94 13-16
6G1-42111-03-EJ 12- 2
664-42119-00 12-12
6L2-42121-00-EJ 10-21
6G1-42125-01 12- 9
6G1-42126-00 12-10
6G1-42131-01 12- 7
6L2-42137-00 12-14
6G1-42138-01 12-20
6L2-42154-01 22- 6
6E0-42159-02 12-21
6J8-42167-00 13- 7
6L2-42167-00 13- 8
689-42169-01 13-12
6G1-42177-00 12-13
6L2-42191-01 22- 7
6L2-42192-00 13-30
6L2-42192-20 22- 8
6L2-42510-00-EJ 10-26
6H4-42528-00 10-18
624-42542-00 5-40
6L2-42610-V4-EJ 8- 1
6L3-42610-V4-EJ 8- 1
6L2-42613-00-EJ 8- 6
6L2-42615-00 8- 2
6L2-42647-00 8- 4
6G1-42651-71 8- 3
6L2-42677-10 8-10
6L3-42677-10 8-10
6L2-42678-10 8-11
6L3-42678-10 8-11
6L2-42711-02-EJ 9- 1
6L2-42716-00 9-16
6L2-42719-A0 9- 8
6G1-42724-00 9-12
6L2-42725-00 9-11
6L2-42725-50 20- 9
689-42725-40 25- 5
6L2-42726-01 25- 8
6L2-42726-10 9-13
6G1-42727-00 9-13
6L2-42738-01 9-21
6L2-42748-01 9-15
6L2-42815-00-EJ 9- 2
6L2-42816-00 9- 4
6L2-43111-02-EJ 10- 1
6L2-43112-03-EJ 10- 2

PART NO. REF. NO.

6J8-43113-01 10-14
648-43114-01 10- 8
6L2-43116-00 10- 7
616-43118-00-EJ 10- 5
6J8-43131-01 10- 9
6E5-43145-00 23- 9
6G5-43145-00 10-13
6L2-43160-00 11- 3
6L2-43165-00 11- 1
6L2-43188-00 11-15
6L2-43191-01 11-10
6L2-43311-03-EJ 10-15
682-43318-01 11- 5
6L2-43336-00 11-25
6L2-43350-02 11-13
689-43373-01 10-19
6J8-43611-01 11-26
6L2-43611-00 11-17
6L2-43613-00 11-22
6L2-43614-00 11-28
6L2-43615-00 11-31
6L2-43617-00 11-21
6L2-43624-00 11-24
6L2-43630-01 11- 4
6L2-43631-00 11-14
6L2-43633-10 11-16
6L2-43641-00 11-18
6L2-43657-00 11-33
6L2-43659-00 11-19
6L2-43676-00 11-34
6L2-43682-01 11- 7
6L2-44111-00-94 12-24
6J8-44116-00 13-19
6L2-44121-00 13-15
6L2-44122-00 13-28
6L2-44123-00 13-22
6L2-44124-00 12-34
6L2-44125-00 12-29
6L2-44141-01 13-33
6L2-44141-10-94 13-36
6L2-44143-00 13-24
6L2-44147-00 15-20
6L2-44150-00 15-49
6L2-44150-10 15-49
6E0-41191-11 10-22
6L2-44311-00 15- 9
6L2-44322-00 15-11
30-15

NUMERICAL INDEX

PART NO. REF. NO.

6L2-44323-00 15-12
30-12
6L2-44328-00 15-16
6L2-44352-00 15-13
30-14
6L2-44361-00 16- 2
6L2-44361-10 16- 2
6L2-44365-00 10-33
6L2-44366-00 16- 3
6L2-44367-00 16- 9
30- 5
6L2-44368-00 16- 1
6H3-44391-01 9-22
6L2-44512-00-EJ 10-31
6L2-44514-00 10-36
6L2-44526-00 10-41
6L2-44551-00-EJ 10-43
6L2-44552-00-EJ 10-44
6L2-44553-00-EJ 10-50
6L2-44555-00 10-48
6L2-44557-00 10-49
6L2-45111-01-EJ 14- 1
6L2-45111-11-EJ 14- 1
6L2-45113-A1 1-37
29-16
6L2-45114-A1 10-32
6L2-45115-00 14- 3
663-45119-00 10-17
6L2-45123-00 14-12
6L2-45151-01-EJ 14- 2
6L2-45214-00 16-10
6L2-45215-00 16-11
6L2-45300-02-EJ 15- 1
6L2-45300-12-EJ 15- 1
6L2-45311-01-EJ 15- 2
6L2-45315-A0 15-22
30- 7
6L2-45331-00-5B 15-17
6L2-45361-02-EJ 15-42
664-45371-01 16- 7
6L2-45375-00 15-25
6L2-45510-00 15-26
6L2-45510-10 15-26
6L2-45536-00 15- 6
6L2-45551-01 15-28
6L2-45560-00 15-32
6L2-45567-00-10 15- 4
6L2-45567-00-11 15- 4

PART NO. REF. NO.

6L2-45567-00-12 15- 4
6L2-45567-00-14 15- 4
6L2-45571-00 15-33
6L2-45577-00-10 15-35
6L2-45577-00-11 15-35
6L2-45577-00-12 15-35
6L2-45577-00-13 15-35
6L2-45587-00-15 15-31
6L2-45587-00-16 15-31
6L2-45611-00 15-36
6L2-45631-00 15-38
648-45633-00 15-40
648-45635-00 15-41
664-45941-01-EL 16-19
664-45943-01-EL 16-19
664-45945-00-EL 16-19
664-45947-01-EL 16-19
664-45949-02-EL 16-19
664-45952-00-EL 16-19
664-45970-00-98 16-19
664-45972-00-98 16-19
6J8-45986-10-98 16-21
6L2-45987-01 16-14
689-45997-00 16-15
703-48153-00 24- 3
703-48189-00 24-20
703-48197-00 24- 6
703-48198-00 24-17
703-48215-00 24-46
702-48217-00 24-47
703-48219-00 24-33
703-48220-12 21- 2
703-48221-00 24-60
703-48222-00 24-30
703-48222-10 24-30
703-48223-00 24-31
703-48224-00 24-59
703-48225-00 24-32
703-48226-00 24-29
703-48227-00 24-27
703-48230-12 21- 1
24- 1
703-48234-00 24-21
703-48235-00 24- 4
703-48236-00 24-19
703-48238-00 24-25
703-48243-00 24-18

PART NO. REF. NO.

703-48244-00 24-24
703-48245-00 24-14
703-48246-00 24-26
701-48248-00 24-16
703-48252-00 24-15
703-48261-10 24- 2
703-48263-00 24- 8
703-48264-00 24- 9
703-48265-00 24-12
703-48268-00 24- 7
703-48273-00 24- 5
703-48284-00 24-56
701-48287-00 24-45
703-48290-01 21- 4
703-48291-10 24-42
703-48293-00 24-44
703-48293-10 24-44
701-48310-40 21- 3
701-48310-60 21- 3
701-48310-80 21- 3
701-48310-90 21- 3
701-48320-00 21- 3
701-48320-20 21- 3
701-48320-30 21- 3
701-48320-40 21- 3
701-48320-50 21- 3
701-48320-60 21- 3
701-48320-70 21- 3
701-48320-80 21- 3
701-48320-90 21- 3
703-48345-01 24-22
701-48350-00 21- 3
701-48350-10 21- 3
701-48350-20 21- 3
703-48358-00 24-23
6L2-48501-11 22- 1
6J8-48511-00-EJ 22-21
6L2-48511-00 22-17
6L2-48531-00 22-11
6L2-48534-01 22- 3
682-48538-50 22-12
6L2-48544-01 22- 2
688-61301-01 23-11
6E5-61303-00 23-16
688-61311-11 23-20
6E5-61313-00 23-19
6E5-61315-00 23-17
689-61350-02 23- 1

PART NO. REF. NO.

689-61351-01 23- 2
6L2-81332-00 17-24
6L2-81800-11 19- 1
682-81809-10 19- 3
682-81810-11 19- 5
6L2-81811-10 19- 9
6L2-81812-10 19-10
682-81813-10 19- 8
6L2-81820-10 19- 6
682-81826-10 19-13
682-81830-10 19-12
682-81832-10 19-11
6L2-81833-10 19- 4
682-81834-10 19-15
6L2-81840-10 19- 7
682-81847-10 19-14
6L2-81850-11 19- 2
697-81901-60 28- 9
663-81910-10 25-13
6G1-81941-10 20- 1
6L2-81945-00 20- 3
6G1-81952-00 20- 2
6J8-81960-00 18-21
6G1-81970-61 20-10
25- 9
6G1-82105-00 20- 6
6J8-82105-10 18-24
6G1-82117-00 20- 7
6Y5-82117-00 28-16
6G1-82119-00 20- 8
6L2-82127-00 14- 6
6E5-82148-00 10- 3
6Y5-82149-00 28-15
1E6-82151-00 27- 8
28-19
6G1-82151-00 20-11
25-10
6G5-82152-00 20-14
6A0-82317-00 5-39
6G1-82370-20 18-17
689-82510-00 26- 2
703-82510-10 24-48
688-82520-00 28-13
6Y5-82521-00 28-17
663-82521-09 28-12
688-82526-00 28-14
703-82531-00 24-50
6H3-82540-00 26-16

PART NO. REF. NO.

703-82540-00 24-54
689-82550-01 25- 1
689-82550-11 25- 6
689-82553-20 25- 4
25- 7
6L2-82554-00 26-17
682-82556-00 9-24
24-52
25- 3
26- 5
18-20
689-82570-15 26- 1
689-82571-02 26- 6
703-82574-00 24-49
26- 3
688-82575-01 24-51
26- 4
9-23
689-82575-03 25- 2
689-82575-12 25- 2
663-82581-01 26- 7
688-82586-11 26-15
688-82586-21 24-53
688-82586-31 26-15
688-82586-50 26-14
6E5-82588-00 9-27
6L2-82590-00 20-29
703-82594-00 24-28
6L2-82599-00 17-26
28- 4
688-83373-10 28- 1
703-83383-01 24-55
6Y5-83504-01 27-21
6Y5-83510-30 27-10
6Y5-83514-00 27- 6
27-14
688-83516-00 27- 3
27-11
6Y5-83518-00 27-24
27-30
6Y5-83523-00 27- 5
27-13
6Y5-83536-00 27-25
27-31
6Y5-83536-10 27- 4
27-12
6Y5-83540-12 27- 2
6Y5-83544-00 27-33
6Y5-83553-00 27- 7

PART NO. REF. NO.

6Y5-83553-00 28-18
663-83553-A0 27-26
27-36
663-83553-Y0 27-27
27-35
688-83556-01 27-17
6K3-83557-00 20-30
688-83557-00 27-15
6Y5-83577-00 27-23
688-83664-00 27-22
27-32
663-84301-01 28- 6
663-84309-00 28- 7
682-84381-00 9-25
6J8-85410-00 9-26
663-85518-00 17-14
6L2-85520-F0 17- 3
6L2-85533-F0 17- 6
6L2-85540-10 18- 1
6L2-85542-01-94 18- 4
6G1-85548-70 17-11
6L2-85550-A0 17- 1
6L2-85560-F1 17- 2
6L2-85570-N0 18- 9
6L2-85592-F1 17- 4
6L2-85595-F1 17- 5
6L2-85720-01 5-45
6Y5-85750-00 27-29
688-85752-01 27-34
6L2-86111-00 20-15
6L2-86112-00 20-23
6L2-86115-00 20-17
682-86117-00 20-16
90101-06M16 18- 7
90101-08M09 10-39
90101-09M66 23- 7
90101-09M70 23-14
90105-06M15 9-20
90105-06M18 10-20
90105-06M23 22-14
90105-08M02 16- 8
90105-10M12 16- 5
90109-05M33 5-10
90109-06M28 13-34
90116-10M28 10-23
90119-06M14 1-11
90119-06M65 5-41
90119-08M20 1-21

NUMERICAL INDEX

PART NO.	REF. NO.
90119-08M21	1-10
90149-05M05	26-10
90149-05M13	12-18
90157-06M06	14- 7
90159-06M11	14- 4
90159-06M15	18- 3
90170-06015	13-25
90170-09M03	23- 5
90170-09M05	23-13
90170-14M06	23-21
90171-14013	16-17
90179-10M14	15-29
90179-12M04	17-16
90185-05002	16-13
90185-09M01	23- 4
	23-15
90185-10051	10-25
	22-18
90185-22043	10-12
90201-06M62	6-35
90201-065F3	6-14
90201-08M01	10-40
90201-08M93	5- 1
90201-08086	1- 8
90201-10M20	23- 3
90201-10M63	23- 8
90201-10M76	23-12
90201-13M42	17-17
90201-18522	2-23
90201-20417	15-34
90201-22428	10-11
90201-30M00	10-28
90201-50306	2-17
90202-05M38	12-38
90202-05088	5-20
	12-37
	13-31
	22- 9
90202-06009	12-32
90202-15M37	12-27
90202-35M24	12- 4
90206-12052	9- 5
90206-15M18	12-26
90206-35M20	12- 3
90209-24M15	2-13
90243-04M00	10- 6
90250-05010	15-39
90266-04M00	8- 5

PART NO.	REF. NO.
90266-04M04	8-12
90269-02M09	12-15
90280-03024	15-27
	30-17
90280-05013	17-15
90338-05M03	9-17
90340-08M04	15- 7
90386-08032	11- 6
	12-19
90386-10009	22- 4
90386-12M45	9- 3
90386-12M72	12-28
90386-15M73	12-25
90386-22M67	10-10
90386-30M60	10-30
90386-30M75	10-27
90386-34M40	12- 5
90386-43M79	12- 6
90387-06M18	13-11
90387-06M51	6-30
90387-06M52	9-19
90387-10M42	23- 6
90430-08020	15- 8
	30- 3
90445-07M04	5-14
90445-07M15	1- 4
90445-07M16	5-16
90445-07M32	5-11
90445-09M25	7-24
90445-09012	3-10
90445-10M40	1-36
90445-11M03	5-32
90445-11M05	7-14
90445-11M06	7-12
90445-11M07	5-33
90446-10M02	5-38
90464-11M24	5-37
90465-08028	18-14
90465-11M10	27-16
90465-13169	24-57
90465-18147	18-12
90467-06016	1- 5
90467-08004	3-11
	5-30
	7-25
90467-10M04	5-36
90467-11M08	5-31
90468-05M03	5-21

PART NO.	REF. NO.
90468-05M03	12-39
90468-07M02	5-12
	5-15
90480-10155	20-20
90480-15M31	9-18
90480-25161	18-13
90501-10065	15-37
90501-10227	6-27
90501-23215	12-16
90506-20M27	11-12
90506-23M11	11-32
90508-12M28	11-29
90508-12M29	11-30
90510-08M04	6-12
90601-31402	27-18
90890-44373	6-10
91490-16010	12-11
91490-20010	12-33
	13-32
	22-10
91490-30030	16-18
91690-30010	2-15
91690-30012	22-13
91690-30318	13-23
	13-29
91690-40014	6- 3
92901-04100	4-32
	26- 9
92902-04100	17-13
92903-04100	29-26
92990-04200	20-22
92990-05100	17-10
	26-12
92990-05600	3- 4
	3-17
	3-23
	11- 9
	13-38
	20-13
	20-19
	25-12
	26-13
	28- 3
92990-06100	6-32
	18-11
	20- 5
	20-25
	20-28

PART NO.	REF. NO.
92990-06100	26-19
92990-06200	18- 2
92990-06600	1-16
	1-23
	1-28
	1-35
93210-03261	2-29
93210-08287	3- 9
	3-19
	5-44
93210-13595	6- 6
93210-16275	6-22
93210-19M82	6-24
93210-29375	6-39
93210-35M86	7-22
93210-37M25	8- 8
	10-35
93210-42159	12-31
	13-10
93210-45161	13-18
	13-21
	14-15
93210-56M80	15-15
	15-24
	15-48
93210-60M99	17-21
	18- 6
	18- 8
93306-00609	18-23
93306-305U5	28-11
93310-424W9	7-33
93313-628U0	10-47
93315-220V9	10-52
93315-22004	10-55
	14- 9
93332-00005	19-17
93341-320U0	24-37
93430-06M02	10-24
93430-06024	12-17
93450-20026	16- 6
93602-18M12	22-19
93604-10M03	16-16
	18-16
	18-19
	2-26
93700-06M03	29- 3
94702-00271	15-46
95303-06700	30- 9

PART NO.	REF. NO.
93101-20048	15-19
	30- 6
93102-25142	2-25
	29- 2
93102-26M27	2- 7
	29-10
93210-03261	20-26
93210-08287	7-17
	7-19
	5- 4
93210-13595	23-10
93210-16275	5- 8
93210-19M82	10-29
93210-29375	3-15
93210-35M86	7-28
93210-37M25	29-15
	2- 8
93210-42159	29-11
	15-10
93210-45161	30- 4
	30-13
	2-27
93210-56M80	29- 4
	15-44
93210-60M99	30- 8
	15-51
	30-10
93306-00609	15-43
93306-305U5	2- 9
93310-424W9	2-12
93313-628U0	2- 6
93315-220V9	15- 5
93315-22004	15-18
	15-45
	15- 3
	15-30
	6-18
93713-06025	24-13
	2-22
	2-21
	1- 6
	10-45
	14- 5
	15-21
	16- 4
93700-06M03	10-16
94702-00271	1-38
95303-06700	6-16

PART NO.	REF. NO.
95333-08600	1- 9
95380-03600	4-24
95380-05600	13-14
	24-10
	26-11
95380-05700	5-19
	13-41
95380-06600	15-50
	24-43
95380-06700	12-36
	13- 3
95380-08600	7-32
	10-54
95380-14700	23-18
95428-31316	28- 8
95612-08645	1- 7
95780-06300	9- 7
95780-08300	10-42
	22- 5
95895-06016	9-28
97013-06012	7-31
	17-20
	20- 4
	20-24
	20-27
	26-18
97013-08025	19-16
97313-05012	3-16
97313-05016	13-37
97313-06008	13-27
97313-06016	1-15
	1-22
	5-43
97313-06020	6-31
	6-38
	6-40
	13-17
	1-27
	3- 8
	6-15
97313-06030	1-34
	18- 5
	18-10
	24-11
97380-05025	3-18
97390-06085	11- 8
97395-05010	12-22
97395-05012	13-20
97395-06012	



FLOOD MARINE SERVICES
downloaded from www.yamahaoutboardparts.co.uk

PART NO.	REF. NO.	PART NO.	REF. NO.
97395-06012	18-15	98580-04008	20-21
	18-18	98580-04010	4- 8
97395-06016	2-28		24-38
	6- 5	98580-04012	29-25
	8- 7	98580-05008	20-18
	12- 8	98580-05010	24-40
	18-22	98580-05016	3- 3
97395-06020	7-21	98586-05016	7- 6
	10-34	98680-05030	16-12
	12-30	98780-05012	24-34
	13- 2	98780-05016	24-35
	14-14	98813-03100	4-24
	15-23	98980-04006	4-22
	15-47	99080-05600	11-11
97395-06025	6-23		11-20
97395-06035	6-21		11-23
97395-06040	15-14		11-27
	30-16	99530-10014	6-25
97395-06075	13- 9		
97395-08030	14- 8		
	24-36		
97395-08045	10-51		
97395-08070	10-53		
97395-08085	10-46		
97395-10040	22-20		
97513-05218	5- 9		
97515-06210	11- 2		
97515-06240	10-38		
97515-06250	10-37		
97516-08212	6-42		
97780-40116	27-19		
97780-60120	28-10		
97780-60516	28- 2		
97886-05016	3-22		
97890-06035	9- 6		
97895-06008	10- 4		
97980-04112	4-18		
97985-05210	17-23		
	17-25		
98303-04008	26- 8		
98501-05010	17- 8		
98501-05020	17- 7		
98503-05025	17- 9		
	20-12		
	25-11		
98580-03015	24-41		
98580-04006	24-39		
98580-04008	17-12		

NUMERICAL INDEX

PART NO.	REF. NO.	PART NO.	REF. NO.
----------	----------	----------	----------

FLOOD MARINE SERVICES
downloaded from www.yamahaoutboardparts.co.uk



FLOOD MARINE SERVICES
downloaded from www.yamahaoutboardparts.co.uk



FLOOD MARINE SERVICES
downloaded from www.yamahaoutboardparts.co.uk



FLOOD MARINE SERVICES
downloaded from www.yamahaoutboardparts.co.uk



FLOOD MARINE SERVICES
downloaded from www.yamahaoutboardparts.co.uk



FLOOD MARINE SERVICES
downloaded from www.yamahaoutboardparts.co.uk



FLOOD MARINE SERVICES
downloaded from www.yamahaoutboardparts.co.uk



FLOOD MARINE SERVICES
downloaded from www.yamahaoutboardparts.co.uk