




PARTS CATALOGUE CATALOGUE DE PIECES DETACHEES

6CMH'09 (6M88)
8CMH'09 (6N08)



1H6M8-300F1

()

2016/2/12

NEWS NO.	DATE	COMMENT
PE0-OM-110032	Jun.,24,2011	COR:FIG.15 LOWER CASING & DRIVE 1 ILLUSTRATION CORRECTION
PE0-OM-120022	Mar.,16,2012	MOD:FIG.5 CARBURETOR LIST/ILLUSTRATION REVISION
PE0-OM-160002	Feb.,8,2016	MOD:6C/6D/8C FUEL ILLUSTRATION REVISION

6CMH/8CMH
PARTS CATALOGUE
©2008 by Yamaha Motor Co., Ltd.
1st edition, July 2008
All rights reserved.
Any reprinting or unauthorized use
without the written permission of
Yamaha Motor Co., Ltd.
is expressly prohibited.
Printed in Japan.

6CMH/8CMH
CATALOGUE DE PIECES DETACHEES
©2008 par Yamaha Motor Co., Ltd.
1^{re} édition, juillet 2008
Tous droits réservés
Toute réimpression ou utilisation
non autorisée sans la permission écrite
de la Yamaha Motor Co., Ltd.
est formellement interdite.
Imprimé au Japon

FOREWORD

This Parts Catalogue is related to the parts for the model(s) on the cover page. When you are ordering replacement parts, please refer to this Parts Catalogue and quote both part numbers and part names correctly.

1. Modifications or additions which have been made after the issue of the Parts Catalogue will be announced in the Parts News.
It is advisable that you make the necessary corrections to the Parts Catalogue according to the Parts News.

2. Abbreviations

The following abbreviations are used in this Parts Catalogue.

“UR” Use specified parts number.

“UN” Use as many as needed.

“AP” Alternate Parts

“LM” Locally Made (Parts need to be ordered locally)

“F#” Frame No. (Applicable machine No.)

“O/S” Over Size

3. The number of components for assembly

- Parts, which are to be supplied in an assembly, are listed with a dot (.) in front of the part name as shown below.
- The numeral appearing to the right of each component part indicates the quantity of parts for each assembly unit.

PART NO.	DESCRIPTION	Q'TY	REMARKS
2F5-83310-60	FRONT FLASHER LIGHT ASSY	2	
115-83311-60	.BULB (6V-18W)	1	

4. Applicable colours of graphics are represented in the “REMARKS” as shown below.



PART NO.	DESCRIPTION	Q'TY	REMARKS
2N4-24110-00-X5	FUEL TANK COMP.	2	MXR
3J1-24240-10	.GRAPHIC, FUEL TANK	1	FOR MXR

5. Note that the illustrations for reference in finding parts numbers are not to be used for assembling. When assembling, please use the applicable service manual.

6. The asterisk (*) before a reference number indicates modified items after the first edition.

7. Applicable Serial No.

Engine Serial No.



8. Applicable Engine Starting Serial No.

Model	Serial No.	Model	Serial No.
6C	6M8-1011826	8C	6N0-1028651

9. Applicable Colour Code

Abbreviation	Colour Name	Colour Code
DBNM2	DARK BLUISH GRAY METALLIC 2	004D

10. Quantity Column Information

Column No.	Name Of Q'ty Column	Applicable Model
1	6M88	6CMH
2	6N08	8CMH

AVANT-PROPOS

Ce catalogue de pièces détachées concerne les pièces pour le(s) modèle(s) indiqué(s) sur la page de couverture. Lorsque vous commandez des pièces de rechange, veuillez vous référer à ce catalogue de pièces détachées et indiquer clairement les numéros et les noms des pièces détachées.

1. Les modifications ou ajouts ayant été effectués après la parution du catalogue de pièces détachées seront décrits dans les Bulletins d'information concernant les pièces détachées.
Il est recommandé que vous apportiez les corrections nécessaires au catalogue des pièces détachées en vous référant aux Bulletins d'information.

2. Abréviations

Dans ce catalogue, les abréviations suivantes sont utilisées:

“UR” Utiliser le numéro de pièces spécifié.

“UN” Utiliser autant que nécessaire.

“AP” Pièces de substitution

“LM” Fabrication locale (les pièces doivent être commandées localement.)

“F#” N° de cadre (applicable au N° de série)

“O/S” Surdimensionné

3. Nombre de pièces d'un assemblage

- Les pièces fournies comme composants d'un assemblage sont précédées d'un point (.) de la manière indiquée ci-dessous.
- Le chiffre apparaissant à la droite de chaque composant indique la quantité de pièces pour chaque unité d'assemblage.

N° PIECES	DESCRIPTION	QTE	REMARQUES
2F5-83310-60	ENS. CLIGNOTANT AVANT	2	
115-83311-60	.AMPOULE (6V-18W)	1	

4. Les couleurs concernant les graphiques sont indiquées dans la colonne “REMARQUES”, comme indiqué ci-dessous.



N° PIECES	DESCRIPTION	QTE	REMARQUES
2N4-24110-00-X5	RESERVOIR A ESSENCE.	2	MXR
3J1-24240-10	.GRAPHIQUE	1	POUR MXR

5. Veuillez noter que les illustrations sont indiquées à titre de référence pour trouver les numéros de pièces, non pour être utilisées lors de l'assemblage. Lors de l'assemblage, veuillez utiliser le manuel d'entretien adéquat.

6. L'astérisque (*) placé devant un numéro de référence indique des éléments qui ont été modifiés après la première édition.

7. N° de série applicable

N° de Série du moteur



8. N° de série initial du moteur applicable

Modèle	N° de série	Modèle	N° de série
6C	6M8-1011826	8C	6N0-1028651

9. Code couleur applicable

Abréviation	Nom de la couleur	Code couleur
DBNM2	DARK BLUISH GRAY METALLIC 2	004D

10. Informations relatives à la colonne Quantité

N° de la colonne	Nom de la colonne Qté	Modèle applicable
1	6M88	6CMH
2	6N08	8CMH

CONTENTS

TOP COWLING	1
CYLINDER & CRANKCASE	2
CRANKSHAFT & PISTON	4
INTAKE	5
CARBURETOR	6
FUEL	8
STARTER	9
GENERATOR	11
ELECTRICAL	12
BOTTOM COWLING	13
STEERING	15
CONTROL	16
BRACKET	18
UPPER CASING	21
LOWER CASING & DRIVE 1	22
LOWER CASING & DRIVE 2	25
FUEL TANK	26
REPAIR KIT	27

INDEX


NUMERICAL INDEX	29
-----------------------	----

TABLE DES MATIERES

CAPOT SUPERIEUR 1
CYLINDRE & CARTER 2
VILEBREQUIN & PISTON 4
ADMISSION 5
CARBURATEUR 6
CARBURANT 8
DEMARREUR 9
GENERATRICE 11
ELECTRIQUE 12
CAPOT INFERIEUR 13
DIRECTION 15
COMMANDE 16
SUPPORT 18
FOURREAU 21
BOITIER D'HELICE TRANSMISSION1 22
BOITIER D'HELICE TRANSMISSION2 25
RESERVOIR A CARBURANT 26
KITS DE REPARATION 27

INDEX

INDEX NUMERIQUE 29



6M81200-2010

FIG. 1 TOP COWLING

CAPOT SUPERIEUR

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6M88	6N08	REMARKS REMARQUES
1	6M8-G2610-30-4D	TOP COWLING ASSY CAPOT (ENS.)	1		
	6N0-G2610-30-4D	TOP COWLING ASSY CAPOT (ENS.)		1	
2	6N0-G2613-00-4D	.MOLDING, AIR DUCT .MANCHON A AIR	1	1	
3	97095-06016	.BOLT .BOULON	4	4	
4	92995-06600	.WASHER .RONDELLE	4	4	
5	6G1-15761-00	.SEAL, RUBBER 1 .JOINT CAOUTCHOUC 1	1	1	
6	6G1-42615-00	.SEAL .JOINT	1	1	
7	6G1-42647-00	.HOLDER, CLAMP BAND .SUPPORT, SANDOW DE SERRAGE	1	1	
8	6N0-G2651-00	.HOOK .CROCHET	1	1	
9	90266-04M00	.RIVET .RIVET	4	4	
10	6N0-WG070-10	.GRAPHIC SET .JEU DIEMBLEMES	1	1	
11	6M8-G2677-20	.GRAPHIC, FRONT .ADHESIF, AVANT	1		
	6N0-G2677-20	.GRAPHIC, FRONT .ADHESIF, AVANT		1	
12	6M8-G2678-11	.GRAPHIC, REAR .ADHESIF, ARRIERE	1		
	6N0-G2678-11	.GRAPHIC, REAR .ADHESIF, ARRIERE		1	
13	60R-G4191-00	.INDICATOR, SHIFT .ETIQUETTE, EMBRAYAGE	1	1	





FIG. 2 CYLINDER & CRANKCASE


CYLINDRE & CARTER

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6M88	6N08	REMARKS REMARQUES
1	6N0-WE090-01-1S	CRANK CYLINDER ASSY EMBIELLAGE CYLINDRE (ENS.)	1	1	
2	6N0-E5100-00-1S	CRANKCASE ASSY CARTER DE MOTEUR COMPLET	1	1	
3	93604-08062	PIN, DOWEL CLAVETTE	4	4	
4	90105-06M26	BOLT, FLANGE BOULON	6	6	
5	90105-06M25	BOLT, FLANGE BOULON	4	4	
6	90387-22M50	COLLAR COLLERETTE	1	1	
7	6E5-12411-02	THERMOSTAT THERMOSTAT	1	1	
8	6E5-12412-00	SEAL, THERMOSTAT JOINT, THERMOSTAT	1	1	
9	6G1-15359-01-94	HOUSING, OIL SEAL LOGEMENT, BAGUE D'ETANCHEITE	1	1	
10	93210-54M54	O-RING JOINT TORIQUE	1	1	
11	93102-20M25	OIL SEAL JOINT SPY	1	1	
12	97013-06016	BOLT BOULON	3	3	
13	6G1-15396-02-5B	HOUSING, OIL SEAL LOGEMENT DE JOINT SPY	1	1	
14	93210-42159	O-RING JOINT TORIQUE	1	1	
15	93101-20M34	OIL SEAL JOINT SPY	1	1	
16	93101-12M26	OIL SEAL JOINT SPY	1	1	
17	97095-06016	BOLT BOULON	1	1	
18	92995-06600	WASHER RONDELLE	1	1	
19	6N0-E1191-00-1S	COVER, CYLINDER HEAD 1 COUVERCLE, CULASSE 1	1	1	
20	6G1-11193-A1	GASKET, HEAD COVER 1 JOINT, COUVERCLE DE CULASSE 1	1	1	
21	90105-06039	BOLT, FLANGE BOULON	7	7	
22	6N0-G1111-00-1S	INNER COVER, EXHAUST PLAQUE, ECHAPPEMENT	1	1	
23	6G1-41112-A1	GASKET, EXHAUST INNER COVER JOINT, PLAQUE D'ECHAPPEMENT	1	1	
24	6G1-41113-01-1S	OUTER COVER, EXHAUST COUVERCLE, ECHAPPEMENT	1	1	
25	90105-06037	BOLT, FLANGE BOULON	7	7	
26	6G1-41114-A0	GASKET, EXHAUST OUTER COVER JOINT, COUVERCLE D'ECHAPPEMENT	1	1	
27	6G1-45113-A1	GASKET, UPPER CASING JOINT, TUBE D'ARBRE	1	1	



CYLINDRE & CARTER

3




6M80010-4030

FIG. 3 CRANKSHAFT & PISTON

VILEBREQUIN & PISTON

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6M88	6N08	REMARKS REMARQUES
1	6N0-E1400-00	CRANKSHAFT ASSY VILEBREQUIN COMPLET	1	1	
2	6N0-E1412-00	.CRANK 1 .MASSOLOTTE DE VILEBREQUIN 1	1	1	
3	6N0-E1422-00	.CRANK 2 .MASSOLOTTE DE VILEBREQUIN 2	1	1	
4	6N0-E1432-00	.CRANK 3 .MASSOLOTTE DE VILEBREQUIN 3	1	1	
5	6N0-E1442-00	.CRANK 4 .MASSOLOTTE DE VILEBREQUIN 4	1	1	
6	6G1-11681-00	.PIN, CRANK 1 .MANETON, VILEBREQUIN 1	2	2	
7	93306-204U0	.BEARING .ROULEMENT	3	3	
8	93310-418V1	.BEARING .ROULEMENT	2	2	
9	90209-18112	.WASHER .RONDELLE	4	4	
10	6N0-E1651-00	.ROD, CONNECTING .BIELE NUE	2	2	
11	6N0-E1515-00	.SEAL, LABYRINTH 1 .JOINT, LABYRINTHE 1	1	1	
12	93440-47055	.CIRCLIP .CIRCLIP	1	1	
13	91609-20008	.PIN, SPRING .AXE DE RESSORT	1	1	
14	90201-41303	WASHER, PLATE RONDELLE, PLATE	1	1	
15	6N0-E1631-00-98	PISTON (STD) PISTON (STD)	2	2	
16	6N0-E1603-00	PISTON RING SET (STD) JEU DE SEGMENTS (STD)	2	2	
17	93310-112V0	BEARING ROULEMENT	2	2	
18	6N0-E1633-00	PIN, PISTON AXE, PISTON	2	2	
19	93450-13022	CIRCLIP CIRCLIP, TYPE S	4	4	




6M88100-H040

FIG. 4 INTAKE

ADMISSION

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6M88	6N08	REMARKS REMARQUES
1	6G1-13610-01	REED VALVE ASSY CLAPET COMPLET	1	1	
2	6G1-W0004-00	.REED SET .JEU DE CLAPETS	1	1	
3	6G1-13621-A1	GASKET, VALVE SEAT JOINT, SIEGE DE CLAPET	1	1	
4	6N0-E3641-00-94	MANIFOLD 1 TUBULURE 1	1	1	
5	6G1-13645-A1	GASKET, MANIFOLD 1 JOINT, TUBULURE 1	1	1	
6	6G1-14198-A1	GASKET JOINT	1	1	
7	95895-06085	BOLT, FLANGE BOULON	2	2	
8	6M8-E4417-00	COVER 1 COUVERCLE 1	1	1	
9	6M8-E4418-00	COVER 2 COUVERCLE 2	1	1	
10	90387-06M70	COLLAR COLLERETTE	2	2	
11	97780-50514	SCREW, TAPPING VIS, TETE BOMBEE	4	4	
12	6G1-41256-00	ROD, CHOKE 1 TRINGLE 1, STARTER	1	1	
13	6G1-41271-00	KNOB, CHOKE BOUTON DE STARTER	1	1	
14	661-41262-02	JOINT, CHOKE LEVER RACCORD, LEVIER DE STARTER	1	1	
15	6AH-81994-40	LABEL, SAFETY ETIQUETTE, SECURITE	1	1	
16	6AH-81994-50	LABEL, SAFETY ETIQUETTE, SECURITE	1	1	




FWD
6M8001040501

FIG. 5 CARBURETOR

CARBURATEUR

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6M88	6N08	REMARKS REMARQUES
1	6H6-14301-01	CARBURETOR ASSY 1 CARBURATEUR COMPLET 1	1		
	6G1-14301-01	CARBURETOR ASSY 1 CARBURATEUR COMPLET 1		1	
2	679-14923-00	.SCREW, PILOT .VIS, RALENTI	1	1	
3	679-14555-00	.SPRING .RESSORT	1	1	
4	6G1-14966-00	.CAP .CAPUCHON	1	1	
5	6G1-14527-00	.PLATE .PLAQUE	1	1	
6	6G1-14126-00	.GASKET .JOINT	1	1	
7	6G1-14948-05	.JET (#45) .GICLEUR (#45)	1	1	
8	676-14966-00	.CAP .CAPUCHON	1	1	
9	97880-04010	.SCREW, PAN HEAD .VIS, TETE TRONCONIQUE	2	2	
10	92990-04100	.WASHER, SPRING .RONDELLE, GROWER	2	2	
11	90501-10326	.SPRING, COMPRESSION .RESSORT, COMPRESSION	1	1	
12	63V-14523-00	.SCREW, STOP .VIS, BUTEE	1	1	
13	6G1-14984-00	.O-RING .JOINT TORIQUE	1	1	
14	6G1-14980-01	.BODY, FLOAT CHAMBER .CORPS, CUVE DE FLOTTEUR	1	1	
15	6H6-14947-00	.JET, NEEDLE .GICLEUR DE STARTER	1		
	6G1-14947-00	.JET, NEEDLE .GICLEUR DE STARTER		1	
16	676-14943-26	.JET, MAIN (#98) .GICLEUR, PRINCIPAL (#98)	1	1	
17	97980-04114	.SCREW, WITH WASHER .VIS, AVEC RONDELLE	4	4	
18	6G1-14398-00	.WASHER .RONDELLE	1	1	
19	6G1-14992-00	.SCREW, DRAIN .BOUCHON, PURGE	1	1	
20	6G1-14985-00	.FLOAT .FLOTTEUR	1	1	
21	6AH-14546-00	.VALVE, NEEDLE .POINTEAU	1	1	
23	663-14159-00	.CLIP .JONC	1	1	
24	98580-04008	.SCREW, PAN HEAD .VIS	1	1	
25	688-14548-00	.PIN, FLOAT ARM .AXE, BRAS DE FLOTTEUR	1	1	





6M8001040501

FIG. 5 CARBURETOR

CARBURATEUR

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6M88	6N08	REMARKS REMARQUES
26	98980-03006	.SCREW, BIND .VIS, DE PRESSION	2	2	
27	95380-03600	.NUT .ECROU	2	2	
28	97980-04125	.SCREW, WITH WASHER .VIS, AVEC RONDELLE	4	4	
29	6G1-24452-00	.COVER .COUVERCLE	1	1	
30	6G1-24432-00	.GASKET, FUEL PUMP 2 .JOINT 2 DE POMPE A ESSENCE	1	1	
31	6G1-24471-00	.DIAPHRAGM .DIAPHRAGME	1	1	
32	6G1-24412-01	.BODY 1 .CORPS 1	1	1	
33	6G1-24411-00	.DIAPHRAGM .DIAPHRAGME	1	1	
34	6G1-24431-01	.GASKET, FUEL PUMP 1 .JOINT 1 DE POMPE A ESSENCE	1	1	
35	6G1-24421-00	.VALVE, CHECK .SOUPAPE, RETENUE	2	2	




6M82300-7060

FIG. 6 FUEL

CARBURANT

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6M88	6N08	REMARKS REMARQUES
1	6G1-24304-02	FUEL PIPE JOINT COMP. 1 DURITE RACCORDEMT. A ESSENCE	1	1	
2	97095-06025	BOLT BOULON	1	1	
3	92995-06600	WASHER RONDELLE	1	1	
4	646-24251-02	STRAINER 1 FILTRE 1	1	1	
5	90445-09221	HOSE (L205) DURITE (L205)	1	1	
6	90445-09220	HOSE (L30) DURITE (L30)	1	1	
7	90467-08004	CLIP JONG	4	4	
8	6N0-F8100-00	TOOL KIT TROUSSE A OUTILS	1	1	
9	6N0-F8170-00	HOLDER, TOOL SUPPORT, OUTIL	1	1	
10	6G1-2811G-00	BAND COLLIER	1	1	
11	97095-06012	BOLT BOULON	2	2	
12	92995-06600	WASHER RONDELLE	2	2	
13	6L8-F8193-00	PLUG, WATER CHECK BOUCHON, CONTROLE D'EAU	1	1	AP
14	6M8-F8199-7B-E0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1	UR (E)
	6M8-F8199-7B-F0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1	UR (E)
	6M8-F8199-7B-S0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1	UR (F)
	6M8-F8199-7B-G0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1	UR (F)
	6M8-F8199-7B-D0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1	UR (ES)
	6M8-F8199-7B-H0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1	UR (ES)
	6M8-F8199-7B-K0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1	UR (D)
	6M8-F8199-7B-L0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1	UR (D)
	6M8-F8199-7B-M0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1	UR (NL)
	6M8-F8199-7B-N0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1	UR (NL)
	6M8-F8199-7B-O0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1	UR (I)
	6M8-F8199-7B-P0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1	UR (I)
	6M8-F8199-7B-Q0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1	UR (DK)
	6M8-F8199-7B-R0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1	UR (DK)
	6M8-F8199-7B-S0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1	UR (GR)
	6M8-F8199-7B-T0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1	UR (GR)
	6M8-F8199-7B-U0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1	UR (P)
	6M8-F8199-7B-V0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1	UR (P)
	6M8-F8199-7B-W0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1	UR (N)
	6M8-F8199-7B-X0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1	UR (N)
	6M8-F8199-7B-Y0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1	UR (S)
	6M8-F8199-7B-Z0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1	UR (S)
	6M8-F8199-7B-AA0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1	UR (SF)
	6M8-F8199-7B-AB0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1	UR (SF)



6M88300-H070


*1: CUT FROM 50M ROLLS, PART NO. 90890-44372, CUTTING LENGTH 1.85M

*1: A PRELEVER SUR BOBINE 50M ,REFERENCE 90890-44372, LONGUEUR DE COUPE 1.85M

FIG. 7 STARTER

DEMARREUR

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6M88	6N08	REMARKS REMARQUES
1	6M8-E5710-03	STARTER ASSY DEMARREUR COMPLET	1	1	
2	6N0-E5711-80-94	.CASE, STARTER .CARTER DE DEMARREUR	1	1	
3	6M8-E5714-00	.DRUM, SHEAVE .TAMBOUR, POULIE	1	1	
4	90510-08M03	.SPRING, SPIRAL .RESSORT, HELICOIDAL	1	1	
5	6G1-15717-00	.SHAFT, STARTER .AXE DE DEMARREUR	1	1	
6	97013-06035	.BOLT .BOULON	1	1	
7	90201-06M30	.WASHER, PLATE .RONDELLE, PLATE	1	1	
8	95303-06600	.NUT .ECROU	1	1	
9	93430-06M02	.CIRCLIP .CLIPS	1	1	
10	6G1-15705-00	.SPRING, DRIVE PAWL .RESSORT DE CLIQUET	1	1	
11	*	.WIRE (L1850) .FIL (L1850)	1	1	*1 *1
12	6G1-15755-00	.HANDLE, STARTER .POIGNEE, DE DEMARREUR	1	1	
13	6G1-15779-00	.COVER .COUVERCLE	1	1	
14	6N0-E5758-00	.GUIDE, ROPE .GUIDE DE CABLE	1	1	
15	6G1-15762-00	.SEAL, RUBBER 2 .JOINT CAOUTCHOUC 2	1	1	
16	95895-06016	.BOLT, FLANGE .BOULON	2	2	
17	677-15741-01	.PAWL, DRIVE .CLIQUET, ENTRAINEMENT	1	1	
18	95895-06020	BOLT, FLANGE BOULON	3	3	
19	6N0-E5723-00-94	PULLEY, STARTER POULIE DE DEMARREUR	1	1	
20	90105-06M29	BOLT, FLANGE BOULON	3	3	
21	6N0-E5771-00-94	STAY 1 SUPPORT 1	1	1	
22	6N0-E5772-00-94	STAY 2 SUPPORT 2	1	1	
23	97075-06020	BOLT BOULON	4	4	
24	92995-06600	WASHER RONDELLE	4	4	
25	6G1-15746-81	ARM BRAS	1	1	
26	6G1-15764-00	COLLAR 1 COLLERETTE 1	1	1	
27	95895-06025	BOLT, FLANGE BOULON	1	1	



6M88300-H070


*1: CUT FROM 50M ROLLS, PART NO. 90890-44372, CUTTING LENGTH 1.85M

*1: A PRELEVER SUR BOBINE 50M ,REFERENCE 90890-44372,
LONGUEUR DE COUPE 1.85M

FIG. 7 STARTER

DEMARREUR

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6M88	6N08	REMARKS REMARQUES
28	6N0-E5770-90	CABLE COMP., STARTER STOP CABLE, BUTEE DE DEMAR	1	1	
29	6G1-15774-81	STAY 4 SUPPORT 4	1	1	
30	656-15748-00	PLUNGER, STARTER STOP PLONGEUR, BOUTE DE DEMAR	1	1	
31	90501-10227	SPRING, COMPRESSION RESSORT, COMPRESSION	1	1	
32	6G1-44125-80	LEVER, SHIFT ROD LEVIER, TIGE D'INVERSION	1	1	
33	97880-05016	SCREW, PAN HEAD VIS, TETE TRONCONIQUE	1	1	
34	92990-05600	WASHER, PLATE RONDELLE, PLATE	1	1	
35	6G1-15747-80	LINK BIELLETTE	1	1	
36	6AH-81995-40	LABEL, WARNING ETIQUETTE, AVERTISSEMENT	1	1	
37	6AH-81995-50	LABEL, WARNING ETIQUETTE, AVERTISSEMENT	1	1	




FWD
6M80010-4080

FIG. 8 GENERATOR

GENERATRICE

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6M88	6N08	REMARKS REMARQUES
1	6G1-85550-71	ROTOR ASSY ROTOR CPLT	1	1	
2	6G1-85560-F0	BASE ASSY ENS. FLASQUE	1	1	
3	6G1-85509-70	.BASE, MAGNETO .BASE, MAGNETO	1	1	
4	6E7-85520-70	.COIL, CHARGE .BOBINE, CHARGE	1	1	
5	6E7-85580-70	.COIL, PULSER .BOBINE, PULSEUR	1	1	
6	6E7-81303-A0	.LIGHTING COIL ASSY .BOBINE D'ECLAIRAGE	1	1	
7	97802-05025	.SCREW, PAN HEAD .VIS	2	2	
8	92902-05100	.WASHER, SPRING .RONDELLE, GROWER	2	2	
9	97802-05016	.SCREW, PAN HEAD .VIS	1	1	
10	97802-05020	.SCREW, PAN HEAD .VIS	2	2	
11	92902-05100	.WASHER, SPRING .RONDELLE, GROWER	3	3	
12	6G1-85548-70	.HOLDER .SUPPORT	1	1	
13	97802-04008	.SCREW, PAN HEAD .VIS	1	1	
14	92902-04100	.WASHER, SPRING .RONDELLE, GROWER	1	1	
15	6G1-85515-70	.LEAD WIRE ASSY .FIL	1	1	
16	90386-44M42	BUSH DOUILLE	1	1	
17	90280-04M06	KEY, WOODRUFF CLAVETTE, DEMI-LUNE	1	1	
18	90170-10113	NUT ECROU	1	1	
19	90201-10126	WASHER, PLATE RONDELLE, PLATE	1	1	




6M84300-D090

FIG. 9 ELECTRICAL

ELECTRIQUE

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6M88	6N08	REMARKS REMARQUES
1	6N0-G1611-00	RETAINER, MAGNETO BASE FLASQUE, PLATEAU D'AVANCE	1	1	
2	6G1-41612-00	RETAINER, MAGNETO BASE FLASQUE, PLATEAU D'AVANCE	1	1	
3	6N0-G1613-00	PLATE, BASE FRICTION PLAQUE, FRICTION DE BASE	1	1	
4	97885-05010	SCREW, PAN HEAD VIS, A ENCOCHE	3	3	
5	92995-05600	WASHER RONDELLE	3	3	
6	6G1-41615-01	STOPPER, MAGNETO BASE BUTEE, PLATEAU D'AVANCE	1	1	
7	95895-06010	BOLT, FLANGE BOULON	1	1	
8	6G1-44194-00	CAP CAPUCHON	1	1	
9	6G1-85570-02	IGNITION COIL ASSY BOBINE D'ALLUMAGE (ENS.)	1	1	
10	95895-06025	BOLT, FLANGE BOULON	2	2	
11	6M8-82361-00	CLAMP, CORD COLLIER, CORDON	1	1	
12	6M8-82362-00	CLAMP, CORD 2 COLLIER, CABLE 2	1	1	
13	6G1-82370-21	PLUG CAP ASSY ANTIPARASITE	2	2	
14	696-85540-12	C.D.I. UNIT ASSY BLOC C.D.I.	1	1	
15	95895-06020	BOLT, FLANGE BOULON	2	2	
16	95895-06010	BOLT, FLANGE BOULON	1	1	
17	6G1-83557-00	TUBE TUBE	1	1	
18	6J8-81960-00	RECTIFIER & REGULATOR ASSY REDRESSEUR REGULATEUR CPLT	1	1	
19	6N0-H1915-00	PLATE, REGULATOR FITTING PLAQUE, FIXATION DE REGULATEUR	1	1	
20	97095-06012	BOLT BOULON	2	2	
21	92995-06600	WASHER RONDELLE	2	2	
22	6N0-H2553-10	EXTENSION, WIRE LEAD EXTENSION, FAISCEAU	1	1	




FWD
6M88100-H100

FIG. 10 BOTTOM COWLING


CAPOT INFERIEUR

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6M88	6N08	REMARKS REMARQUES
1	6N0-G2711-00-4D	COWLING, BOTTOM 1 CUVETTE 1	1	1	
2	6N0-G2815-00-4D	LEVER, CLAMP LEVIER, PRESSE	1	1	
3	90386-12M45	BUSH DOUILLE	2	2	
4	6E0-42816-00	LEVER, CLAMP LEVIER, PRESSE	1	1	
5	90206-12052	WASHER, WAVE RONDELLE, ONDULEE	1	1	
6	97885-06030	SCREW, PAN HEAD VIS, A ENCOCHE	1	1	
7	95380-06700	NUT ECROU	1	1	
8	6N0-G2719-80	PANEL, FRONT LOWER PANNEAU, AVANT INFERIEUR	1	1	
9	6N0-G2767-00	BRACKET SUPPORT	1	1	
10	90149-05M02	SCREW VIS	3	3	
11	95380-05700	NUT ECROU	1	1	
12	6G1-42724-00	GROMMET PASSE-FIL	1	1	
13	6G1-42725-00	GROMMET PASSE-FIL	1	1	
14	6G1-42726-00	GROMMET PASSE-FIL	1	1	
15	6G1-42727-00	GROMMET PASSE-FIL	1	1	
16	6G1-42748-00	GROMMET PASSE-FIL	1	1	
17	6G1-26326-00	GROMMET RONDELLE CAOUTCHOUC	1	1	
18	90480-15M31	GROMMET PASSE-FIL	4	4	
19	90387-06M52	COLLAR COLLERETTE	4	4	
20	95895-06020	BOLT, FLANGE BOULON	4	4	
21	6N0-G2716-00	RUBBER, SEAL 1 JOINT EN CAOUTCHOUC 1	1	1	
22	6E9-82575-02	ENGINE STOP SWITCH ASSY COUPE CIRCUIT CPLT	1	1	
23	682-82556-00	.LANYARD, STOP SWITCH .PLAQUETTE	1	1	
24	689-8257Y-00	.CAP .CHAPEAU	1	1	
25	6E7-42791-10	MARK 1 ETIQUETTE 1	1	1	
26	6N0-F8176-00	LABEL, CAUTION ETIQUETTE, RECOMMANDATION	1	1	
27	6AH-42794-40	LABEL, WARNING (GENERAL) ETIQUETTE, AVERTISSEMENT	1	1	



CAPOT INFERIEUR

14



FWD
6N08110-H120

FIG. 11 STEERING

DIRECTION

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6M88	6N08	REMARKS REMARQUES
1	6M8-G2111-11-4D	HANDLE, STEERING POIGNEE	1	1	
2	90206-36M21	WASHER, WAVE RONDELLE, ONDULEE	1	1	
3	90202-36M55	WASHER, PLATE RONDELLE, PLATE	1	1	
4	90386-33M96	BUSH DOUILLE	1	1	
5	90386-34M97	BUSH DOUILLE	1	1	
6	6G1-42131-02	COVER, HANDLE STEERING COUVERCLE	1	1	
7	90116-08016	BOLT, STUD GOUJON	1	1	
8	90185-08057	NUT, SELF-LOCKING ECROU, AUTO-BLOQUANT	1	1	
9	6G1-42125-01	BOLT, FRICTION ADJUSTING BOULON	1	1	
10	6G1-42126-00	FRICTION, STEERING HANDLE GRIP CUVETTE, POIGNEE DE DIRECTION	1	1	
11	91490-16010	PIN, COTTER GOUPILLE	1	1	
12	6M4-G2119-00	GRIP, STEERING HANDLE POIGNEE, BARRE FRANCHE	1	1	
13	6N0-G2177-00	RUBBER, HANDLE CAOUTCHOUC, POIGNEE	1	1	
14	6N0-G2137-10	INDICATOR, THROTTLE INDICATEUR, ACCELERATION	1	1	
15	90269-02M09	RIVET RIVET	1	1	
16	90501-23215	SPRING, COMPRESSION RESSORT, COMPRESSION	1	1	
17	90201-10M02	WASHER, PLATE RONDELLE, PLATE	2	2	
18	90149-05M13	SCREW VIS	1	1	
19	90386-08032	BUSH DOUILLE	1	1	
20	6G1-42138-01	LEVER, THROTTLE LEVIER, ACCELERATEUR	1	1	
21	6E0-42159-02	STAY SUPPORT	1	1	
22	97885-05012	SCREW, PAN HEAD VIS, A ENCOCHE	2	2	
23	6N0-F6301-10	THROTTLE CABLE ASSY CABLE D'ACCELERATEUR	2	2	




FIG. 12 CONTROL


COMMANDE

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6M88	6N08	REMARKS REMARQUES
1	6G1-41631-00	LEVER, MAGNETO CONTROL LEVIER, COMMANDE D'AVANCE	1	1	
2	6G1-41638-00	PULLEY POULIE	1	1	
3	6G1-41283-01	LEVER, FREE ACCEL. LEVIER	1	1	
4	6G1-41661-00	BRACKET 1 SUPPORT 1	1	1	
5	97880-05010	SCREW, PAN HEAD VIS, TETE TRONCONIQUE	2	2	
6	92990-05100	WASHER, SPRING RONDELLE, GROWER	2	2	
7	6G1-14497-81	STAY, THROTTLE WIRE SUPPORT DE BOISSEAU	1	1	
8	95895-06010	BOLT, FLANGE BOULON	2	2	
9	6G1-41238-00	JOINT, LINK RACCORD	1	1	
10	662-41237-01	JOINT, LINK RACCORD	1	1	
11	6E9-41237-00	JOINT, LINK RACCORD	1	1	
12	6G1-41211-00	LINK, ACCEL. BIELLETTTE, ACCELERATION	1	1	
13	661-41262-02	JOINT, CHOKE LEVER RACCORD, LEVIER DE STARTER	2	2	
14	6N0-G4111-00	HANDLE, GEAR SHIFT POIGNEE, LEVIER D'EMBRAYAGE	1	1	
15	93210-12327	O-RING JOINT TORIQUE	1	1	
16	97880-05016	SCREW, PAN HEAD VIS, TETE TRONCONIQUE	1	1	
17	92990-05600	WASHER, PLATE RONDELLE, PLATE	1	1	
18	6G1-44121-02-94	LEVER, SHIFT ROD LEVIER, TIGE D'INVERSION	1	1	
19	6G1-41662-01-94	BRACKET 2 SUPPORT 2	2	2	
20	90105-06M14	BOLT FLANGE BOULON	2	2	
21	6G1-44116-01	SPRING RESSORT	1	1	
22	95895-06012	BOLT, FLANGE BOULON	1	1	
23	6N0-G4110-00	SHIFT ROD ASSY TIGE D'INVERSION (ENS.)	1	1	
24	91690-20010	.PIN, SPRING .AGRAFFE	3	3	
25	92990-05600	.WASHER, PLATE .RONDELLE, PLATE	1	1	
26	6N0-G4145-00	CONNECTOR, SHIFT ROD CONNECTEUR, TIGE D'INVERSION	1	1	UR
	6N0-G4145-10	CONNECTOR, SHIFT ROD CONNECTEUR, TIGE D'INVERSION	1	1	UR



COMMANDE

17




6N00110-4140

FIG. 13 BRACKET

SUPPORT

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6M88	6N08	REMARKS REMARQUES
1	6M8-G3111-02-4D	BRACKET, CLAMP 1 PRESSE 1	1	1	
2	6E5-82148-00	WIRE, LEAD 4 FIL 4	1	1	
3	97885-06008	SCREW, PAN HEAD VIS, A ENCOCHE	2	2	
4	6M8-G3112-01-4D	BRACKET, CLAMP 2 PRESSE 2	1	1	
5	620-43114-00	PAD, TRANSOM CLAMP RONDELLE D'APPUI	2	2	
6	6N0-G3116-00	SCREW, TRANSOM CLAMP VIS DE PRESSE	2	2	
7	6L8-G3118-01	HANDLE, TRANSOM CLAMP POIGNEE DE VIS DE PRESSE	2	2	
8	90243-04M01	PIN GOUPILLE	2	2	
9	689-43191-00	SHAFT, STOPPER AXE, BUTEE	1	1	
10	689-43192-01	KNOB, STOPPER BOUTON, BUTEE DE RELEVAGE	1	1	
11	91690-30016	PIN, SPRING AGRAFFE	1	1	
12	90101-08869	BOLT BOULON	1	1	
13	6G1-43136-00	PIECE, FRICTION FRICTION	2	2	
14	6A1-43113-01	PLATE, CLAMP BRACKET PLAQUETTE, PRESSE	1	1	
15	90185-08057	NUT, SELF-LOCKING ECROU, AUTO-BLOQUANT	1	1	
16	90387-06M13	COLLAR COLLERETTE	1	1	
17	97095-06135	BOLT BOULON	1	1	
18	92990-06600	WASHER, PLATE RONDELLE, PLATE	1	1	
19	95380-06600	NUT, HEXAGON ECROU	1	1	
20	6N0-G3160-00	TILT ROD ASSY BROCHE D'INCLINAISON (ENS.)	1	1	
21	91690-30008	PIN, SPRING AGRAFFE	1	1	
22	6N0-G3165-00	PLATE, TILT LOCK TAQUET, BROCHE INCLINAISON	1	1	
23	90502-10M06	SPRING, CONICAL RESSORT, CONIQUE	1	1	
24	6N0-G3311-10-4D	BRACKET, SWIVEL 1 SUPPORT, PIVOT 1	1	1	
25	93700-06M03	NIPPLE, GREASE PION	2	2	
26	6G1-42528-00	PLATE, FRICTION PLAQUE, FRICTION	1	1	
27	90501-18M00	SPRING, COMPRESSION RESSORT, COMPRESSION	1	1	



6N00110-4140

FIG. 13 BRACKET

SUPPORT

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6M88	6N08	REMARKS REMARQUES
28	92990-08600	WASHER, PLATE RONDELLE, PLATE	1	1	
29	6G1-43373-00	SEAL, DAMPER JOINT	1	1	
30	6G1-42529-00	SCREW, FRICTION PIECE VIS, PIECE DE FRICTION	1	1	
31	6G1-44532-01	STOPPER, UPPER MOUNT PLAQUETTE	1	1	
32	97095-06010	BOLT BOULON	1	1	
33	92995-06600	WASHER RONDELLE	1	1	
34	6N0-G3614-00	PLATE, TILT LOCK ETRIER, VERROUILLAGE MARCHE AR	1	1	
35	6G1-43659-00	SHAFT, REVERSE LOCK AXE, VERROUILLAGE MARCHE AR	2	2	
36	99080-05600	CIRCLIP CIRCLIP	2	2	
37	6G1-43615-02	PLATE, TILT LOCK ETRIER, VERROUILLAGE MARCHE AR	1	1	
38	6G1-43681-00	LEVER, SHALLOW WATER DRIVE 1 LEVIER, PEU PROFOND D'EAU 1	1	1	
39	6G1-43318-01	COVER CAPUCHON	1	1	
40	90508-10M15	SPRING, TORSION RESSORT, TORSION	1	1	
41	90508-10M16	SPRING, TORSION RESSORT, TORSION	1	1	
42	90508-14M17	SPRING, TORSION RESSORT, TORSION	1	1	
43	6N0-G2731-00	CARRYING HANDLE POIGNEE DE PORTAGE	1	1	
44	97095-08016	BOLT BOULON	1	1	
45	92995-08600	WASHER RONDELLE	1	1	
46	6M8-G2511-01-4D	BRACKET, STEERING CADRE, DIRECTION	1	1	
47	6G1-44511-00-4D	COVER, UPPER MOUNT COUVERCLE, SUSPENSION SUPERIEUR	1	1	
48	6N0-G4514-00	MOUNT DAMPER, UPPER SIDE SILENT-BLOC, SUPERIEUR LATERAL	2	2	
49	6G1-44516-00	MOUNT DAMPER, UPPER FRONT SILENT-BLOC, SUPERIEUR AVANT	1	1	
50	95895-06035	BOLT, FLANGE BOULON	2	2	
51	6G1-42551-00	GROMMET PASSE-FIL	1	1	
52	6G1-42535-00	WASHER, THRUST RONDELLE DE CALAGE	2	2	
53	6G1-42537-00	BUSHING, PIVOT SHAFT COUSSINET	1	1	
54	6G1-42538-01	BUSHING, PIVOT SHAFT COUSSINET	1	1	





FIG. 13 BRACKET

SUPPORT

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6N88	6N08	REMARKS REMARQUES
55	93210-30M31	O-RING JOINT TORIQUE	3	3	
56	6N0-G4551-00-4D	HOUSING, LOWER MOUNT RUBBER BOITIER, SILENT-BLOC INFÉRIEUR	1	1	
57	6N0-G4552-00-4D	HOUSING, LOWER MOUNT RUBBER BOITIER, SILENT-BLOC INFÉRIEUR	1	1	
58	6N0-G4555-A0	MOUNT DAMPER, LOWER SIDE SILENT-BLOC, INFÉRIEUR LATÉRAL	2	2	
59	6N0-G4557-A0	MOUNT DAMPER, LOWER FRONT SILENT-BLOC, INFÉRIEUR AVANT	1	1	
60	95895-06035	BOLT, FLANGE BOULON	2	2	



FWD
6M82100-7150

FIG. 14 UPPER CASING

FOURREAU

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6M88	6N08	REMARKS REMARQUES
1	6M8-G1131-00-5B	MANIFOLD, EXT. 1 PIPE D'ECHAPPEMENT	1		
	6N0-G1131-00-5B	MANIFOLD, EXT. 1 PIPE D'ECHAPPEMENT		1	
2	6G1-41133-A0	GASKET, EXHAUST MANIFOLD 1 JOINT, PIPE D'ECHAPPEMENT	1	1	
3	97095-06020	BOLT BOULON	3	3	
4	92995-06600	WASHER RONDELLE	3	3	
5	6N0-G5111-00-4D	CASING, UPPER FOURREAU	1	1	S(17.2") S(17.2")
	6N0-G5111-10-4D	CASING, UPPER FOURREAU	1	1	L(22.2") L(22.2")
6	93604-08062	PIN, DOWEL CLAVETTE	2	2	
7	95895-06030	BOLT, FLANGE BOULON	6	6	
8	655-44147-00	BOOT, SHIFT ROD SOUFFLET, TIGE D'INVERSION	1	1	L(22.2") L(22.2")
9	90480-20M29	GROMMET PASSE-FIL	1	1	S(17.2") S(17.2")
10	6G1-45135-00	PIPE TUYAU	1	1	
11	6G1-82149-00	WIRE, LEAD 3 FIL 3	1	1	
12	97885-06008	SCREW, PAN HEAD VIS, A ENCOCHE	2	2	




FIG. 15 LOWER CASING & DRIVE 1

BOITIER D'HELICE TRANSMISSION1

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6M88	6N08	REMARKS REMARQUES
1	6M8-G5300-00-4D	LOWER UNIT ASSY UNITE INFERIEURE (ENS.)	1	1	S(17.2") S(17.2")
	6M8-G5300-10-4D	LOWER UNIT ASSY UNITE INFERIEURE (ENS.)	1	1	L(22.2") L(22.2")
2	6N0-G4150-00	SHIFT CAM ASSY CAME D'INVERSION	1	1	S(17.2") S(17.2")
	6N0-G4150-10	SHIFT CAM ASSY CAME D'INVERSION	1	1	L(22.2") L(22.2")
3	6G1-44147-00	.BOOT, SHIFT ROD .SOUFFLET, TIGE D'INVERSION	1	1	
4	6N0-G5311-00-4D	CASING, LOWER BOITIER D'HELICE	1	1	
5	6G1-45317-09	.BUSHING, DRIVE SHAFT .DOUILLE, ARBRE MOTEUR	1	1	
6	90387-14M49	COLLAR COLLERETTE	1	1	
7	93332-000U4	BEARING ROULEMENT	1	1	
8	6N0-G5251-00	ANODE ANODE	1	1	
9	97095-06016	BOLT BOULON	1	1	
10	92990-06300	WASHER, INTERNAL TOOTH RONDELLE, DENTURE INTERNE	1	1	
11	90340-08002	PLUG, STRAIGHT SCREW PLOT, FILETE DROIT	3	3	
12	90430-08020	GASKET JOINT	3	3	
13	6G1-45331-01-5B	HOUSING, BEARING FLASQUE, ROULEMENT	1	1	
14	6G1-45316-09	.BUSHING, DRIVE SHAFT .DOUILLE, ARBRE MOTEUR	1	1	
15	93101-11M23	OIL SEAL JOINT SPY	2	2	
16	97095-06030	BOLT BOULON	1	1	
17	92995-06600	WASHER RONDELLE	1	1	
18	93604-08062	PIN, DOWEL CLAVETTE	2	2	
19	6G1-45315-A0	PACKING, LOWER CASING JOINT, BOITIER D'HELICE	1	1	
20	6N0-G5361-00-4D	CAP, LOWER CASING COUVERCLE, BOITIER D'HELICE	1	1	
21	6G1-45362-09	.BUSHING .COUSSINET	1	1	
22	93306-004YH	BEARING ROULEMENT	1	1	
23	93101-15074	OIL SEAL JOINT SPY	2	2	
24	93210-49046	O-RING JOINT TORIQUE	1	1	
25	93210-53M08	O-RING JOINT TORIQUE	1	1	







FIG. 15 LOWER CASING & DRIVE 1

BOITIER D'HELICE TRANSMISSION1

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6M88	6N08	REMARKS REMARQUES
26	97095-06016	BOLT BOULON	2	2	
27	92995-06600	WASHER RONDELLE	2	2	
28	6N0-G4311-00	HOUSING, WATER PUMP CORPS, POMPE A EAU	1	1	
29	6G1-44315-A0	GASKET, WATER PUMP JOINT, POMPE A EAU	1	1	
30	6G1-44322-00	INSERT, CARTRIDGE CUVETTE	1	1	
31	6G1-44323-00	OUTER PLATE, CARTRIDGE PLAQUE EXTERIEURE	1	1	
32	647-44366-00	DAMPER, WATER SEAL JOINT, TUBE D'EAU	1	1	
33	6G1-44352-00	IMPELLER TURBINE	1	1	
34	97095-06045	BOLT BOULON	4	4	
35	6G1-44328-00	PLATE PLAQUETTE	2	2	
36	6N0-G5511-00	SHAFT, DRIVE ARBRE, MOTEUR	1	1	S(17.2") S(17.2")
	6N0-G5511-10	SHAFT, DRIVE ARBRE, MOTEUR	1	1	L(22.2") L(22.2")
37	90467-09M05	CLIP JONC	1	1	
38	90280-03024	KEY, WOODRUFF CLAVETTE, DEMI-LUNE	1	1	
39	99001-06600	CIRCLIP CIRCLIP	1	1	
40	6N0-G5551-00	PINION (13T) PIGNON D'ATTAQUE (13D)	1	1	
41	6G1-45533-00	SHIM (T:1.90MM) CALE (T:1.90MM)	1	1	UR
	6G1-45533-10	SHIM (T:2.00MM) CALE (T:2.00MM)	1	1	UR
	6G1-45533-20	SHIM (T:2.10MM) CALE (T:2.10MM)	1	1	UR
	6G1-45533-30	SHIM (T:2.20MM) CALE (T:2.20MM)	1	1	UR
42	6N0-G5560-00	GEAR 1 (27T) PIGNON 1 (27T)	1	1	
43	664-45587-01	SHIM (T:0.10MM) CALE (T:0.10MM)	1	1	UR
	664-45587-10	SHIM (T:0.12MM) CALE (T:0.12MM)	1	1	UR
	664-45587-20	SHIM (T:0.15MM) CALE (T:0.15MM)	1	1	UR
	664-45587-30	SHIM (T:0.18MM) CALE (T:0.18MM)	1	1	UR
	664-45587-40	SHIM (T:0.30MM) CALE (T:0.30MM)	1	1	UR
	664-45587-50	SHIM (T:0.40MM) CALE (T:0.40MM)	1	1	UR



24




6M80010-7180

FIG. 16 LOWER CASING & DRIVE 2

BOITIER D'HELICE TRANSMISSION2

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6M88	6N08	REMARKS REMARQUES
1	93604-08062	PIN, DOWEL CLAVETTE	2	2	
2	95895-06030	BOLT, FLANGE BOULON	4	4	
3	6G1-45214-00	COVER, WATER INLET 1 GRILLE, ENTREE D'EAU 1	1	1	
4	6G1-45215-00	COVER, WATER INLET 2 GRILLE, ENTREE D'EAU 2	1	1	
5	90152-05M03	SCREW, COUNTERSUNK VIS, TETE NOYEE	1	1	
6	90185-05002	NUT, NYLON ECROU, AUTO-BLOQUANT	1	1	
7	6N0-G4361-00	TUBE, WATER TUBE D'EAU	1	1	S(17.2") S(17.2")
	6N0-G4361-10	TUBE, WATER TUBE D'EAU	1	1	L(22.2") L(22.2")
8	6G1-44365-00	DAMPER, WATER SEAL JOINT, TUBE D'EAU	1	1	
9	6N0-G5987-00	SPACER ENTRETOISE	1	1	UR
	6N0-G5987-10	SPACER ENTRETOISE	1	1	UR
10	90201-10M01	WASHER, PLATE RONDELLE, PLATE	1	1	UR
11	90171-10M01	NUT, CASTLE ECROU, CRENELE	1	1	UR
12	91490-30020	PIN, COTTER GOUPILLE	1	1	UR
13	6G1-45941-00-EL	PROPELLER (3X8-1/2"X8-1/2"-N) HELICE (3X8-1/2"X8-1/2"-N)	1	1	UR
	6G1-45943-00-EL	PROPELLER (3X8-1/2"X7-1/2"-N) HELICE (3X8-1/2"X7-1/2"-N)	1	1	UR
	6G1-45947-00-EL	PROPELLER (3X8-1/2"X6-1/2"-N) HELICE (3X8-1/2"X6-1/2"-N)	1	1	UR
14	6G1-W4591-01-EL	PROPELLER (3X9"X7"-N) HELICE (3X9"X7"-N)	1	1	UR
	6G1-W4592-00-EL	PROPELLER (3X9"X5"-N) HELICE (3X9"X5"-N)	1	1	UR
15	6G1-45616-01	NUT, PROPELLER CONE, HELICE	1	1	UR
16	90201-10M02	WASHER, PLATE RONDELLE, PLATE	1	1	UR




FWD
66M4100-D270

FIG. 17 FUEL TANK

RESERVOIR A CARBURANT

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6M88	6N08	REMARKS REMARQUES
1	6YL-24201-05	FUEL TANK ASSY (12L) RESERVOIR A ESSENCE (ENS.) 12L	1	1	AP AP
2	6YL-24610-01	.CAP ASSY .BOUCHON	1	1	
3	6YL-24260-01	.FUEL METER ASSY .INDICATEUR DE CARBURANT	1	1	
4	90157-05M16	.SCREW, PAN HEAD .VIS, TETE TRONCONIQUE	4	4	
5	6YL-24329-00	.SEAL .JOINT	4	4	
6	6YL-24268-01	.GASKET, FUEL METER .JOINT, JAUGE A CARBURANT	1	1	
7	6YL-24306-54	FUEL PIPE COMP. 1 DURITE A ESSENCE 1	1	1	AP AP




6M80010-7190

FIG. 18 REPAIR KIT

KITS DE REPARATION

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6M88	6N08	REMARKS REMARQUES
1	6N0-W0001-A0	POWER HEAD GASKET KIT POCHETTE DE JINTS TETE MOTRICE	1	1	
2	93210-54M54	.O-RING .JOINT TORIQUE	1	1	
3	93102-20M25	.OIL SEAL .JOINT SPY	1	1	
4	93210-42159	.O-RING .JOINT TORIQUE	1	1	
5	93101-20M34	.OIL SEAL .JOINT SPY	1	1	
6	93101-12M26	.OIL SEAL .JOINT SPY	1	1	
7	6G1-41133-A0	.GASKET, EXHAUST MANIFOLD 1 .JOINT, PIPE D'ECHAPPEMENT	1	1	
8	6G1-11193-A1	.GASKET, HEAD COVER 1 .JOINT, COUVERCLE DE CULASSE 1	1	1	
9	6G1-41112-A1	.GASKET, EXHAUST INNER COVER .JOINT, PLAQUE D'ECHAPPEMENT	1	1	
10	6G1-45113-A1	.GASKET, UPPER CASING .JOINT, TUBE D'ARBRE	1	1	
11	6G1-13621-A1	.GASKET, VALVE SEAT .JOINT, SIEGE DE CLAPET	1	1	
12	6G1-13645-A1	.GASKET, MANIFOLD 1 .JOINT, TUBULURE 1	1	1	
13	6G1-14984-00	.O-RING .JOINT TORIQUE	1	1	
14	6G1-14198-A1	.GASKET .JOINT	1	1	
15	6G1-41114-A0	.GASKET, EXHAUST OUTER COVER .JOINT, COUVERCLE D'ECHAPPEMENT	1	1	
16	6N0-W0093-00	CARBURETOR REPAIR KIT KIT DE REPARATION CARBURATEUR	1	1	
17	679-14923-00	.SCREW, PILOT .VIS, RALENTI	1	1	
18	6G1-14966-00	.CAP .CAPUCHON	1	1	
19	6G1-14126-00	.GASKET .JOINT	1	1	
20	676-14966-00	.CAP .CAPUCHON	1	1	
21	6G1-14984-00	.O-RING .JOINT TORIQUE	1	1	
22	97980-04114	.SCREW, WITH WASHER .VIS, AVEC RONDELLE	4	4	
23	6G1-14985-00	.FLOAT .FLOTTEUR	1	1	
24	6G1-14546-01	.VALVE, NEEDLE .POINTEAU	1	1	
25	676-14186-00	.PIN, FLOAT .AXE, FLOTTEUR	1	1	
26	688-14548-00	.PIN, FLOAT ARM .AXE, BRAS DE FLOTTEUR	1	1	
27	6N0-W0001-C0	LOWER UNIT GASKET KIT POCHETTE DE JOINTS EMBASE	1	1	



6M80010-7190

FIG. 18 REPAIR KIT

KITS DE REPARATION

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6M88	6N08	REMARKS REMARQUES
28	90430-08020	.GASKET .JOINT	3	3	
29	93101-11M23	.OIL SEAL .JOINT SPY	2	2	
30	93101-15074	.OIL SEAL .JOINT SPY	2	2	
31	93210-49046	.O-RING .JOINT TORIQUE	1	1	
32	93210-53M08	.O-RING .JOINT TORIQUE	1	1	
33	6G1-44315-A0	.GASKET, WATER PUMP .JOINT, POMPE A EAU	1	1	
34	647-44366-00	.DAMPER, WATER SEAL .JOINT, TUBE D'EAU	1	1	
35	6G1-45315-A0	.PACKING, LOWER CASING .JOINT, BOITIER D'HELICE	1	1	
36	6N0-W0078-A0	WATER PUMP REPAIR KIT KIT DE REPARATION DE LA POMPE	1	1	
37	6G1-44315-A0	.GASKET, WATER PUMP .JOINT, POMPE A EAU	1	1	
38	6G1-44322-00	.INSERT, CARTRIDGE .CUVETTE	1	1	
39	6G1-44323-00	.OUTER PLATE, CARTRIDGE .PLAQUE EXTERIEURE	1	1	
40	647-44366-00	.DAMPER, WATER SEAL .JOINT, TUBE D'EAU	1	1	
41	6G1-44352-00	.IMPELLER .TURBINE	1	1	
42	6G1-44328-00	.PLATE .PLAQUETTE	2	2	
43	97095-06045	.BOLT .BOULON	4	4	
44	6N0-W0078-0A	CHROME PUMP KIT KIT DE POMPE A EAU CHROMEE	1	1	
45	6G1-44322-40	.INSERT, CARTRIDGE .CUVETTE	1	1	
46	6G1-44323-40	.OUTER PLATE, CARTRIDGE .PLAQUE EXTERIEURE	1	1	

PART NO. N° PIECES	REF. NO.
6G1-11193-A1	2 - 20
	18 - 8
6G1-11681-00	3 - 6
6E5-12411-02	2 - 7
6E5-12412-00	2 - 8
6G1-13610-01	4 - 1
6G1-13621-A1	4 - 3
	18 - 11
6G1-13645-A1	4 - 5
	18 - 12
6G1-14126-00	5 - 6
	18 - 19
663-14159-00	5 - 23
676-14186-00	5 - 22
	18 - 25
6G1-14198-A1	4 - 6
	18 - 14
6G1-14301-01	5 - 1
6H6-14301-01	5 - 1
6G1-14398-00	5 - 18
6G1-14497-81	12 - 7
63V-14523-00	5 - 12
6G1-14527-00	5 - 5
6G1-14546-01	5 - 21
	18 - 24
688-14548-00	5 - 25
	18 - 26
679-14555-00	5 - 3
679-14923-00	5 - 2
	18 - 17
676-14943-26	5 - 16
6G1-14947-00	5 - 15
6H6-14947-00	5 - 15
6G1-14948-05	5 - 7
676-14966-00	5 - 8
	18 - 20
6G1-14966-00	5 - 4
	18 - 18
6G1-14980-01	5 - 14
6G1-14984-00	5 - 13
	18 - 13
	18 - 21
6G1-14985-00	5 - 20
	18 - 23
6G1-14992-00	5 - 19
6G1-15359-01-94	2 - 9
6G1-15396-02-5B	2 - 13
6G1-15705-00	7 - 10

PART NO. N° PIECES	REF. NO.
6G1-15717-00	7 - 5
677-15741-01	7 - 17
6G1-15746-81	7 - 25
6G1-15747-80	7 - 35
656-15748-00	7 - 30
6G1-15755-00	7 - 12
6G1-15761-00	1 - 5
6G1-15762-00	7 - 15
6G1-15764-00	7 - 26
6G1-15774-81	7 - 29
6G1-15779-00	7 - 13
6YL-24201-05	17 - 1
646-24251-02	6 - 4
6YL-24260-01	17 - 3
6YL-24268-01	17 - 6
6G1-24304-02	6 - 1
6YL-24306-54	17 - 7
6YL-24329-00	17 - 5
6G1-24411-00	5 - 33
6G1-24412-01	5 - 32
6G1-24421-00	5 - 35
6G1-24431-01	5 - 34
6G1-24432-00	5 - 30
6G1-24452-00	5 - 29
6G1-24471-00	5 - 31
6YL-24610-01	17 - 2
6G1-26326-00	10 - 17
6G1-2811G-00	6 - 10
6G1-41112-A1	2 - 23
	18 - 9
6G1-41113-01-1S	2 - 24
6G1-41114-A0	2 - 26
	18 - 15
6G1-41133-A0	14 - 2
	18 - 7
6G1-41211-00	12 - 12
6E9-41237-00	12 - 11
662-41237-01	12 - 10
6G1-41238-00	12 - 9
6G1-41256-00	4 - 12
661-41262-02	4 - 14
	12 - 13
6G1-41271-00	4 - 13
6G1-41283-01	12 - 3
6G1-41612-00	9 - 2
6G1-41615-01	9 - 6
6G1-41631-00	12 - 1
6G1-41638-00	12 - 2

NUMERICAL INDEX
INDEX NUMERIQUE

PART NO. N° PIECES	REF. NO.
6G1-41661-00	12 - 4
6G1-41662-01-94	12 - 19
6G1-42125-01	11 - 9
6G1-42126-00	11 - 10
6G1-42131-02	11 - 6
6G1-42138-01	11 - 20
6E0-42159-02	11 - 21
6G1-42528-00	13 - 26
6G1-42529-00	13 - 30
6G1-42535-00	13 - 52
6G1-42537-00	13 - 53
6G1-42538-01	13 - 54
6G1-42551-00	13 - 51
6G1-42615-00	1 - 6
6G1-42647-00	1 - 7
6G1-42724-00	10 - 12
6G1-42725-00	10 - 13
6G1-42726-00	10 - 14
6G1-42727-00	10 - 15
6G1-42748-00	10 - 16
6E7-42791-10	10 - 25
6AH-42794-40	10 - 27
6AH-42794-50	10 - 28
6E0-42816-00	10 - 4
6A1-43113-01	13 - 14
620-43114-00	13 - 5
6G1-43136-00	13 - 13
689-43191-00	13 - 9
689-43192-01	13 - 10
6G1-43318-01	13 - 39
6G1-43373-00	13 - 29
6G1-43615-02	13 - 37
6G1-43659-00	13 - 35
6G1-43681-00	13 - 38
6G1-44116-01	12 - 21
6G1-44121-02-94	12 - 18
6G1-44125-80	7 - 32
655-44147-00	14 - 8
6G1-44147-00	15 - 3
6G1-44194-00	9 - 8
6G1-44315-A0	15 - 29
	18 - 33
	18 - 37
6G1-44322-00	15 - 30
	18 - 38
6G1-44322-40	18 - 45
6G1-44323-00	15 - 31
	18 - 39

PART NO. N° PIECES	REF. NO.
6G1-44323-40	18 - 46
6G1-44328-00	15 - 35
	18 - 42
6G1-44352-00	15 - 33
	18 - 41
6G1-44365-00	16 - 8
647-44366-00	15 - 32
	18 - 34
	18 - 40
6G1-44511-00-4D	13 - 47
6G1-44516-00	13 - 49
6G1-44532-01	13 - 31
6G1-45113-A1	2 - 27
	18 - 10
6G1-45135-00	14 - 10
6G1-45214-00	16 - 3
6G1-45215-00	16 - 4
6G1-45315-A0	15 - 19
	18 - 35
6G1-45316-09	15 - 14
6G1-45317-09	15 - 5
6G1-45331-01-5B	15 - 13
6G1-45362-09	15 - 21
6G1-45533-00	15 - 41
6G1-45533-10	15 - 41
6G1-45533-20	15 - 41
6G1-45533-30	15 - 41
647-45567-00	15 - 46
664-45587-01	15 - 43
664-45587-10	15 - 43
664-45587-20	15 - 43
664-45587-30	15 - 43
664-45587-40	15 - 43
664-45587-50	15 - 43
664-45587-60	15 - 43
6G1-45611-01	15 - 52
6G1-45616-01	16 - 15
6G1-45631-00	15 - 47
6G1-45632-00	15 - 48
654-45633-00	15 - 49
6G1-45635-00	15 - 51
6G1-45941-00-EL	16 - 13
6G1-45943-00-EL	16 - 13
6G1-45947-00-EL	16 - 13
6E7-81303-A0	8 - 6
6J8-81960-00	9 - 18
6AH-81994-40	4 - 15
6AH-81994-50	4 - 16

PART NO. N° PIECES	REF. NO.
6AH-81995-40	7 - 36
6AH-81995-50	7 - 37
6E5-82148-00	13 - 2
6G1-82149-00	14 - 11
6M8-82361-00	9 - 11
6M8-82362-00	9 - 12
6G1-82370-21	9 - 13
682-82556-00	10 - 23
6E9-82575-02	10 - 22
689-8257Y-00	10 - 24
6G1-83557-00	9 - 17
6G1-85509-70	8 - 3
6G1-85515-70	8 - 15
6E7-85520-70	8 - 4
696-85540-12	9 - 14
6G1-85548-70	8 - 12
6G1-85550-71	8 - 1
6G1-85560-F0	8 - 2
6G1-85570-02	9 - 9
6E7-85580-70	8 - 5
6N0-E1191-00-1S	2 - 19
6N0-E1400-00	3 - 1
6N0-E1412-00	3 - 2
6N0-E1422-00	3 - 3
6N0-E1432-00	3 - 4
6N0-E1442-00	3 - 5
6N0-E1515-00	3 - 11
6N0-E1603-00	3 - 16
6N0-E1631-00-98	3 - 15
6N0-E1633-00	3 - 18
6N0-E1651-00	3 - 10
6N0-E3641-00-94	4 - 4
6M8-E4417-00	4 - 8
6M8-E4418-00	4 - 9
6N0-E5100-00-1S	2 - 2
6M8-E5710-03	7 - 1
6N0-E5711-80-94	7 - 2
6M8-E5714-00	7 - 3
6N0-E5723-00-94	7 - 19
6N0-E5758-00	7 - 14
6N0-E5770-90	7 - 28
6N0-E5771-00-94	7 - 21
6N0-E5772-00-94	7 - 22
6N0-F6301-10	11 - 23
6N0-F8100-00	6 - 8
6N0-F8170-00	6 - 9
6N0-F8176-00	10 - 26
6L8-F8193-00	6 - 13

PART NO. N° PIECES	REF. NO.
6M8-F8199-7B-D0	6 - 14
6M8-F8199-7B-E0	6 - 14
6M8-F8199-7B-F0	6 - 14
6M8-F8199-7B-G0	6 - 14
6M8-F8199-7B-H0	6 - 14
6M8-F8199-7B-S0	6 - 14
6M8-F8199-8C-K0	6 - 15
6M8-F8199-8C-L0	6 - 15
6M8-F8199-8C-M0	6 - 15
6M8-F8199-8C-N0	6 - 15
6M8-F8199-8C-P0	6 - 15
6M8-F8199-8C-R0	6 - 15
6N0-G1111-00-1S	2 - 22
6M8-G1131-00-5B	14 - 1
6N0-G1131-00-5B	14 - 1
6N0-G1611-00	9 - 1
6N0-G1613-00	9 - 3
6M8-G2111-11-4D	11 - 1
6M4-G2119-00	11 - 12
6N0-G2137-10	11 - 14
6N0-G2177-00	11 - 13
6M8-G2511-01-4D	13 - 46
6M8-G2610-30-4D	1 - 1
6N0-G2610-30-4D	1 - 1
6N0-G2613-00-4D	1 - 2
6N0-G2651-00	1 - 8
6M8-G2677-20	1 - 11
6N0-G2677-20	1 - 11
6M8-G2678-11	1 - 12
6N0-G2678-11	1 - 12
6N0-G2711-00-4D	10 - 1
6N0-G2716-00	10 - 21
6N0-G2719-80	10 - 8
6N0-G2731-00	13 - 43
6N0-G2767-00	10 - 9
6N0-G2815-00-4D	10 - 2
6M8-G3111-02-4D	13 - 1
6M8-G3112-01-4D	13 - 4
6N0-G3116-00	13 - 6
6L8-G3118-01	13 - 7
6N0-G3160-00	13 - 20
6N0-G3165-00	13 - 22
6N0-G3311-10-4D	13 - 24
6N0-G3614-00	13 - 34
6N0-G4110-00	12 - 23
6N0-G4111-00	12 - 14
6N0-G4145-00	12 - 26
6N0-G4145-10	12 - 26

NUMERICAL INDEX
INDEX NUMERIQUE

PART NO. N° PIECES	REF. NO.
6N0-G4146-00	12 - 27
6N0-G4146-10	12 - 27
6N0-G4150-00	15 - 2
6N0-G4150-10	15 - 2
60R-G4191-00	1 - 13
6N0-G4311-00	15 - 28
6N0-G4361-00	16 - 7
6N0-G4361-10	16 - 7
6N0-G4514-00	13 - 48
6N0-G4551-00-4D	13 - 56
6N0-G4552-00-4D	13 - 57
6N0-G4555-A0	13 - 58
6N0-G4557-A0	13 - 59
6N0-G5111-00-4D	14 - 5
6N0-G5111-10-4D	14 - 5
6N0-G5251-00	15 - 8
6M8-G5300-00-4D	15 - 1
6M8-G5300-10-4D	15 - 1
6N0-G5311-00-4D	15 - 4
6N0-G5361-00-4D	15 - 20
6N0-G5511-00	15 - 36
6N0-G5511-10	15 - 36
6N0-G5551-00	15 - 40
6N0-G5560-00	15 - 42
6N0-G5571-00	15 - 44
6N0-G5987-00	16 - 9
6N0-G5987-10	16 - 9
6N0-H1915-00	9 - 19
6N0-H2553-10	9 - 22
6N0-W0001-A0	18 - 1
6N0-W0001-C0	18 - 27
6G1-W0004-00	4 - 2
6N0-W0078-0A	18 - 44
6N0-W0078-A0	18 - 36
6N0-W0093-00	18 - 16
6G1-W4591-01-EL	16 - 14
6G1-W4592-00-EL	16 - 14
6N0-WE090-01-1S	2 - 1
6N0-WG070-10	1 - 10
90101-08869	13 - 12
90105-06037	2 - 25
90105-06039	2 - 21
90105-06M14	12 - 20
90105-06M25	2 - 5
90105-06M26	2 - 4
90105-06M29	7 - 20
90109-06M17	12 - 28
90116-08016	11 - 7

PART NO. N° PIECES	REF. NO.
90149-05M02	10 - 10
90149-05M13	11 - 18
90152-05M03	16 - 5
90157-05M16	17 - 4
90170-10113	8 - 18
90171-10M01	16 - 11
90185-05002	16 - 6
90185-08057	11 - 8
	13 - 15
90201-06M30	7 - 7
90201-10126	8 - 19
90201-10M01	16 - 10
90201-10M02	11 - 17
	16 - 16
90201-15M89	15 - 45
90201-41303	3 - 14
90202-36M55	11 - 3
90206-12052	10 - 5
90206-36M21	11 - 2
90209-18112	3 - 9
90243-04M01	13 - 8
90266-04M00	1 - 9
90269-02M09	11 - 15
90280-03024	15 - 38
90280-04M06	8 - 17
90340-08002	15 - 11
90386-08032	11 - 19
90386-12M45	10 - 3
90386-33M96	11 - 4
90386-34M97	11 - 5
90386-44M42	8 - 16
90387-06M13	13 - 16
90387-06M52	10 - 19
90387-06M70	4 - 10
90387-14M49	15 - 6
90387-22M50	2 - 6
90430-08020	15 - 12
	18 - 28
90445-09220	6 - 6
90445-09221	6 - 5
90467-08004	6 - 7
90467-09M05	15 - 37
90480-15M31	10 - 18
90480-20M29	14 - 9
90501-10227	7 - 31
90501-10326	5 - 11
90501-12M38	15 - 50
90501-18M00	13 - 27

PART NO. N° PIECES	REF. NO.
90501-23215	11 - 16
90502-10M06	13 - 23
90508-10M15	13 - 40
90508-10M16	13 - 41
90508-14M17	13 - 42
90510-08M03	7 - 4
91490-16010	11 - 11
91490-30020	16 - 12
91609-20008	3 - 13
91690-20010	12 - 24
91690-30008	13 - 21
91690-30016	13 - 11
92902-04100	8 - 14
92902-05100	8 - 8
	8 - 11
92990-04100	5 - 10
92990-05100	12 - 6
92990-05600	7 - 34
	12 - 17
	12 - 25
92990-06300	15 - 10
92990-06600	13 - 18
92990-08600	13 - 28
92995-05600	9 - 5
92995-06600	1 - 4
	2 - 18
	6 - 3
	6 - 12
	7 - 24
	9 - 21
	13 - 33
	14 - 4
	15 - 17
	15 - 27
	13 - 45
	15 - 15
	18 - 29
	2 - 16
	18 - 6
	15 - 23
	18 - 30
	2 - 15
	18 - 5
	2 - 11
	18 - 3
	12 - 15
	13 - 55
	2 - 14

PART NO. N° PIECES	REF. NO.
93210-42159	18 - 4
93210-49046	15 - 24
	18 - 31
93210-53M08	15 - 25
	18 - 32
93210-54M54	2 - 10
	18 - 2
93306-004YH	15 - 22
93306-204U0	3 - 7
93310-112V0	3 - 17
93310-418V1	3 - 8
93332-000U4	15 - 7
93430-06M02	7 - 9
93440-47055	3 - 12
93450-13022	3 - 19
93604-08062	2 - 3
	14 - 6
	15 - 18
	16 - 1
	13 - 25
	2 - 28
	7 - 8
	5 - 27
	10 - 11
	12 - 29
	13 - 19
	10 - 7
	9 - 7
	9 - 16
	12 - 8
	12 - 22
	7 - 16
	7 - 18
	9 - 15
	10 - 20
	7 - 27
	9 - 10
	14 - 7
	16 - 2
	13 - 50
	13 - 60
	4 - 7
	2 - 12
	7 - 6
	7 - 23
	13 - 32
	6 - 11
	9 - 20

PART NO. N° PIECES	REF. NO.
97095-06016	1 - 3
	2 - 17
	15 - 9
	15 - 26
97095-06020	14 - 3
97095-06025	6 - 2
97095-06030	15 - 16
97095-06045	15 - 34
	18 - 43
97095-06135	13 - 17
97095-08016	13 - 44
97780-50514	4 - 11
97802-04008	8 - 13
97802-05016	8 - 9
97802-05020	8 - 10
97802-05025	8 - 7
97880-04010	5 - 9
97880-05010	12 - 5
97880-05016	7 - 33
	12 - 16
97885-05010	9 - 4
97885-05012	11 - 22
97885-06008	13 - 3
	14 - 12
97885-06030	10 - 6
97980-04114	5 - 17
	18 - 22
97980-04125	5 - 28
98580-04008	5 - 24
98980-03006	5 - 26
99001-06600	15 - 39
99080-05600	13 - 36