




PARTS CATALOGUE CATALOGUE DE PIECES DETACHEES

20DMHO'11 (6L3A)

25NMHO'11 (6L2A)



YAMAHA
GENUINE
Parts & Accessories

1K6L2-300F1

()

20DMHO/25NMHO
PARTS CATALOGUE
©2010 by Yamaha Motor Co., Ltd.
1st edition, July 2010
All rights reserved.
Any reprinting or unauthorized use
without the written permission of
Yamaha Motor Co., Ltd.
is expressly prohibited.
Printed in Japan.

20DMHO/25NMHO
CATALOGUE DE PIECES DETACHEES
©2010 par Yamaha Motor Co., Ltd.
1^{re} édition, juillet 2010
Tous droits réservés
Toute réimpression ou utilisation
non autorisée sans la permission écrite
de la Yamaha Motor Co., Ltd.
est formellement interdite.
Imprimé au Japon

FOREWORD

This Parts Catalogue is related to the parts for the model(s) on the cover page. When you are ordering replacement parts, please refer to this Parts Catalogue and quote both part numbers and part names correctly.

1. Modifications or additions which have been made after the issue of the Parts Catalogue will be announced in the Parts News.
It is advisable that you make the necessary corrections to the Parts Catalogue according to the Parts News.

2. Abbreviations

The following abbreviations are used in this Parts Catalogue.

“UR” Use specified parts number.

“UN” Use as many as needed.

“AP” Alternate Parts

“LM” Locally Made (Parts need to be ordered locally)

“F#” Frame No. (Applicable machine No.)

“O/S” Over Size

3. The number of components for assembly

- Parts, which are to be supplied in an assembly, are listed with a dot (.) in front of the part name as shown below.
- The numeral appearing to the right of each component part indicates the quantity of parts for each assembly unit.

PART NO.	DESCRIPTION	Q'TY	REMARKS
2F5-83310-60	FRONT FLASHER LIGHT ASSY	2	
115-83311-60	.BULB (6V-18W)	1	

4. Applicable colours of graphics are represented in the “REMARKS” as shown below.



PART NO.	DESCRIPTION	Q'TY	REMARKS
2N4-24110-00-X5	FUEL TANK COMP.	2	MXR
3J1-24240-10	.GRAPHIC, FUEL TANK	1	FOR MXR

5. Note that the illustrations for reference in finding parts numbers are not to be used for assembling. When assembling, please use the applicable service manual.

6. The asterisk (*) before a reference number indicates modified items after the first edition.

7. Applicable Serial No.

Engine Serial No.



8. Applicable Engine Starting Serial No.

Model	Serial No.	Model	Serial No.
20D	6L3K-1010349	25N	6L2K-1048753

9. Applicable Colour Code

Abbreviation	Colour Name	Colour Code
DBNM2	DARK BLUISH GRAY METALLIC 2	004D

10. Quantity Column Information

Column No.	Name Of Q'ty Column	Applicable Model
1	6L3A	20DMHO
2	6L2A	25NMHO

AVANT-PROPOS

Ce catalogue de pièces détachées concerne les pièces pour le(s) modèle(s) indiqué(s) sur la page de couverture. Lorsque vous commandez des pièces de rechange, veuillez vous référer à ce catalogue de pièces détachées et indiquer clairement les numéros et les noms des pièces détachées.

1. Les modifications ou ajouts ayant été effectués après la parution du catalogue de pièces détachées seront décrits dans les Bulletins d'information concernant les pièces détachées.
Il est recommandé que vous apportiez les corrections nécessaires au catalogue des pièces détachées en vous référant aux Bulletins d'information.

2. Abréviations

Dans ce catalogue, les abréviations suivantes sont utilisées:

- “UR” Utiliser le numéro de pièces spécifié.
- “UN” Utiliser autant que nécessaire.
- “AP” Pièces de substitution
- “LM” Fabrication locale (les pièces doivent être commandées localement.)
- “F#” N° de cadre (applicable au N° de série)
- “O/S” Surdimensionné

3. Nombre de pièces d'un assemblage

- Les pièces fournies comme composants d'un assemblage sont précédées d'un point (.) de la manière indiquée ci-dessous.
- Le chiffre apparaissant à la droite de chaque composant indique la quantité de pièces pour chaque unité d'assemblage.

N° PIECES	DESCRIPTION	QTE	REMARQUES
2F5-83310-60	ENS. CLIGNOTANT AVANT	2	
115-83311-60	.AMPOULE (6V-18W)	1	

4. Les couleurs concernant les graphiques sont indiquées dans la colonne “REMARQUES”, comme indiqué ci-dessous.



N° PIECES	DESCRIPTION	QTE	REMARQUES
2N4-24110-00-X5	RESERVOIR A ESSENCE.	2	MXR
3J1-24240-10	.GRAPHIQUE	1	POUR MXR

5. Veuillez noter que les illustrations sont indiquées à titre de référence pour trouver les numéros de pièces, non pour être utilisées lors de l'assemblage. Lors de l'assemblage, veuillez utiliser le manuel d'entretien adéquat.

6. L'astérisque (*) placé devant un numéro de référence indique des éléments qui ont été modifiés après la première édition.

7. N° de série applicable

N° de Série du moteur



8. N° de série initial du moteur applicable

Modèle	N° de série	Modèle	N° de série
20D	6L3K-1010349	25N	6L2K-1048753

9. Code couleur applicable

Abréviation	Nom de la couleur	Code couleur
DBNM2	DARK BLUISH GRAY METALLIC 2	004D

10. Informations relatives à la colonne Quantité

N° de la colonne	Nom de la colonne Qté	Modèle applicable
1	6L3A	20DMHO
2	6L2A	25NMHO

CONTENTS

TOP COWLING	1
CYLINDER & CRANKCASE	2
CRANKSHAFT & PISTON	4
INTAKE	6
CARBURETOR	7
OIL PUMP	9
FUEL	11
STARTER	12
GENERATOR	14
ELECTRICAL	15
BOTTOM COWLING	16
STEERING	18
CONTROL	20
BRACKET 1	22
BRACKET 2	24
UPPER CASING	26
LOWER CASING & DRIVE 1	27
LOWER CASING & DRIVE 2	30
FUEL TANK 1	32
FUEL TANK 2	33
REPAIR KIT 1	34
REPAIR KIT 2	35

INDEX


NUMERICAL INDEX	36
-----------------------	----

TABLE DES MATIERES

CAPOT SUPERIEUR	1
CYLINDRE & CARTER	2
VILEBREQUIN & PISTON	4
ADMISSION	6
CARBURATEUR	7
POMPE A HUILE	9
CARBURANT	11
DEMARREUR	12
GENERATRICE	14
ELECTRIQUE	15
CAPOT INFERIEUR	16
DIRECTION	18
COMMANDE	20
SUPPORT 1	22
SUPPORT 2	24
FOURREAU	26
BOITIER D'HELICE TRANSMISSION1	27
BOITIER D'HELICE TRANSMISSION2	30
RESERVOIR A CARBURANT 1	32
RESERVOIR A CARBURANT 2	33
KITS DE REPARATION 1	34
KITS DE REPARATION 2	35

INDEX

INDEX NUMERIQUE	36
-----------------------	----



FWD
6L21300-2010

FIG. 1 TOP COWLING

CAPOT SUPERIEUR

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6L3A	6L2A	REMARKS REMARQUES
1	6L2-42610-30	TOP COWLING ASSY CAPOT (ENS.)		1	
	6L3-42610-30	TOP COWLING ASSY CAPOT (ENS.)	1		
2	6L2-42615-00	.SEAL .JOINT	1	1	
3	6G1-42651-71	.HOOK .CROCHET	1	1	
4	6L2-42647-00	.HOLDER, CLAMP BAND .SUPPORT, SANDOW DE SERRAGE	1	1	
5	90266-04M00	.RIVET .RIVET	2	2	
6	6L2-42613-01-4D	.MOLDING, AIR DUCT .MANCHON A AIR	1	1	
7	97095-06016	.BOLT .BOULON	4	4	
8	92995-06600	.WASHER .RONDELLE	4	4	
9	6L2-W0070-13	.GRAPHIC SET .JEU DIEMBLEMES	1	1	
10	6L2-42677-20	.GRAPHIC, FRONT .ADHESIF, AVANT		1	
	6L3-42677-20	.GRAPHIC, FRONT .ADHESIF, AVANT	1		
11	6L2-42678-11	.GRAPHIC, REAR .ADHESIF, ARRIERE		1	
	6L3-42678-11	.GRAPHIC, REAR .ADHESIF, ARRIERE	1		
12	90266-04M04	.RIVET .RIVET	2	2	
13	6L2-13437-00	.MARK, CAUTION .MAKER	1	1	




FIG. 2 CYLINDER & CRANKCASE

CYLINDRE & CARTER

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6L3A	6L2A	REMARKS REMARQUES
1	6L2-W0090-12-1S	CRANK CYLINDER ASSY EMBIELLAGE CYLINDRE (ENS.)	1	1	O/I O/I
2	6L2-15100-10	CRANKCASE ASSY CARTER DE MOTEUR COMPLET	1	1	O/I O/I
3	6E5-11372-01	.NIPPLE, HOSE .RACCORD, TUYAU	4	4	
4	90445-07M15	HOSE (L40) DURITE (L40)	2	2	
5	90467-06016	CLIP JONC	4	4	
6	93604-12M07	PIN, DOWEL CLAVETTE	4	4	
7	95617-08645	BOLT, STUD GOIJON	2	2	
8	90201-08086	WASHER, PLATE RONDELLE, PLATE	2	2	
9	95333-08600	NUT ECROU	2	2	
10	90119-08M65	BOLT, WITH WASHER BOULON, AVEC RONDELLE	4	4	
11	90119-06M14	BOLT, WITH WASHER BOULON, AVEC RONDELLE	4	4	
12	6J8-11325-00	ANODE ANODE	1	1	
13	6H3-11327-00-94	COVER, ANODE COUVERCLE ANODE	1	1	
14	6H3-11328-00	GROMMET, ANODE PASSE-FIL	1	1	
15	97013-06016	BOLT BOULON	1	1	
16	92903-06600	WASHER, PLATE RONDELLE, PLATE	1	1	
17	6L2-11111-01-1S	HEAD, CYLINDER 1 CULASSE	1	1	
18	6L2-11181-A3	GASKET, CYLINDER HEAD 1 JOINT, DE CULASSE 1	1	1	
19	6L2-11191-00-1S	COVER, CYLINDER HEAD 1 COUVERCLE, CULASSE 1	1	1	
20	6L2-11193-A1	GASKET, HEAD COVER 1 JOINT, COUVERCLE DE CULASSE 1	1	1	
21	90119-08M91	BOLT, WITH WASHER BOULON, AVEC RONDELLE	10	10	
22	90119-06023	BOLT, WITH WASHER BOULON, AVEC RONDELLE	2	2	
23	6E5-12411-30	THERMOSTAT THERMOSTAT	1	1	
24	688-12412-00	.SEAL, THERMOSTAT .JOINT, THERMOSTAT	1	1	
25	6H4-12413-00-1S	COVER, THERMOSTAT COUVERCLE, THERMOSTAT	1	1	
26	6J8-12414-A0	GASKET, COVER JOINT, COUVERCLE	1	1	
27	90119-06MA3	BOLT, WITH WASHER BOULON, AVEC RONDELLE	2	2	





FIG. 2 CYLINDER & CRANKCASE

CYLINDRE & CARTER

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6L3A	6L2A	REMARKS REMARQUES
28	6L2-41111-00-1S	INNER COVER, EXHAUST PLAQUE, ECHAPPEMENT	1	1	
29	6L2-41112-A3	GASKET, EXHAUST INNER COVER JOINT, PLAQUE D'ECHAPPEMENT	1	1	
30	6L2-41113-00-1S	OUTER COVER, EXHAUST COUVERCLE, ECHAPPEMENT	1	1	
31	676-11372-00	.NIPPLE, HOSE .RACCORD, TUYAU	1	1	
32	6L2-41114-A1	GASKET, EXHAUST OUTER COVER JOINT, COUVERCLE D'ECHAPPEMENT	1	1	
33	90119-06MA4	BOLT, WITH WASHER BOULON, AVEC RONDELLE	10	10	
34	90445-10M40	HOSE (L330) DURITE (L330)	1	1	
35	6L2-45113-A2	GASKET, UPPER CASING JOINT, TUBE D'ARBRE	1	1	
36	94702-00271	PLUG, SPARK (NGK BR7HS-10) BOUGIE D'ALLUMAGE(NGK BR7HS-10)	2	2	




6L20300-1030

FIG. 3 CRANKSHAFT & PISTON

VILEBREQUIN & PISTON

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6L3A	6L2A	REMARKS REMARQUES
1	6L2-11400-10	CRANKSHAFT ASSY VILEBREQUIN COMPLET	1	1	O/I O/I
2	6L2-11412-00	.CRANK 1 .MASSOLOTTE DE VILEBREQUIN 1	1	1	
3	6L2-11422-00	.CRANK 2 .MASSOLOTTE DE VILEBREQUIN 2	1	1	
4	6L2-11432-00	.CRANK 3 .MASSOLOTTE DE VILEBREQUIN 3	1	1	
5	6L2-11442-00	.CRANK 4 .MASSOLOTTE DE VILEBREQUIN 4	1	1	
6	93311-632U7	.BEARING .ROULEMENT	1	1	
7	93102-26M27	.OIL SEAL .JOINT SPY	1	1	
8	93210-42159	.O-RING .JOINT TORIQUE	1	1	
9	93306-305U3	.BEARING .ROULEMENT	2	2	
10	6L2-11651-00	.ROD, CONNECTING .BIELLE NUE	2	2	
11	6L2-11681-00	.PIN, CRANK 1 .MANETON, VILEBREQUIN 1	2	2	
12	93310-424W9	.BEARING .ROULEMENT	2	2	
13	90209-24M15	.WASHER .RONDELLE	4	4	
14	6L2-11515-00	.SEAL, LABYRINTH 1 .JOINT, LABYRINTHE 1	1	1	
15	91690-30010	.PIN, SPRING .AGRAFFE	1	1	
16	6J8-11536-00	.GEAR, DRIVE .ENGRENAGE, MENANT	1	1	O/I O/I
17	90387-28M00	.COLLAR .COLLERETTE	1	1	
18	90201-50306	WASHER, PLATE .RONDELLE, PLATE	1	1	
19	6L2-11631-00-97	PISTON (STD) PISTON (STD)	2	2	
	6L2-11635-00	PISTON (0.25MM O/S) PISTON (0.25MM O/S)	2	2	AP AP
	6L2-11636-00	PISTON (0.50MM O/S) PISTON (0.50MM O/S)	2	2	AP AP
20	6L2-11610-00	PISTON RING SET (STD) JEU DE SEGMENTS (STD)	2	2	
	6L2-11610-10	PISTON RING SET (0.25MM O/S) JEU DE SEGMENTS (0.25MM O/S)	2	2	AP AP
	6L2-11610-20	PISTON RING SET (0.50MM O/S) JEU DE SEGMENTS (0.50MM O/S)	2	2	AP AP
21	648-11633-00	PIN, PISTON AXE, PISTON	2	2	
22	93602-18M12	PIN, DOWEL GOUJON	62	62	
23	93450-20026	CIRCLIP CIRCLIP, TYPE S	4	4	



6L20300-1030

FIG. 3 CRANKSHAFT & PISTON

VILEBREQUIN & PISTON

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6L3A	6L2A	REMARKS REMARQUES
24	90201-18522	WASHER, PLATE RONDELLE, PLATE	4	4	
25	6L2-15396-00-1S	HOUSING, OIL SEAL LOGEMENT DE JOINT SPY	1	1	
26	93102-25142	OIL SEAL JOINT SPY	1	1	
27	93101-13M37	OIL SEAL JOINT SPY	1	1	
28	93210-56M80	O-RING JOINT TORIQUE	1	1	
29	97095-06016	BOLT BOULON	2	2	
30	92995-06600	WASHER RONDELLE	2	2	




FIG. 4 INTAKE

ADMISSION

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6L3A	6L2A	REMARKS REMARQUES
1	6L2-13610-00	REED VALVE ASSY CLAPET COMPLET	2	2	
2	6L2-W0004-00	.REED SET .JEU DE CLAPETS	1	1	
3	97980-05216	SCREW, WITH WASHER VIS, AVEC RONDELLE	4	4	
4	6L2-13641-10	MANIFOLD 1 TUBULURE 1	1	1	O/I O/I
5	676-14485-00	.PIPE, JOINT .DURITE	2	2	
6	6L2-13621-00	GASKET, VALVE SEAT JOINT, SIEGE DE CLAPET	1	1	
7	97013-06025	BOLT BOULON	6	6	
8	92903-06600	WASHER, PLATE RONDELLE, PLATE	6	6	
9	90445-09012	HOSE (L70) DURITE (L70)	1	1	
10	90467-08004	CLIP JONC	2	2	
11	6L2-14198-00	GASKET JOINT	2	2	
12	6L2-14417-00-94	COVER 1 COUVERCLE 1	1	1	
13	6L2-14476-00	SEAL JOINT SPY	1	1	
14	93210-35M86	O-RING JOINT TORIQUE	2	2	
15	97013-05012	BOLT BOULON	4	4	
16	92903-05600	WASHER, PLATE RONDELLE, PLATE	4	4	
17	97513-06585	BOLT, WITH WASHER VIS HEXAGONAL AVC RONDELLE	4	4	
18	6L2-14476-11	SEAL JOINT SPY	1	1	
19	6L2-14418-00	COVER 2 COUVERCLE 2	1	1	
20	97980-05216	SCREW, WITH WASHER VIS, AVEC RONDELLE	4	4	
21	6J8-41259-00	ROD, CHOKE 3 TRINGLE 3, STARTER	1	1	
22	661-41262-02	JOINT, CHOKE LEVER RACCORD, LEVIER DE STARTER	3	3	
23	6J8-41271-01	KNOB, CHOKE BOUTON DE STARTER	1	1	
24	6L2-41257-00	ROD, CHOKE 2 TRINGLE 2, STARTER	1	1	
25	6L2-41217-00	ROD, ACCEL. LEVER TIGE, LEVIER ACCELERATION	1	1	
26	6AH-81994-40	LABEL, SAFETY ETIQUETTE, SECURITE	1	1	
27	6AH-81994-50	LABEL, SAFETY ETIQUETTE, SECURITE	1	1	



6L24100-D050




FIG. 5 CARBURETOR

CARBURATEUR

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6L3A	6L2A	REMARKS REMARQUES
1	6L2-14301-02	CARBURETOR ASSY 1 CARBURATEUR COMPLET 1		1	#1
	6L3-14301-01	CARBURETOR ASSY 1 CARBURATEUR COMPLET 1	1		#1
2	6L2-14302-02	CARBURETOR ASSY 2 CARBURATEUR COMPLET 2		1	#2
	6L3-14302-01	CARBURETOR ASSY 2 CARBURATEUR COMPLET 2	1		#2
3	6L2-14381-00	.BODY, FLOAT CHAMBER 1 .CORPS, CUVE DE FLOTTEUR 1	1	1	#1
	6L2-14383-00	.BODY, FLOAT CHAMBER 2 .CORPS, CUVE DE FLOTTEUR 2	1	1	#2
4	6L2-14384-00	.GASKET, FLOAT CHAMBER .JOINT, CUVE DE FLOTTEUR	2	2	
5	6L2-14385-00	.FLOAT .FLOTTEUR	2	2	
6	6E5-14386-01	.PIN, FLOAT .AXE, FLOTTEUR	2	2	
7	6L2-14392-00	.VALVE, NEEDLE .POINTEAU	2	2	
8	97880-04010	.SCREW, PAN HEAD .VIS, TETE TRONCONIQUE	4	4	
9	92900-04100	.WASHER .RONDELLE	4	4	
10	6L2-14157-00	.COVER, MIXING .COUVERCLE DE CHAMBRE	2	2	
11	6L2-14399-00	.GASKET .JOINT	2	2	
12	6L2-14341-00	.NOZZLE, MAIN .PUITS D'AIGUILLE	2	2	
13	30X-14343-63	.JET, MAIN (#125) .GICLÉUR, PRINCIPAL (#125)	2	2	
14	6L2-14342-30	.JET, PILOT (# 60) .GICLÉUR, RALENTI (# 60)	2	2	
15	50M-14355-00	.PLUG .PLOT	2	2	
16	6L2-14323-00	.SCREW, AIR ADJUSTING .VIS DE DOSEUR D'AIR	2	2	
17	646-14212-01	.SPRING, PILOT ADJUSTING .RESSORT, VIS DE RALENTI	4	4	
18	664-14321-01	.SCREW, THROTTLE .VIS, ACCELERATEUR	2	2	
19	97980-04112	.SCREW, WITH WASHER .VIS, AVEC RONDELLE	8	8	
20	677-14383-01	.SCREW, DRAIN .BOUCHON, PURGE	2	2	
21	6L2-14398-00	.GASKET .JOINT	2	2	
22	677-24444-01	.SCREW .VIS	4	4	
23	98980-04006	.SCREW, BIND .VIS, DE PRESSION	2	2	
24	6A0-24421-01	.VALVE, CHECK .SOUPAPE, RETENUE	2	2	

6L24100-D050





FIG. 5 CARBURETOR

CARBURATEUR

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6L3A	6L2A	REMARKS REMARQUES
25	95380-03600	.NUT .ECROU	2	2	
26	6E7-14325-00	.SCREW, PAN HEAD .VIS TETE CONIQUE	2	2	
27	6L2-24435-00	.GASKET, BODY 2 .JOINT, CORPS 2	1	1	
28	6L2-24413-00	.BODY 2 .CORPS 2	1	1	
29	682-24412-01	.BODY 1 .CORPS 1	1	1	
30	677-24411-02	.DIAPHRAGM .DIAPHRAGME	1	1	
31	677-24434-02	.GASKET, BODY .JOINT, CORPS	1	1	
32	6L2-14578-01	.COLLAR .COLLERETTE	1	1	#2
33	6L2-14584-00	.STOPPER .BUTEE	1	1	#2




6L20300-4060

FIG. 6 OIL PUMP

POMPE A HUILE

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6L3A	6L2A	REMARKS REMARQUES
1	90201-08M93	WASHER, PLATE RONDELLE, PLATE	1	1	
2	6L2-11537-00	GEAR, DRIVEN PIGNON SECONDAIRE	1	1	
3	6J8-13117-00	COLLAR, DISTANCE ENTRETOISE	1	1	
4	93210-13M04	O-RING JOINT TORIQUE	1	1	
5	6L2-13200-00	OIL INJECTION PUMP ASSY POMPE A HUILE COMPLET	1	1	
6	6L2-13471-00	.PLUG, DRAIN .PLOT, VIDANGE	1	1	
7	6L2-13475-00	.GASKET .JOINT	1	1	
8	93210-19M82	.O-RING .JOINT TORIQUE	1	1	
9	97513-05518	BOLT, WITH WASHER VIS HEXAGONAL AVC RONDELLE	1	1	
10	90109-05M33	BOLT BOULON	1	1	
11	90445-07M32	HOSE (L120) DURITE (L120)	2	2	
12	90468-07M02	CLIP JONC	4	4	
13	6E9-13183-70	VALVE, CHECK CLAPET ANTI RETOUR	2	2	
14	90445-07M04	HOSE (L50) DURITE (L50)	1	1	
15	90468-07M02	CLIP JONC	4	4	
16	90445-07M16	HOSE (L85) DURITE (L85)	1	1	
17	682-41237-50	JOINT, LINK RACCORD	1	1	
18	6H1-41237-00	JOINT, LINK RACCORD	1	1	
19	95380-05700	NUT ECROU	1	1	
20	90202-05088	WASHER, PLATE RONDELLE, PLATE	1	1	
21	90468-05M03	CLIP JONC	1	1	
22	6L2-21707-01	OIL TANK COMP. RESERVOIR A PETROLE COMP.	1	1	
23	6H4-21770-00	OIL TANK CAP ASSY CABOCHON DE RESERVOIR A HUILE	1	1	
24	6L2-21758-00	WASHER, SPECIAL 2 RONDELLE, SPECIALE 2	1	1	
25	6H1-24633-00	CHAIN, BALL CHANE DE BALLE	1	1	
26	6H1-21757-00	WASHER, SPECIAL 1 RONDELLE, SPECIALE 1	2	2	
27	6J8-13411-00	STRAINER, OIL FILTRE, HUILE	1	1	




FWD
6L20300-4060

FIG. 6 OIL PUMP

POMPE A HUILE

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6L3A	6L2A	REMARKS REMARQUES
28	6J8-13414-00	GASKET, STRAINER COVER JOINT, COUVERCLE DE FILTRE	1	1	
29	6L2-13416-00	PIPE, OIL 1 DURITE A HUILE	1	1	
30	90467-08004	CLIP JONC	1	1	
31	90467-11M08	CLIP JONC	1	1	
32	90445-11M03	HOSE (L330) DURITE (L330)	2	2	
33	90445-11M07	HOSE (L30) DURITE (L30)	2	2	
34	63D-21744-00	BREATHER RENIFLARD	1	1	
35	6E5-24376-10	PIPE, JOINT 1 DURITE 1, RACCORDEMENT	1	1	
36	90467-10M04	CLIP JONC	1	1	
37	90464-11M24	CLAMP BRIDE	1	1	
38	90446-10M02	HOSE DURITE	1	1	
39	6A0-82317-00	DAMPER, IGNITION COIL AMORTISSEUR, BOBINE D'ALLUM	3	3	
40	90387-06119	COLLAR COLLERETTE	3	3	
41	90119-06M65	BOLT, WITH WASHER BOULON, AVEC RONDELLE	3	3	
42	6L2-21798-00	BRACKET, DAMPER SUPPORT, AMORTISSEUR	1	1	
43	97095-06016	BOLT BOULON	2	2	
44	92995-06600	WASHER RONDELLE	2	2	
45	6L2-85720-02	OIL LEVEL GAUGE ASSY JAUGE A HUILE CPLT	1	1	




FWD
6L22300-3070

FIG. 7 FUEL

CARBURANT

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6L3A	6L2A	REMARKS REMARQUES
1	6G1-24304-02	FUEL PIPE JOINT COMP. 1 DURITE RACCORDEMT. A ESSENCE	1	1	
2	97095-06020	BOLT BOULON	1	1	
3	92995-06600	WASHER RONDELLE	1	1	
4	6H4-24311-00	PIPE, FUEL 1 DURITE A ESSENCE	1	1	
5	6L2-24311-00	PIPE, FUEL 1 DURITE A ESSENCE	1	1	
6	90467-08004	CLIP JONG	4	4	
7	61N-24560-00	FILTER ASSY ENS FILTRE	1	1	
8	61N-24563-00	.ELEMENT, FILTER .ELEMENT, FILTRE	1	1	
9	61N-24521-00	.CUP, FILTER .CUVETTE, FILTRE	1	1	
10	93210-32738	.O-RING .JOINT TORIQUE	1	1	
11	6L2-24566-00	BRACKET, FILTER SUPPORT, FILTRE	1	1	
12	97013-06014	BOLT BOULON	1	1	
13	95380-08600	NUT ECROU	1	1	
14	656-W2810-02	TOOL KIT TROUSSE A OUTILS	1	1	AP AP
15	6L3-28199-7D-E0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1	UR (E) UR (E)
16	6L3-28199-7D-F0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1	UR (F) UR (F)
	6L3-28199-7D-S0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1	UR (ES) UR (ES)
	6L3-28199-7D-G0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1	UR (D) UR (D)
	6L3-28199-7D-D0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1	UR (NL) UR (NL)
	6L3-28199-7D-H0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1	UR (I) UR (I)
	6L3-28199-8E-K0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1	UR (DK) UR (DK)
	6L3-28199-8E-R0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1	UR (GR) UR (GR)
	6L3-28199-8E-P0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1	UR (P) UR (P)
	6L3-28199-8E-N0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1	UR (N) UR (N)
	6L3-28199-8E-M0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1	UR (S) UR (S)
	6L3-28199-8E-L0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1	UR (SF) UR (SF)




*1: CUT FROM 50M ROLLS, PART NO. 90890-44373, CUTTING LENGTH 1.95M

*1: A PRELEVER SUR BOBINE 50M ,REFERENCE 90890-44373, LONGUEUR DE COUPE 1.95M

FIG. 8 STARTER

DEMARREUR

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6L3A	6L2A	REMARKS REMARQUES
1	6L2-15710-02	STARTER ASSY DEMARREUR COMPLET	1	1	
2	6L2-15711-00-94	.CASE, STARTER .CARTER DE DEMARREUR	1	1	
3	91690-40014	.PIN, SPRING .AGRAFFE	1	1	
4	6L2-15758-01-94	.GUIDE, ROPE .GUIDE DE CABLE	1	1	
5	97095-06016	.BOLT .BOULON	2	2	
6	92995-06600	.WASHER .RONDELLE	2	2	
7	6L2-15762-00	.SEAL, RUBBER 2 .JOINT CAOUTCHOUC 2	1	1	
8	689-15755-01	.HANDLE, STARTER .POIGNEE, DE DEMARREUR	1	1	
9	6F5-15779-02	.COVER .COUVERCLE	1	1	
10	*	.WIRE (L:1,950MM) .FIL (L:1,950MM)	1	1	*1 *1
11	6J8-15714-00	.DRUM, SHEAVE .TAMBOUR, POULIE	1	1	
12	90510-08M04	.SPRING, SPIRAL .RESSORT, HELICOIDAL	1	1	
13	677-15717-01	.SHAFT, STARTER .AXE DE DEMARREUR	1	1	
14	90201-06060	.WASHER, PLATE .RONDELLE, PLATE	1	1	
15	97013-06025	.BOLT .BOULON	1	1	
16	95303-06700	.NUT .ECROU	1	1	
17	676-15741-03	.PAWL, DRIVE .CLIQUET, ENTRAINEMENT	1	1	
18	93430-06M02	.CIRCLIP .CLIPS	1	1	
19	6J8-15705-00	.SPRING, DRIVE PAWL .RESSORT DE CLIQUET	1	1	
20	6A0-15789-00	.DAMPER .AMORTISSEUR	1	1	
21	97095-06035	BOLT BOULON	1	1	
22	92995-06600	WASHER RONDELLE	1	1	
23	97095-06025	BOLT BOULON	2	2	
24	92995-06600	WASHER RONDELLE	2	2	
25	99530-10014	PIN, DOWEL GOIJON, D'ASSEMBLAGE	1	1	
26	656-15748-00	PLUNGER, STARTER STOP PLONGEUR, BOUTE DE DEMAR	1	1	
27	90501-10227	SPRING, COMPRESSION RESSORT, COMPRESSION	1	1	



*1: CUT FROM 50M ROLLS, PART NO. 90890-44373, CUTTING LENGTH 1.95M

*1: A PRELEVER SUR BOBINE 50M ,REFERENCE 90890-44373, LONGUEUR DE COUPE 1.95M

FIG. 8 STARTER

DEMARREUR

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6L3A	6L2A	REMARKS REMARQUES
28	6L2-15770-00	CABLE COMP., STARTER STOP CABLE, BUTEE DE DEMAR	1	1	
29	6L2-15746-00	ARM BRAS	1	1	
30	90387-06M51	COLLAR COLLERETTE	1	1	
31	90119-06M53	BOLT, WITH WASHER BOULON, AVEC RONDELLE	1	1	
32	6L2-15747-00	LINK BIELLE	1	1	
33	6L2-15774-00	STAY 4 SUPPORT 4	1	1	
34	661-41262-02	JOINT, CHOKE LEVER RACCORD, LEVIER DE STARTER	2	2	
35	6L2-15772-00-94	STAY 2 SUPPORT 2	1	1	
36	97013-06020	BOLT BOULON	1	1	
37	92903-06600	WASHER, PLATE RONDELLE, PLATE	1	1	
38	97095-06020	BOLT BOULON	1	1	
39	6L2-15723-01	PULLEY, STARTER POULIE DE DEMARREUR	1	1	
40	90105-08M10	BOLT, FLANGE BOULON	3	3	
41	6L2-13437-21	MARK, CAUTION MAKER	1	1	
42	6AH-81995-40	LABEL, WARNING ETIQUETTE, AVERTISSEMENT	1	1	
43	6AH-81995-50	LABEL, WARNING ETIQUETTE, AVERTISSEMENT	1	1	





FIG. 9 GENERATOR

GENERATRICE

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6L3A	6L2A	REMARKS REMARQUES
1	6L2-85550-00	ROTOR ASSY ROTOR CPLT	1	1	
2	6L2-85560-10	BASE ASSY ENS. FLASQUE	1	1	
3	6L2-85520-12	.COIL, CHARGE .BOBINE, CHARGE	1	1	
4	6L2-85533-10	.COIL, LIGHTING .BOBINE, ECLAIRAGE	1	1	
5	6L2-85580-10	.COIL, PULSER .BOBINE, PULSEUR	1	1	
6	6L2-85580-20	.COIL, PULSER .BOBINE, PULSEUR	1	1	
7	97607-04110	.SCREW, WITH WASHER .VIS HEXAGONAL	4	4	
8	97607-06125	.SCREW, WITH WASHER .VIS HEXAGONAL	4	4	
9	97802-04006	.SCREW, PAN HEAD .VIS	1	1	
10	6E9-81328-70	.CLAMP .COLLIER	1	1	
11	6L2-85561-10	.BASE, MAGNETO .BASE, MAGNETO	1	1	
12	61N-85537-00	.COVER .COUVERCLE	1	1	
13	663-85518-00	JOINT, BALL JOINT SPHERIQUE	1	1	
14	90280-05013	KEY, WOODRUFF CLAVETTE, DEMI-LUNE	1	1	
15	90179-12M04	NUT ECROU	1	1	
16	90201-13M42	WASHER, PLATE RONDELLE, PLATE	1	1	
17	6G1-41611-00	RETAINER, MAGNETO BASE FLASQUE, PLATEAU D'AVANCE	1	1	
18	695-41613-00	PLATE, BASE FRICTION PLAQUE, FRICTION DE BASE	1	1	
19	97095-06012	BOLT BOULON	3	3	
20	92995-06600	WASHER RONDELLE	3	3	
21	6G1-41612-00	RETAINER, MAGNETO BASE FLASQUE, PLATEAU D'AVANCE	1	1	
22	97885-05010	SCREW, PAN HEAD VIS, A ENCOCHE	3	3	
23	92995-05600	WASHER RONDELLE	3	3	
24	6L2-81332-00	PLATE, TIMING PLATEAU, ALLUMAGE	1	1	
25	97885-05010	SCREW, PAN HEAD VIS, A ENCOCHE	1	1	
26	92995-05600	WASHER RONDELLE	1	1	
27	6L2-82599-01	COVER, CONNECTER COUVERCLE, CONNECTEUR	1	1	




6L29300-J100

FIG. 10 ELECTRICAL

ELECTRIQUE

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6L3A	6L2A	REMARKS REMARQUES
1	6L2-85540-23	C.D.I. UNIT ASSY BLOC C.D.I.	1	1	
2	97095-06020	BOLT BOULON	2	2	
3	92995-06600	WASHER RONDELLE	2	2	
4	6L2-85542-02-94	BRACKET SUPPORT	1	1	
5	97075-06030	BOLT BOULON	3	3	
6	92995-06600	WASHER RONDELLE	3	3	
7	90101-06M16	BOLT BOULON	2	2	
8	92903-06600	WASHER, PLATE RONDELLE, PLATE	2	2	
9	61N-85570-00	IGNITION COIL ASSY BOBINE D'ALLUMAGE (ENS.)	2	2	
10	97595-06420	BOLT, WITH WASHER VIS HEXAGONAL AVC RONDELLE	2	2	
11	90464-08M07	CLAMP BRIDE	1	1	O/I O/I
12	90480-25161	GROMMET PASSE-FIL	1	1	
13	90465-06M86	CLAMP BRIDE	1	1	O/I O/I
14	97095-06012	BOLT BOULON	1	1	
15	92995-06100	WASHER, SPRING RONDELLE, GROWER	1	1	
16	6G1-82370-21	PLUG CAP ASSY ANTIPARASITE	2	2	
17	97095-06012	BOLT BOULON	2	2	
18	92995-06100	WASHER, SPRING RONDELLE, GROWER	2	2	
19	689-82560-00	THERMO SWITCH ASSY THERMO-CONTACT COMPLET	1	1	O/I O/I
20	6J8-81960-00	RECTIFIER & REGULATOR ASSY REDRESSEUR REGULATEUR CPLT	1	1	
21	97095-06016	BOLT BOULON	1	1	
22	92995-06600	WASHER RONDELLE	1	1	




FWD
6L2A300-K110

FIG. 11 BOTTOM COWLING


CAPOT INFERIEUR

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6L3A	6L2A	REMARKS REMARQUES
1	6L2-42711-03-4D	COWLING, BOTTOM 1 CUVETTE 1	1	1	
2	6L2-42815-01-4D	LEVER, CLAMP LEVIER, PRESSE	1	1	
3	90386-12M45	BUSH DOUILLE	2	2	
4	6L2-42816-00	LEVER, CLAMP LEVIER, PRESSE	1	1	
5	90206-12052	WASHER, WAVE RONDELLE, ONDULEE	1	1	
6	97880-06035	SCREW, PAN HEAD VIS, TETE TRONCONIQUE	1	1	
7	95780-06300	NUT, FLANGE ECROU	1	1	
8	6L2-42719-A0	PANEL, FRONT LOWER Panneau, AVANT INFERIEUR	1	1	
9	689-41273-00	GROMMET PASSE-FIL	1	1	
10	6J8-41274-00	GROMMET 2 PASSE-FIL 2	1	1	
11	6L2-42725-00	GROMMET PASSE-FIL	1	1	
12	6L2-42726-01	GROMMET PASSE-FIL	1	1	
13	6G1-42727-00	GROMMET PASSE-FIL	1	1	
14	6L2-42748-01	GROMMET PASSE-FIL	1	1	
15	6L2-42716-00	RUBBER, SEAL 1 JOINT EN CAOUTCHOUC 1	1	1	
16	90338-05M03	PLUG PLOT	2	2	
17	90480-15M31	GROMMET PASSE-FIL	4	4	
18	90387-06M52	COLLAR COLLERETTE	4	4	
19	95895-06020	BOLT, FLANGE BOULON	4	4	
20	6L2-42738-01	PLATE, FITTING ETRIER	2	2	
21	6BL-44391-00	NIPPLE, HOSE RACCORD D'ESSENCE	1	1	
22	6L2-82575-00	ENGINE STOP SWITCH ASSY COUPE CIRCUIT CPLT	1	1	
23	682-82556-00	.LANYARD, STOP SWITCH .PLAQUETTE	1	1	
24	689-8257Y-00	.CAP .COUVERCLE	1	1	
25	6J8-85410-00	EMERGENCY SIGNAL LIGHT ASSY FEU DE DETRESSE	1	1	O/I O/I
26	682-84381-00	2P CONCENT RALLONGE 2 FILS	1	1	
27	6E7-42791-10	MARK 1 ETIQUETTE 1	1	1	

CAPOT INFERIEUR

[illegible]

6L2A300-K110




6L2A300-K120

FIG. 12 STEERING

DIRECTION

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6L3A	6L2A	REMARKS REMARQUES
1	6L2-W0084-11-4D	HANDLE STEERING ASSY BARRE FRANCHE (ENS.)	1	1	
2	6G1-42111-12-4D	HANDLE, STEERING POIGNEE	1	1	
3	90206-36M21	WASHER, WAVE RONDELLE, ONDULEE	1	1	
4	90202-36M55	WASHER, PLATE RONDELLE, PLATE	1	1	
5	90386-33M96	BUSH DOUILLE	1	1	
6	90386-34M97	BUSH DOUILLE	1	1	
7	6G1-42131-02	COVER, HANDLE STEERING COUVERCLE	1	1	
8	90116-08016	BOLT, STUD GOUJON	1	1	
9	90185-08057	NUT, SELF-LOCKING ECROU, AUTO-BLOQUANT	1	1	
10	6G1-42125-01	BOLT, FRICTION ADJUSTING BOULON	1	1	
11	6G1-42126-00	FRICTION, STEERING HANDLE GRIP CUVETTE, POIGNEE DE DIRECTION	1	1	
12	91490-16010	PIN, COTTER GOUPILLE	1	1	
13	664-42119-00	GRIP, STEERING HANDLE POIGNEE, BARRE FRANCHE	1	1	
14	6F6-42177-A0	RUBBER, HANDLE CAOUTCHOUC, POIGNEE	1	1	
15	6L2-42137-00	INDICATOR, THROTTLE INDICATEUR, ACCELERATION	1	1	
16	90269-02M09	RIVET RIVET	1	1	
17	90501-23215	SPRING, COMPRESSION RESSORT, COMPRESSION	1	1	
18	90201-10M02	WASHER, PLATE RONDELLE, PLATE	2	2	
19	90152-05011	SCREW, COUNTERSUNK VIS, TETE NOYEE	1	1	
20	90386-08032	BUSH DOUILLE	1	1	
21	6G1-42138-01	LEVER, THROTTLE LEVIER, ACCELERATEUR	1	1	
22	6E0-42159-02	STAY SUPPORT	1	1	
23	97885-05012	SCREW, PAN HEAD VIS, A ENCOCHE	2	2	
24	6L2-26301-01	THROTTLE CABLE ASSY CABLE D'ACCELERATEUR	2	2	
25	6L2-44111-01-94	HANDLE, GEAR SHIFT POIGNEE, LEVIER D'EMBRAYAGE	1	1	
26	90386-15M73	BUSH DOUILLE	2	2	
27	90206-15M18	WASHER, WAVE RONDELLE, ONDULEE	1	1	



FWD
6L2A300-K120

FIG. 12 STEERING

DIRECTION

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6L3A	6L2A	REMARKS REMARQUES
28	90202-15M37	WASHER, PLATE RONDELLE, PLATE	1	1	
29	90386-12M72	BUSH DOUILLE	1	1	
30	6L2-44125-00-94	LEVER, SHIFT ROD LEVIER, TIGE D'INVERSION	1	1	
31	97095-06020	BOLT BOULON	1	1	
32	92995-06600	WASHER RONDELLE	1	1	
33	90202-06009	WASHER, PLATE RONDELLE, PLATE	2	2	
34	91490-20010	PIN. COTTER GOUPILLE	1	1	
35	6L2-44124-00	LINK, SHIFT ROD BIELLETTTE	1	1	
36	6L2-26363-00	END, CABLE EMBOUT DE CABLE	1	1	
37	95380-06700	NUT ECROU	1	1	
38	90202-05088	WASHER, PLATE RONDELLE, PLATE	2	2	
39	90202-05M38	WASHER, PLATE RONDELLE, PLATE	1	1	
40	90468-05M03	CLIP JONC	1	1	




FIG. 13 CONTROL

COMMANDE

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6L3A	6L2A	REMARKS REMARQUES
1	6L2-14497-00	STAY, THROTTLE WIRE SUPPORT DE BOISSEAU	1	1	
2	97095-06020	BOLT BOULON	1	1	
3	95380-06700	NUT ECROU	1	1	
4	6L2-41213-00	CAM, ACCEL. CAME, ACCELERATION	1	1	
5	6L2-41283-00	LEVER, FREE ACCEL. LEVIER	1	1	
6	6L2-41631-00	LEVER, MAGNETO CONTROL LEVIER, COMMANDE D'AVANCE	1	1	
7	6J8-42167-00	SPRING 1 RESSORT1	1	1	
8	6L2-42167-00	SPRING 1 RESSORT1	1	1	
9	97595-06575	BOLT, WITH WASHER VIS HEXAGONAL AVC RONDELLE	1	1	
10	90387-06M18	COLLAR COLLERETTE	1	1	
11	689-42169-01	JOINT AXE	1	1	
12	662-41237-01	JOINT, LINK RACCORD	1	1	
13	95380-05600	NUT ECROU	1	1	
14	6L2-44122-00	BUSHING, SHIFT ROD LEVER DOUILLE, LEVIER D'EMBRAYAGE	1	1	
15	90254-03M04	PIN, SPRING RIVET, TETE TRONCONIQUE	1	1	
16	6L2-42192-00	ROD 2 TRINGLE 2	1	1	
17	90202-05088	WASHER, PLATE RONDELLE, PLATE	2	2	
18	91490-20010	PIN, COTTER GOUPILLE	2	2	
19	6L2-44141-02	LINK, SHIFT ROD BIELLETTTE	1	1	
20	6L2-44141-10-94	LINK, SHIFT ROD BIELLETTTE	1	1	
21	6L2-44121-00	LEVER, SHIFT ROD LEVIER, TIGE D'INVERSION	1	1	
22	6L2-41212-00	ARM, ACCEL. BRAS	1	1	
23	90109-06M28	BOLT BOULON	1	1	
24	97013-05016	BOLT BOULON	1	1	
25	92903-05600	WASHER, PLATE RONDELLE, PLATE	1	1	
26	6L2-41237-00	JOINT, LINK RACCORD	1	1	
27	6L2-41238-00	JOINT, LINK RACCORD	1	1	





FIG. 13 CONTROL

COMMANDE

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6L3A	6L2A	REMARKS REMARQUES
28	95380-05700	NUT ECROU	1	1	
29	6G1-41662-01-94	BRACKET 2 SUPPORT 2	2	2	
30	97013-06020	BOLT BOULON	2	2	
31	92903-06600	WASHER, PLATE RONDELLE, PLATE	2	2	
32	6J8-44116-00	SPRING RESSORT	1	1	
33	95895-06012	BOLT, FLANGE BOULON	1	1	
34	6L2-44123-00	ARM, SHIFT ROD BRAS, TIGE D'INVERSION	1	1	
35	90254-03M04	PIN, SPRING RIVET, TETE TRONCONIQUE	1	1	
36	6L2-44143-00	ROD, SHIFT TIGE D'EMBRAYAGE	1	1	
37	90170-06015	NUT ECROU	1	1	
38	6L2-14368-00	DIAPHRAGM ASSY 1 DIAPHRAGME 1	1	1	
39	97095-06008	BOLT BOULON	2	2	




6L2A300-K140

FIG. 14 BRACKET 1

SUPPORT 1

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6L3A	6L2A	REMARKS REMARQUES
1	6L2-43111-05-4D	BRACKET, CLAMP 1 PRESSE 1	1	1	
2	6L2-43112-06-4D	BRACKET, CLAMP 2 PRESSE 2	1	1	
3	6E5-82148-00	WIRE, LEAD 4 FIL 4	1	1	
4	97885-06008	SCREW, PAN HEAD VIS, A ENCOCHE	2	2	
5	6E0-43118-01	HANDLE, TRANSOM CLAMP POIGNEE DE VIS DE PRESSE	2	2	
6	90243-04M01	PIN GOUPILLE	2	2	
7	6L2-43116-00	SCREW, TRANSOM CLAMP VIS DE PRESSE	2	2	
8	648-43114-01	PAD, TRANSOM CLAMP RONDELLE D'APPUI	2	2	
9	6J8-43131-01	BOLT, CLAMP BRACKET BOULON, PRESSE	1	1	
10	90386-22M67	BUSH DOUILLE	2	2	
11	90201-22M03	WASHER, PLATE RONDELLE, PLATE	2	2	
12	90185-22043	NUT, SELF-LOCKING ECROU, AUTO-BLOQUANT	2	2	
13	6G5-43145-01	CAP, CLAMP BRACKET CAPUCHON, PRESSE	2	2	
14	6J8-43113-01	PLATE, CLAMP BRACKET PLAQUETTE, PRESSE	1	1	
15	6L2-43311-05-4D	BRACKET, SWIVEL 1 SUPPORT, PIVOT 1	1	1	
16	93700-06M03	NIPPLE, GREASE PION	1	1	
17	663-45119-00	CAP, GREASE NIPPLE CAPUCHON, GRAISSEUR	1	1	AP AP
18	6H4-42528-00	PLATE, FRICTION PLAQUE, FRICTION	1	1	
19	689-43373-01	SEAL, DAMPER JOINT	1	1	
20	90105-06M18	BOLT, FLANGE BOULON	1	1	
21	6L2-42121-03-4D	BRACKET SUPPORT	1	1	
22	6E0-44191-11	INDICATOR, SHIFT ETIQUETTE, EMBRAYAGE	1	1	
23	90116-10M28	BOLT, STUD GOUJON	2	2	
24	92995-10600	WASHER RONDELLE	2	2	
25	90185-10051	NUT, SELF-LOCKING ECROU, AUTO-BLOQUANT	2	2	
26	6L2-42510-01-4D	STEERING BRACKET ASSY DIRECTION SUPPORT (ENS.)	1	1	
27	90386-30M75	BUSH DOUILLE	2	2	




FWD
6L2A300-K140

FIG. 14 BRACKET 1

SUPPORT 1

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6L3A	6L2A	REMARKS REMARQUES
28	90201-30M00	WASHER, PLATE RONDELLE, PLATE	1	1	
29	93210-29375	O-RING JOINT TORIQUE	1	1	
30	90386-30M60	BUSH DOUILLE	1	1	
31	6L2-44512-00-4D	COVER, UPPER MOUNT COUVERCLE	1	1	
32	6L2-45114-A1	GASKET, UPPER CASING JOINT, TUBE D'ARBRE	1	1	
33	6L2-44365-00	DAMPER, WATER SEAL 1 JOINT, TUBE D'EAU 1	1	1	
34	97095-06020	BOLT BOULON	3	3	
35	92995-06600	WASHER RONDELLE	3	3	
36	6L2-44514-01	MOUNT DAMPER, UPPER SIDE SILENT-BLOC, SUPERIEUR LATERAL	1	1	
37	90119-06M04	BOLT, WITH WASHER BOULON, AVEC RONDELLE	2	2	
38	90119-06M05	BOLT, WITH WASHER BOULON, AVEC RONDELLE	1	1	
39	90101-08M09	BOLT BOULON	2	2	
40	90201-08M01	WASHER, PLATE RONDELLE, PLATE	4	4	
41	6L2-44526-00	PLATE PLAQUE	1	1	
42	90185-08057	NUT, SELF-LOCKING ECROU, AUTO-BLOQUANT	2	2	
43	6L2-44551-01-4D	HOUSING, LOWER MOUNT RUBBER 1 BOITIER, SILENT-BLOC INFERIEUR	1	1	
44	6L2-44552-01-4D	HOUSING, LOWER MOUNT RUBBER 2 BOITIER, SILENT-BLOC INFERIEUR	1	1	
45	93604-12M07	PIN, DOWEL CLAVETTE	2	2	
46	97595-08585	BOLT, WITH WASHER VIS HEXAGONAL AVEC RONDELLE	2	2	
47	6L2-44555-00	MOUNT DAMPER, LOWER SIDE SILENT-BLOC, INFERIEUR LATERAL	2	2	
48	6L2-44557-00	MOUNT DAMPER, LOWER FRONT SILENT-BLOC, INFERIEUR AVANT	1	1	
49	6L2-44553-01-4D	COVER, LOWER MOUNT COUVERCLE, SUSPENSION INFERIEUR	1	1	
50	97095-08045	BOLT BOULON	2	2	
51	92995-08600	WASHER RONDELLE	2	2	




6L23300-C180

FIG. 15 BRACKET 2

SUPPORT 2

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6L3A	6L2A	REMARKS REMARQUES
1	6L2-43165-01	PLATE, TILT LOCK TAQUET, BROCHE INCLINAISON	1	1	
2	97090-06010	BOLT BOULON	4	4	
3	92990-06600	WASHER, PLATE RONDELLE, PLATE	4	4	
4	6L2-43160-01	TILT ROD ASSY BROCHE D'INCLINAISON (ENS.)	1	1	
5	689-43165-00	.PLATE, TILT LOCK .TAQUET, BROCHE INCLINAISON	1	1	
6	91690-30008	.PIN, SPRING .AGRAFFE	1	1	
7	90502-10M07	SPRING, CONICAL RESSORT, CONIQUE	1	1	
8	6L2-43630-01	TILT LEVER ASSY LEVIER D'INCLINAISON	1	1	
9	682-43318-01	COVER CAPUCHON	1	1	
10	90386-08032	BUSH DOUILLE	3	3	
11	6L2-43682-01	LEVER, SHALLOW WATER DRIVE 2 LEVIER, PEU PROFOND D'EAU 2	1	1	
12	97095-05010	BOLT BOULON	1	1	
13	92995-05600	WASHER RONDELLE	1	1	
14	6L2-43191-01	SHAFT, STOPPER AXE, BUTEE	1	1	
15	99080-05600	CIRCLIP CIRCLIP	1	1	
16	90506-20M27	SPRING, TENSION RESSORT, TENSION	1	1	
17	6L2-43350-02	RECEIVER ASSY RECEIVER ASSY	1	1	
18	6J8-43611-01	SHAFT, TILT LOCK AXE, VERROUILLAGE MARCHE AR	1	1	
19	99080-05600	CIRCLIP CIRCLIP	1	1	
20	6L2-43614-00	PLATE, TILT LOCK ETRIER, VERROUILLAGE MARCHE AR	1	1	
21	90508-12M28	SPRING, TORSION RESSORT, TORSION	1	1	
22	90508-12M29	SPRING, TORSION RESSORT, TORSION	1	1	
23	6L2-43615-00	PLATE, TILT LOCK ETRIER, VERROUILLAGE MARCHE AR	1	1	
24	6L2-43657-00	SPRING, LOCK RESSORT, BLOCAGE	1	1	
25	6L2-43676-00	HOOK CROCHET	1	1	
26	6L2-43631-00	LEVER, TILT LEVIER, INCLINAISON	1	1	
27	6L2-43188-00	SPRING RESSORT	1	1	




6L23300-C180

FIG. 15 BRACKET 2

SUPPORT 2

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6L3A	6L2A	REMARKS REMARQUES
28	6L2-43633-10	COVER, TILT LEVER COUVERCLE	1	1	
29	6L2-43611-00	SHAFT, TILT LOCK AXE, VERROUILLAGE MARCHE AR	1	1	
30	6L2-43641-00	LEVER, TILT LEVIER, INCLINAISON	1	1	
31	6L2-43659-00	SHAFT, REVERSE LOCK AXE, VERROUILLAGE MARCHE AR	1	1	
32	99080-05600	CIRCLIP CIRCLIP	1	1	
33	6L2-43617-00	ROD, TILT LOCK TIGE	1	1	
34	6L2-43613-00	ARM, TILT LOCK GUIDE	1	1	
35	99080-05600	CIRCLIP CIRCLIP	1	1	
36	6L2-43624-00	PLATE, TILT ROCK ETRIER, VERROUILLAGE MARCHE AR	1	1	
37	6L2-43336-00	PIN CLAVETTE	1	1	
38	90506-23M11	SPRING, TENSION RESSORT, TENSION	1	1	



FWD
6L20100-1190

FIG. 16 UPPER CASING

FOURREAU

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6L3A	6L2A	REMARKS REMARQUES
1	6L2-45111-03-4D	CASING, UPPER FOURREAU	1	1	S(16.5") S(16.5")
	6L2-45111-13-4D	CASING, UPPER FOURREAU	1	1	L(21.5") L(21.5")
2	6L2-45151-01-4D	COVER, UPPER CASING CAPUCHON, FOURREAU	1	1	
3	6L2-45115-00	GASKET, UPPER CASING JOINT, TUBE D'ARBRE	1	1	
4	90159-06M11	SCREW, WITH WASHER VIS, AVEC RONDELLE	2	2	
5	93604-12M07	PIN, DOWEL CLAVETTE	2	2	
6	6L2-82127-00	WIRE, LEAD 2 FIL 2	1	1	
7	90157-06M06	SCREW, PAN HEAD VIS, TETE TRONCONIQUE	1	1	
8	97075-08030	BOLT BOULON	6	6	
9	92995-08600	WASHER RONDELLE	6	6	
10	6L2-41131-00-CA	MANIFOLD, EXT. 1 PIPE D'ECHAPPEMENT	1	1	
	6L3-41131-00-CA	MANIFOLD, EXT. 1 PIPE D'ECHAPPEMENT	1	1	
11	6L2-41134-00	GASKET, EXHAUST MANIFOLD JOINT, PIPE D'ECHAPPEMENT	1	1	
12	6L2-45123-01	GASKET, MUFFLER JOINT, POT DE DETENTE	1	1	
13	6L2-41133-A3	GASKET, EXHAUST MANIFOLD 1 JOINT, PIPE D'ECHAPPEMENT	1	1	
14	97095-06020	BOLT BOULON	4	4	
15	92995-06600	WASHER RONDELLE	4	4	




FIG. 17 LOWER CASING & DRIVE 1

BOITIER D'HELICE TRANSMISSION1

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6L3A	6L2A	REMARKS REMARQUES
1	6L2-45300-03-4D	LOWER UNIT ASSY UNITE INFERIEURE (ENS.)		1	S(16.5") S(16.5")
	6L2-45300-13-4D	LOWER UNIT ASSY UNITE INFERIEURE (ENS.)	1	1	L(21.5") L(21.5")
2	6L2-45311-02-4D	CASING, LOWER BOITIER D'HELICE	1	1	
3	93332-00005	BEARING ROULEMENT	1	1	
4	6L2-45567-00	SHIM (T:1.0MM) CALE (T:1.0MM)	1	1	UR
	6L2-45567-10	SHIM (T:1.1MM) CALE (T:1.1MM)	1	1	UR
	6L2-45567-20	SHIM (T:1.2MM) CALE (T:1.2MM)	1	1	UR
	6L2-45567-30	SHIM (T:1.3MM) CALE (T:1.3MM)	1	1	UR
	6L2-45567-40	SHIM (T:1.4MM) CALE (T:1.4MM)	1	1	UR
5	93315-220V9	BEARING ROULEMENT	1	1	
6	6L2-45536-00	SLEEVE, DRIVE SHAFT MANCHON, ARBRE MOTEUR	1	1	
7	90340-08002	PLUG, STRAIGHT SCREW PLOT, FILETE DROIT	2	2	
8	90430-08020	GASKET JOINT	2	2	
9	6L2-44311-00	HOUSING, WATER PUMP CORPS, POMPE A EAU	1	1	
10	93210-45161	O-RING JOINT TORIQUE	1	1	
11	6L2-44322-00	INSERT, CARTRIDGE CUVETTE	1	1	
12	6L2-44323-00	OUTER PLATE, CARTRIDGE PLAQUE EXTERIEURE	1	1	
13	6L2-44352-00	IMPELLER TURBINE	1	1	
14	97095-06040	BOLT BOULON	4	4	
15	92995-06600	WASHER RONDELLE	4	4	
16	6L2-44328-00	PLATE PLAQUETTE	2	2	
17	6L2-45331-00-CA	HOUSING, BEARING FLASQUE, ROULEMENT	1	1	
18	93315-22004	BEARING ROULEMENT	1	1	
19	93101-20048	OIL SEAL JOINT SPY	2	2	
20	6L2-44147-00	BOOT, SHIFT ROD SOUFFLET, TIGE D'INVERSION	1	1	
21	93604-12M07	PIN, DOWEL CLAVETTE	2	2	
22	6L2-45315-A0	PACKING, LOWER CASING JOINT, BOITIER D'HELICE	1	1	




FIG. 17 LOWER CASING & DRIVE 1


BOITIER D'HELICE TRANSMISSION1

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6L3A	6L2A	REMARKS REMARQUES
23	97095-06020	BOLT BOULON	2	2	
24	92995-06600	WASHER RONDELLE	2	2	
25	6L2-45375-00	DAMPER, SEAL BOURRELET, CAOUTCHOUC	1	1	
26	6L2-45510-00	DRIVE SHAFT ASSY ARBRE MOTEUR (ENS.)		1	S(16.5") S(16.5")
	6L2-45510-10	DRIVE SHAFT ASSY ARBRE MOTEUR (ENS.)		1	L(21.5") L(21.5")
27	90280-03024	KEY, WOODRUFF CLAVETTE, DEMI-LUNE	1	1	
28	6L2-45551-01	PINION (13T) PIGNON D'ATTAQUE (13D)	1	1	
29	90179-10M14	NUT ECROU	1	1	
30	93341-320U0	BEARING CERVEAUX DE DIRECTION	1	1	
31	6L2-45587-00	SHIM (T:1.5MM) CALE (T:1.5MM)	1	1	UR UR
	6L2-45587-10	SHIM (T:1.6MM) CALE (T:1.6MM)	1	1	UR UR
32	6L2-45560-10	GEAR 1 (27T) PIGNON 1 (27T)	1	1	
33	6L2-45571-00	GEAR 2 (27T) PIGNON 2 (27T)	1	1	
34	90201-20417	WASHER, PLATE RONDELLE, PLATE	1	1	
35	6L2-45577-00	SHIM (T:1.0MM) CALE (T:1.0MM)	1	1	UR UR
	6L2-45577-10	SHIM (T:1.1MM) CALE (T:1.1MM)	1	1	UR UR
	6L2-45577-20	SHIM (T:1.2MM) CALE (T:1.2MM)	1	1	UR UR
	6L2-45577-30	SHIM (T:1.3MM) CALE (T:1.3MM)	1	1	UR UR
36	65W-45611-00	SHAFT, PROPELLER ARBRE, HELICE	1	1	
37	90501-10065	SPRING, COMPRESSION RESSORT, COMPRESSION	1	1	
38	6L2-45631-00	CLUTCH, DOG CRABOT	1	1	
39	90250-05010	PIN, STRAIGHT GOUPILLE, DROITE	1	1	
40	648-45633-00	RING, CROSS PIN JONC, GOUPILLE CRABOT	1	1	
41	648-45635-00	PLUNGER, SHIFT POUSSOIR D'EMBRAYAGE	1	1	
42	6L2-45361-03-4D	CAP, LOWER CASING COUVERCLE, BOITIER D'HELICE	1	1	
43	93306-00612	BEARING ROULEMENT	1	1	
44	93210-60MA3	O-RING JOINT TORIQUE	1	1	

FIG. 17 LOWER CASING & DRIVE 1

BOITIER D'HELICE TRANSMISSION1

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6L3A	6L2A	REMARKS REMARQUES
45	93315-22004	BEARING ROULEMENT	1	1	
46	93101-20M07	OIL SEAL JOINT SPY	2	2	
47	97095-06020	BOLT BOULON	2	2	
48	92995-06600	WASHER RONDELLE	2	2	
49	93210-60M99	O-RING JOINT TORIQUE	1	1	
50	6L2-44150-00	SHIFT CAM ASSY CAME D'INVERSION	1	1	S(16.5") S(16.5")
	6L2-44150-10	SHIFT CAM ASSY CAME D'INVERSION	1	1	L(21.5") L(21.5")
51	95380-06600	NUT, HEXAGON ECROU	1	1	





FLOOD MARINE SERVICES
downloaded from www.yamahaoutboardparts.co.uk

FLOOD MARINE SERVICES

FLOOD MARINE SERVICES
downloaded from www.yamaha.com 15 689-45997



FMS
FLOOD MARINE SERVICES
downloaded from www.yamahaoutboardsports.co.uk

FIG. 18 LO

REF. NO.	PAR N° P
19	664-45972

downloaded from www.yam.com 2016-06-18-W4591

FMS
FLOOD MARINE SERVICES
downloaded from www.yamahaoutboardparts.co.uk





FIG. 19 FUEL TANK 1

RESERVOIR A CARBURANT 1

[illegible]




68U3100-C240

FIG. 20 FUEL TANK 2

RESERVOIR A CARBURANT 2

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6L3A	6L2A	REMARKS REMARQUES
1	6YJ-24201-10	FUEL TANK ASSY (24L) RESERVOIR A ESSENCE (ENS.):24L		1	AP FOR RUS AP FOR RUS
2	6YJ-24610-01	.CAP ASSY .BOUCHON		1	
3	6Y1-24260-12	.FUEL METER ASSY .INDICATEUR DE CARBURANT		1	WITH INDICATOR WITH INDICATOR
4	90157-05M19	.SCREW, PAN HEAD .VIS, TETE TRONCONIQUE		4	
5	6Y1-24329-00	.SEAL .JOINT		4	
6	6Y1-24268-00	.GASKET, FUEL METER .JOINT, JAUGE A CARBURANT		1	
7	6YJ-24167-00	.STRAINER .FILTRE		1	
8	61J-24306-04	FUEL PIPE COMP. 1 DURITE A ESSENCE 1		1	AP FOR RUS AP FOR RUS
9	90445-11M06	.HOSE (L2050) .DURITE (L2050)		1	
10	61J-24360-00	.PRIMER PUMP ASSY .POMPE D'AMORCAGE		1	
11	90445-11M05	.HOSE (L850) .DURITE (L850)		1	
12	650-24351-01	.BAND 1 .COLLIER 1		4	
13	6G1-24305-05	.FUEL PIPE JOINT COMP. 2 .DURITE RACCORDEMT. A ESSENCE		1	
14	93210-08287	..O-RING ..JOINT TORIQUE		1	
15	6Y1-24305-06	.FUEL PIPE JOINT COMP. 2 .DURITE RACCORDEMT. A ESSENCE		1	
16	93210-08287	..O-RING ..JOINT TORIQUE		1	




6L23100-C260

FIG. 21 REPAIR KIT 1

KITS DE REPARATION 1

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6L3A	6L2A	REMARKS REMARQUES
1	6L2-W0001-03	POWER HEAD GASKET KIT POCHETTE DE JINTS TETE MOTRICE	1	1	
2	93102-25142	.OIL SEAL .JOINT SPY	1	1	
3	93101-13M37	.OIL SEAL .JOINT SPY	1	1	
4	93210-56M80	.O-RING .JOINT TORIQUE	1	1	
5	6L2-11181-A3	.GASKET, CYLINDER HEAD 1 .JOINT, DE CULASSE 1	1	1	
6	6L2-11193-A1	.GASKET, HEAD COVER 1 .JOINT, COUVERCLE DE CULASSE 1	1	1	
7	6J8-12414-A0	.GASKET, COVER .JOINT, COUVERCLE	1	1	
8	6L2-41114-A1	.GASKET, EXHAUST OUTER COVER .JOINT, COUVERCLE D'ECHAPPEMENT	1	1	
9	6L2-41112-A3	.GASKET, EXHAUST INNER COVER .JOINT, PLAQUE D'ECHAPPEMENT	1	1	
10	93102-26M27	.OIL SEAL .JOINT SPY	1	1	
11	93210-42159	.O-RING .JOINT TORIQUE	1	1	
12	6L2-13621-00	.GASKET, VALVE SEAT .JOINT, SIEGE DE CLAPET	1	1	
13	6L2-14384-00	.GASKET, FLOAT CHAMBER .JOINT, CUVE DE FLOTTEUR	2	2	
14	6L2-14198-00	.GASKET .JOINT	2	2	
15	93210-32738	.O-RING .JOINT TORIQUE	1	1	
16	6L2-45113-A2	.GASKET, UPPER CASING .JOINT, TUBE D'ARBRE	1	1	
17	6L2-41133-A3	.GASKET, EXHAUST MANIFOLD 1 .JOINT, PIPE D'ECHAPPEMENT	1	1	
18	6L2-W0093-00	CARBURETOR REPAIR KIT KIT DE REPARATION CARBURATEUR	1	1	
19	6L2-14198-00	.GASKET .JOINT	2	2	
20	6L2-14384-00	.GASKET, FLOAT CHAMBER .JOINT, CUVE DE FLOTTEUR	2	2	
21	6L2-14385-00	.FLOAT .FLOTTEUR	2	2	
22	6E5-14386-01	.PIN, FLOAT .AXE, FLOTTEUR	2	2	
23	6L2-14392-00	.VALVE, NEEDLE .POINTEAU	2	2	
24	6L2-14399-00	.GASKET .JOINT	2	2	
25	97980-04112	.SCREW, WITH WASHER .VIS, AVEC RONDELLE	2	2	
26	6L2-14398-00	.GASKET .JOINT	2	2	



6L20100-4270

FIG. 22 REPAIR KIT 2

KITS DE REPARATION 2

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6L3A	6L2A	REMARKS REMARQUES
1	6L2-W0001-C3	LOWER UNIT GASKET KIT POCHETTE DE JOINTS EMBASE	1	1	
2	6L2-41134-00	.GASKET, EXHAUST MANIFOLD .JOINT, PIPE D'ECHAPPEMENT	1	1	
3	90430-08020	.GASKET .JOINT	2	2	
4	93210-45161	.O-RING .JOINT TORIQUE	1	1	
5	6L2-44367-00	.DAMPER, WATER SEAL 3 .JOINT TUBE D'EAU 3	1	1	
6	93101-20048	.OIL SEAL .JOINT SPY	2	2	
7	6L2-45315-A0	.PACKING, LOWER CASING .JOINT, BOITIER D'HELICE	1	1	
8	93210-60MA3	.O-RING .JOINT TORIQUE	1	1	
9	93101-20M07	.OIL SEAL .JOINT SPY	2	2	
10	93210-60M99	.O-RING .JOINT TORIQUE	1	1	
11	6L2-W0078-00	WATER PUMP REPAIR KIT KIT DE REPARATION DE LA POMPE	1	1	
12	6L2-44323-00	.OUTER PLATE, CARTRIDGE .PLAQUE EXTERIEURE	1	1	
13	93210-45161	.O-RING .JOINT TORIQUE	1	1	
14	6L2-44352-00	.IMPELLER .TURBINE	1	1	
15	6L2-44322-00	.INSERT, CARTRIDGE .CUVETTE	1	1	
16	97095-06040	.BOLT .BOULON	4	4	
17	90280-03024	.KEY, WOODRUFF .CLAVETTE, DEMI-LUNE	1	1	

PART NO. N° PIECES	REF. NO.
6L2-11111-01-1S	2 - 17
6L2-11181-A3	2 - 18
	21 - 5
6L2-11191-00-1S	2 - 19
6L2-11193-A1	2 - 20
	21 - 6
6J8-11325-00	2 - 12
6H3-11327-00-94	2 - 13
6H3-11328-00	2 - 14
676-11372-00	2 - 31
6E5-11372-01	2 - 3
6L2-11400-10	3 - 1
6L2-11412-00	3 - 2
6L2-11422-00	3 - 3
6L2-11432-00	3 - 4
6L2-11442-00	3 - 5
6L2-11515-00	3 - 14
6J8-11536-00	3 - 16
6L2-11537-00	6 - 2
6L2-11610-00	3 - 20
6L2-11610-10	3 - 20
6L2-11610-20	3 - 20
6L2-11631-00-97	3 - 19
648-11633-00	3 - 21
6L2-11635-00	3 - 19
6L2-11636-00	3 - 19
6L2-11651-00	3 - 10
6L2-11681-00	3 - 11
6E5-12411-30	2 - 23
688-12412-00	2 - 24
6H4-12413-00-1S	2 - 25
6J8-12414-A0	2 - 26
	21 - 7
6J8-13117-00	6 - 3
6E9-13183-70	6 - 13
6L2-13200-00	6 - 5
6J8-13411-00	6 - 27
6J8-13414-00	6 - 28
6L2-13416-00	6 - 29
6L2-13437-00	1 - 13
6L2-13437-21	8 - 41
6L2-13471-00	6 - 6
6L2-13475-00	6 - 7
6L2-13610-00	4 - 1
6L2-13621-00	4 - 6
	21 - 12
6L2-13641-10	4 - 4
6L2-14157-00	5 - 10

NUMERICAL INDEX
INDEX NUMERIQUE

PART NO. N° PIECES	REF. NO.
676-15741-03	8 - 17
6L2-15746-00	8 - 29
6L2-15747-00	8 - 32
656-15748-00	8 - 26
689-15755-01	8 - 8
6L2-15758-01-94	8 - 4
6L2-15762-00	8 - 7
6L2-15770-00	8 - 28
6L2-15772-00-94	8 - 35
6L2-15774-00	8 - 33
6F5-15779-02	8 - 9
6A0-15789-00	8 - 20
6L2-21707-01	6 - 22
63D-21744-00	6 - 34
6H1-21757-00	6 - 26
6L2-21758-00	6 - 24
6H4-21770-00	6 - 23
6L2-21798-00	6 - 42
6YJ-24167-00	20 - 7
6YK-24201-03	19 - 1
6YJ-24201-10	20 - 1
6YK-24260-01	19 - 4
6Y1-24260-12	20 - 3
6Y1-24268-00	20 - 6
6YL-24268-01	19 - 2
6G1-24304-02	7 - 1
6G1-24305-05	20 - 13
6Y1-24305-06	20 - 15
61J-24306-04	20 - 8
6YL-24306-54	19 - 7
6H4-24311-00	7 - 4
6L2-24311-00	7 - 5
6Y1-24329-00	20 - 5
6YL-24329-00	19 - 6
650-24351-01	20 - 12
61J-24360-00	20 - 10
6E5-24376-10	6 - 35
677-24411-02	5 - 30
682-24412-01	5 - 29
6L2-24413-00	5 - 28
6A0-24421-01	5 - 24
677-24434-02	5 - 31
6L2-24435-00	5 - 27
677-24444-01	5 - 22
61N-24521-00	7 - 9
61N-24560-00	7 - 7
61N-24563-00	7 - 8
6L2-24566-00	7 - 11
6YJ-24610-01	20 - 2
6YK-24610-01	19 - 3
6H1-24633-00	6 - 25
6L2-26301-01	12 - 24
6L2-26363-00	12 - 36
6L3-28199-7D-D0	7 - 15
6L3-28199-7D-E0	7 - 15
6L3-28199-7D-F0	7 - 15
6L3-28199-7D-G0	7 - 15
6L3-28199-7D-H0	7 - 15
6L3-28199-7D-S0	7 - 15
6L3-28199-8E-K0	7 - 16
6L3-28199-8E-L0	7 - 16
6L3-28199-8E-M0	7 - 16
6L3-28199-8E-N0	7 - 16
6L3-28199-8E-P0	7 - 16
6L3-28199-8E-R0	7 - 16
6L2-41111-00-1S	2 - 28
6L2-41112-A3	2 - 29
	21 - 9
6L2-41113-00-1S	2 - 30
6L2-41114-A1	2 - 32
	21 - 8
6L2-41131-00-CA	16 - 10
6L3-41131-00-CA	16 - 10
6L2-41133-A3	16 - 13
	21 - 17
6L2-41134-00	16 - 11
	22 - 2
6L2-41212-00	13 - 22
6L2-41213-00	13 - 4
6L2-41217-00	4 - 25
6H1-41237-00	6 - 18
6L2-41237-00	13 - 26
662-41237-01	13 - 12
682-41237-50	6 - 17
6L2-41238-00	13 - 27
6L2-41257-00	4 - 24
6J8-41259-00	4 - 21
661-41262-02	4 - 22
	8 - 34
6J8-41271-01	4 - 23
689-41273-00	11 - 9
6J8-41274-00	11 - 10
6L2-41283-00	13 - 5
6G1-41611-00	9 - 17
6G1-41612-00	9 - 21
695-41613-00	9 - 18

PART NO. N° PIECES	REF. NO.
6L2-41631-00	13 - 6
6G1-41662-01-94	13 - 29
6G1-42111-12-4D	12 - 2
664-42119-00	12 - 13
6L2-42121-03-4D	14 - 21
6G1-42125-01	12 - 10
6G1-42126-00	12 - 11
6G1-42131-02	12 - 7
6L2-42137-00	12 - 15
6G1-42138-01	12 - 21
6E0-42159-02	12 - 22
6J8-42167-00	13 - 7
6L2-42167-00	13 - 8
689-42169-01	13 - 11
6F6-42177-A0	12 - 14
6L2-42192-00	13 - 16
6L2-42510-01-4D	14 - 26
6H4-42528-00	14 - 18
6L2-42610-30	1 - 1
6L3-42610-30	1 - 1
6L2-42613-01-4D	1 - 6
6L2-42615-00	1 - 2
6L2-42647-00	1 - 4
6G1-42651-71	1 - 3
6L2-42677-20	1 - 10
6L3-42677-20	1 - 10
6L2-42678-11	1 - 11
6L3-42678-11	1 - 11
6L2-42711-03-4D	11 - 1
6L2-42716-00	11 - 15
6L2-42719-A0	11 - 8
6L2-42725-00	11 - 11
6L2-42726-01	11 - 12
6G1-42727-00	11 - 13
6L2-42738-01	11 - 20
6L2-42748-01	11 - 14
6E7-42791-10	11 - 27
6AH-42794-40	11 - 28
6AH-42794-50	11 - 29
6L2-42815-01-4D	11 - 2
6L2-42816-00	11 - 4
6L2-43111-05-4D	14 - 1
6L2-43112-06-4D	14 - 2
6J8-43113-01	14 - 14
648-43114-01	14 - 8
6L2-43116-00	14 - 7
6E0-43118-01	14 - 5
6J8-43131-01	14 - 9

PART NO. N° PIECES	REF. NO.
6G5-43145-01	14 - 13
6L2-43160-01	15 - 4
689-43165-00	15 - 5
6L2-43165-01	15 - 1
6L2-43188-00	15 - 27
6L2-43191-01	15 - 14
6L2-43311-05-4D	14 - 15
682-43318-01	15 - 9
6L2-43336-00	15 - 37
6L2-43350-02	15 - 17
689-43373-01	14 - 19
6L2-43611-00	15 - 29
6J8-43611-01	15 - 18
6L2-43613-00	15 - 34
6L2-43614-00	15 - 20
6L2-43615-00	15 - 23
6L2-43617-00	15 - 33
6L2-43624-00	15 - 36
6L2-43630-01	15 - 8
6L2-43631-00	15 - 26
6L2-43633-10	15 - 28
6L2-43641-00	15 - 30
6L2-43657-00	15 - 24
6L2-43659-00	15 - 31
6L2-43676-00	15 - 25
6L2-43682-01	15 - 11
6L2-44111-01-94	12 - 25
6J8-44116-00	13 - 32
6L2-44121-00	13 - 21
6L2-44122-00	13 - 14
6L2-44123-00	13 - 34
6L2-44124-00	12 - 35
6L2-44125-00-94	12 - 30
6L2-44141-02	13 - 19
6L2-44141-10-94	13 - 20
6L2-44143-00	13 - 36
6L2-44147-00	17 - 20
6L2-44150-00	17 - 50
6L2-44150-10	17 - 50
6E0-44191-11	14 - 22
6L2-44311-00	17 - 9
6L2-44322-00	17 - 11
	22 - 15
6L2-44323-00	17 - 12
	22 - 12
6L2-44328-00	17 - 16
6L2-44352-00	17 - 13
	22 - 14

PART NO. N° PIECES	REF. NO.
6L2-44361-00	18 - 2
6L2-44361-10	18 - 2
6L2-44365-00	14 - 33
6L2-44366-00	18 - 3
6L2-44367-00	18 - 9
	22 - 5
6L2-44368-00	18 - 1
6BL-44391-00	11 - 21
6L2-44512-00-4D	14 - 31
6L2-44514-01	14 - 36
6L2-44526-00	14 - 41
6L2-44551-01-4D	14 - 43
6L2-44552-01-4D	14 - 44
6L2-44553-01-4D	14 - 49
6L2-44555-00	14 - 47
6L2-44557-00	14 - 48
6L2-45111-03-4D	16 - 1
6L2-45111-13-4D	16 - 1
6L2-45113-A2	2 - 35
	21 - 16
6L2-45114-A1	14 - 32
6L2-45115-00	16 - 3
663-45119-00	14 - 17
6L2-45123-01	16 - 12
6L2-45151-01-4D	16 - 2
6L2-45214-00	18 - 10
6L2-45215-00	18 - 11
6L2-45300-03-4D	17 - 1
6L2-45300-13-4D	17 - 1
6L2-45311-02-4D	17 - 2
6L2-45315-A0	17 - 22
	22 - 7
6L2-45331-00-CA	17 - 17
6L2-45361-03-4D	17 - 42
664-45371-01	18 - 7
6L2-45375-00	17 - 25
6L2-45510-00	17 - 26
6L2-45510-10	17 - 26
6L2-45536-00	17 - 6
6L2-45551-01	17 - 28
6L2-45560-10	17 - 32
6L2-45567-00	17 - 4
6L2-45567-10	17 - 4
6L2-45567-20	17 - 4
6L2-45567-30	17 - 4
6L2-45567-40	17 - 4
6L2-45571-00	17 - 33
6L2-45577-00	17 - 35

NUMERICAL INDEX
INDEX NUMERIQUE

PART NO. N° PIECES	REF. NO.
61N-85570-00	10 - 9
6L2-85580-10	9 - 5
6L2-85580-20	9 - 6
6L2-85720-02	6 - 45
6L2-W0001-03	21 - 1
6L2-W0001-C3	22 - 1
6L2-W0004-00	4 - 2
6L2-W0070-13	1 - 9
6L2-W0078-00	22 - 11
6L2-W0084-11-4D	12 - 1
6L2-W0090-12-1S	2 - 1
6L2-W0093-00	21 - 18
656-W2810-02	7 - 14
6J8-W4591-00-EL	18 - 20
90101-06M16	10 - 7
90101-08M09	14 - 39
90105-06M18	14 - 20
90105-08M02	18 - 8
90105-08M10	8 - 40
90105-10M12	18 - 5
90109-05M33	6 - 10
90109-06M28	13 - 23
90116-08016	12 - 8
90116-10M28	14 - 23
90119-06023	2 - 22
90119-06M04	14 - 37
90119-06M05	14 - 38
90119-06M14	2 - 11
90119-06M53	8 - 31
90119-06M65	6 - 41
90119-06MA3	2 - 27
90119-06MA4	2 - 33
90119-08M65	2 - 10
90119-08M91	2 - 21
90151-05M05	18 - 12
90152-05011	12 - 19
90157-05M16	19 - 5
90157-05M19	20 - 4
90157-06M06	16 - 7
90159-06M11	16 - 4
90170-06015	13 - 37
90171-14013	18 - 17
90179-10M14	17 - 29
90179-12M04	9 - 15
90185-05002	18 - 13
90185-08057	12 - 9
	14 - 42
90185-10051	14 - 25
	90185-22043
	90201-06060
	90201-08086
	90201-08M01
	90201-08M93
	90201-10M02
	90201-13M42
	90201-18522
	90201-20417
	90201-22M03
	90201-30M00
	90201-50306
	90202-05088
	90202-05M38
	90202-06009
	90202-15M37
	90202-36M55
	90206-12052
	90206-15M18
	90206-36M21
	90209-24M15
	90243-04M01
	90250-05010
	90254-03M04
	90266-04M00
	90266-04M04
	90269-02M09
	90280-03024
	90280-05013
	90338-05M03
	90340-08002
	90386-08032
	90386-12M45
	90386-12M72
	90386-15M73
	90386-22M67
	90386-30M60
	90386-30M75
	90386-33M96
	90386-34M97
	90387-06119
	90387-06M18
	90387-06M51

PART NO. N° PIECES	REF. NO.
90387-06M52	11 - 18
90387-28M00	3 - 17
90430-08020	17 - 8
	22 - 3
90445-07M04	6 - 14
90445-07M15	2 - 4
90445-07M16	6 - 16
90445-07M32	6 - 11
90445-09012	4 - 9
90445-10M40	2 - 34
90445-11M03	6 - 32
90445-11M05	20 - 11
90445-11M06	20 - 9
90445-11M07	6 - 33
90446-10M02	6 - 38
90464-08M07	10 - 11
90464-11M24	6 - 37
90465-06M86	10 - 13
90467-06016	2 - 5
90467-08004	4 - 10
	6 - 30
	7 - 6
90467-10M04	6 - 36
90467-11M08	6 - 31
90468-05M03	6 - 21
	12 - 40
90468-07M02	6 - 12
	6 - 15
	11 - 17
90480-15M31	10 - 12
90480-25161	10 - 12
90501-10065	17 - 37
90501-10227	8 - 27
90501-23215	12 - 17
90502-10M07	15 - 7
90506-20M27	15 - 16
90506-23M11	15 - 38
90508-12M28	15 - 21
90508-12M29	15 - 22
90510-08M04	8 - 12
91490-16010	12 - 12
91490-20010	12 - 34
	13 - 18
91490-30022	18 - 18
91690-30008	15 - 6
91690-30010	3 - 15
91690-40014	8 - 3
92900-04100	5 - 9
92903-05600	4 - 16

PART NO. N° PIECES	REF. NO.
92903-05600	13 - 25
92903-06600	2 - 16
	4 - 8
	8 - 37
	10 - 8
	13 - 31
	15 - 3
92990-06600	18 - 16
92995-05600	9 - 23
	9 - 26
	15 - 13
92995-06100	10 - 15
	10 - 18
92995-06600	1 - 8
	3 - 30
	6 - 44
	7 - 3
	8 - 6
	8 - 22
	8 - 24
	9 - 20
	10 - 3
	10 - 6
	10 - 22
	12 - 32
	14 - 35
	16 - 15
	17 - 15
	17 - 24
	17 - 48
92995-08600	14 - 51
	16 - 9
92995-10600	14 - 24
	18 - 6
93101-13M37	3 - 27
	21 - 3
93101-20048	17 - 19
	22 - 6
93101-20M07	17 - 46
	22 - 9
93102-25142	3 - 26
	21 - 2
93102-26M27	3 - 7
	21 - 10
93210-08287	20 - 14
	20 - 16
93210-13M04	6 - 4
93210-19M82	6 - 8


PART NO. N° PIECES	REF. NO.
92903-05600	13 - 25
92903-06600	2 - 16
	4 - 8
	8 - 37
	10 - 8
	13 - 31
	15 - 3
92990-06600	18 - 16
92995-05600	9 - 23
	9 - 26
	15 - 13
92995-06100	10 - 15
	10 - 18
92995-06600	1 - 8
	3 - 30
	6 - 44
	7 - 3
	8 - 6
	8 - 22
	8 - 24
	9 - 20
	10 - 3
	10 - 6
	10 - 22
	12 - 32
	14 - 35
	16 - 15
	17 - 15
	17 - 24
	17 - 48
92995-08600	14 - 51
	16 - 9
92995-10600	14 - 24
	18 - 6
93101-13M37	3 - 27
	21 - 3
93101-20048	17 - 19
	22 - 6
93101-20M07	17 - 46
	22 - 9
93102-25142	3 - 26
	21 - 2
93102-26M27	3 - 7
	21 - 10
93210-08287	20 - 14
	20 - 16
93210-13M04	6 - 4
93210-19M82	6 - 8



PART NO. / SERVICES N° PIECES	REF. NO.
93210-29375	14 - 29
93210-32738	7 - 10
	21 - 15
93210-35M86	4 - 14
93210-42159	3 - 8
	21 - 11
93210-45161	17 - 10
	22 - 4
	22 - 13
93210-56M80	3 - 28
	21 - 4
93210-60M99	17 - 49
	22 - 10
93210-60MA3	17 - 44
	22 - 8
93306-00612	17 - 43
93306-305U3	3 - 9
93310-424W9	3 - 12
93311-632U7	3 - 6
93315-22004	17 - 18
	17 - 45
93315-220V9	17 - 5
93332-00005	17 - 3
93341-320U0	17 - 30
93430-06M02	8 - 18
93450-20026	3 - 23
93602-18M12	3 - 22
93604-12M07	2 - 6
	14 - 45
	16 - 5
	17 - 21
	18 - 4
93700-06M03	14 - 16
94702-00271	2 - 36
95303-06700	8 - 16
95333-08600	2 - 9
95380-03600	5 - 25
95380-05600	13 - 13
95380-05700	6 - 19
	13 - 28
95380-06600	17 - 51
95380-06700	12 - 37
	13 - 3
95380-08600	7 - 13
95617-08645	2 - 7
95780-06300	11 - 7
95895-06012	13 - 33
95895-06020	11 - 19

PART NO. N° PIECES	REF. NO.
97013-05012	4 - 15
97013-05016	13 - 24
97013-06014	7 - 12
97013-06016	2 - 15
97013-06020	8 - 36
	13 - 30
97013-06025	4 - 7
	8 - 15
97075-06030	10 - 5
97075-08030	16 - 8
97090-06010	15 - 2
97095-05010	15 - 12
97095-06008	13 - 39
97095-06012	9 - 19
	10 - 14
	10 - 17
97095-06016	1 - 7
	3 - 29
	6 - 43
	8 - 5
	10 - 21
97095-06020	7 - 2
	8 - 38
	10 - 2
	12 - 31
	13 - 2
	14 - 34
	16 - 14
	17 - 23
	17 - 47
97095-06025	8 - 23
97095-06035	8 - 21
97095-06040	17 - 14
	22 - 16
97095-08045	14 - 50
97513-05518	6 - 9
97513-06585	4 - 17
97595-06420	10 - 10
97595-06575	13 - 9
97595-08585	14 - 46
97607-04110	9 - 7
97607-06125	9 - 8
97802-04006	9 - 9
97880-04010	5 - 8
97880-06035	11 - 6
97885-05010	9 - 22
	9 - 25
97885-05012	12 - 23

NUMERICAL INDEX
INDEX NUMERIQUE



PART NO. N° PIECES	REF. NO.	PART NO. N° PIECES	REF. NO.
97885-06008	14 - 4		
97980-04112	5 - 19		
	21 - 25		
97980-05216	4 - 3		
	4 - 20		
98980-04006	5 - 23		
99080-05600	15 - 15		
	15 - 19		
	15 - 32		
	15 - 35		
99530-10014	8 - 25		



FLOOD MARINE SERVICES

downloaded from www.yamahaoutboardparts.co.uk



PART NO. N° PIECES	REF. NO.

